

ELECTRICAL DISTRIBUTIONS

By

Dr Kyaw Naing

IQY IPEM Education Group

Section 1 – Distribution System

1.1 Describe the common system for electrical distribution	5
Distribution	5
System of Distribution	5
Relative Merits of Overhead and Underground Systems	5
Standard Voltages	7
Distribution Systems	7
Spacing of Substations	7
Single Phase Systems	7
Types of Feeders	8
Radial Feeders (Figure 3)	8
Parallel Feeders (Figures 4 and 5)	9
Ring Main Feeders	10
Substation Busbar Arrangements	10
Electrical Power System Considerations	11
Reserve, diversity, and economical dispatch	12
Industrial Heating	12
Electric Furnaces	12
Electronic Loads	13
Power Factor	13
Consumer Classification	13
Consumer Factors	13
Maximum Demand	13
Diversity Factor	13
Coincidence Factor	14
Utilisation Factor	14
Review questions for Section 1	15
2.1 Identify relevant components use in over head line design	16
Conductor Supports	16
Arcing Horns	20
Insulator Ties	20
2.2 Outline relevant factors related to installation, maintenance, cross arms, stays, pole types and choice of conductors sizes for commonly used configuration	21
Limiting Size of Aerial Conductors	21
Regulation 28.(1)	22
Regulation 28.(2)	22
SAGS	22
SAG Calculations	23
Table 1	23
Erection Sags	24
Sag Measurement	24
Sometimes the approximate formula is used	24
Wave Timing Chart	25
Figure 11	25
Wood Poles	28
AAC (All Aluminium Conductor)	28
2.3 Determine mechanical limitations and physical dimensions of lines – Part 1	31
Overhead Line Conductors	31
Material	31
Conductor Current Rating	31
Heating	32
Conditions Affecting Maximum Conductor Temperature	32
Fault Conditions	32
Voltage Drop	33
Power Losses	34
Pin Insulator Designation	34
Pin insulators are designated by a series of letters and numbers	34
Shackle Insulators	34
Disc Insulators	34
Stay Insulators	35
Insulator Pins	35
Causes of Insulator Failure	37
Mechanical Properties of Overhead Conductors	37
Reference	37
Working Strengths	37
Maximum Tensions	37

Section 1 – Distribution System

2.3 Determine mechanical limitations and physical dimensions of lines – Part 2	38
Armour Rods and Vibration Dampers	38
Helically Formed Fittings.....	38
Armour Rods.....	38
Line Guards	38
Vibration Dampers	38
Terminations or Dead Ends	39
Insulating Materials for Electrical Conductors	39
Polyvinyl Chloride (P.V.C).....	39
Cross-Linked Polyethylene (XLPE).....	39
Ethylene Propylene Rubber (EPR)	40
Impregnated Paper	40
2.4 Determine leading limitation using design schedules and calculations (Part 1)	42
Wood Poles.....	42
Table 7.2 Wood Pole Strength Tables	45
Steel Poles.....	46
Main Street Feeder Conversion	51
2.4 Determine leading limitation using design schedules and calculations (Part 2)	53
Criteria	53
Poles.....	53
Stresses.....	53
The cross sectional area at the top of a class 5 pole is	54
Bending Moment.....	55
Maximum Fibre Stress	55
So that	55
Wind Pressure	55
The pressure on the rectangle (P_x) will be	55
The pressure on the triangle (P) will be	55
And its moment about the base will be	56
And the load pressure on the pole (P_2) will be	56
And the total moment on the pole (M_2) will be	56
Examples 5-2	56
$M = \frac{4}{144} 34 \cdot 12^2 \cdot \frac{8}{3} \cdot \frac{12}{6} = 21,580$ in lb or 1798 ft lb.....	56
Say 700 lb/in²	56
Assume long leaf yellow pine, $f = 7400$ lb/in², is used	57
Table 5-2 Resisting Moments and Data for 40ft Poles	57
Example 5-4.....	58
For the three no. 4/0 conductors,	58
$\sqrt{\frac{3790 \cdot 420 \cdot 10^2}{7400}}$ 59,91 in at ground line.....	59
Check for the possibility of using a wallaba pole, $f = 11,000$ lb/in²	59
2.4 Determine leading limitation using design schedules and calculations (Part 3)	60
Example 5-5.....	60
$X = \sqrt{150^2 + 30^2}$ 146.96ft.....	60
$C = \sqrt[3]{\frac{3790 \cdot 416,000}{7400}}$ 59.73 in at ground line	61
Check for possible use of a wallaba pole, $f = 11,000$ lb/in²	61
Example 5-6	61
Total moment on pole $\sqrt{996.3^2 + 5.694^2} \cdot 10^2 = 996,316$ ft-lb	61
Equipment on Poles.....	61
Cross Arms	62
Bending Moment.....	62
Example 5-7.....	63
Double Arms	64

Section 1 – Distribution System

Cross Arm Brace.....	65
Table 5-3 – Ultimate Bearing Strength of Wood	66
Pins.....	66
Loading.....	66
Double Pins.....	67
Pins in Lieu of Cross Arms.....	67
Insulators.....	69
Loadings.....	69
Pin Type.....	69
Post Type.....	69
Suspension or Strain Type.....	69
Strain Ball Type.....	69
Spool Type.....	69
Guys and Anchors.....	70
Stresses.....	70
Anchor Guy.....	71
Span Guy.....	71
Loading.....	71
If T is the total tension caused by all the conductors, and a is the angle of.....	71
And the total stress handled by the guy is twice that, or.....	71
$Lx \text{ Lytan} b$ or $Lx \text{ Lcsin} b$	73
And the fibre stress in the pole at the point of attachment of the guy will be	73
Where d is the diameter of the pole at this point	73
Guy Wires.....	73
Anchors.....	74
2.4 Determine leading limitation using design schedules and calculations (Part 5)	75
Table 5-5A Classification of Soils.....	75
Straightaway Poles.....	76
Angle Poles.....	76
Dead End Poles.....	77
Guying Requirements.....	77
General.....	77
Straightaway Poles.....	77
Table 5-20 Multipliers for determining tension in guy wire when tension in line wire is known.....	76
Applicable to conditions A to D inclusive; see illustrations below	78
Table 5-21 Allowable Guy Tensions	80
Construction.....	80
Concrete Poles.....	80
2.5 State pole and line installation techniques	81
11.3.2 Structure construction procedures.....	81
11.6.1 Tension definition.....	81
Wire and Temperature Limits for ACSR & 6201 AAAC.....	82
Line Planning.....	82
11.10.1 Plan-profile Drawings.....	83
11.10.7 Final Drawings.....	85
2.6 Recall regulations pertaining to over head lines	115
Notes and comments on some of the overhead line construction and maintenance regulations.....	115
Regulation 12 - Protection against corrosion.....	115
Example.....	116
Maximum angle of deviation = 15.6^5	116
Regulation 18 – Supports	117
Regulation 19 – Earthing and Insulating of Metalwork.....	117
Regulation 20 – Prevention of Unauthorised Climbing.....	120
Regulations 21 – 26 – Overhead Service Lines.....	120
Regulation 28 – Size of Conductors.....	120
Regulation 33 – Separation of Conductors.....	121
2.7 Measure ground levels, deviation angles and compass bearings.....	126
Basic Survey Methods.....	126
Method 3 – Polar Co-ordinates/radiation	127
Site Surveying and levelling.....	129
Chain lines: AB, BC, CD, DA, DB, and AC	131
2.1.2 Survey Stations.....	131
2.1.3 The Base Line.....	131

Section 1 – Distribution System

2.3.6 Tapes	132
2.4.4 Laying-down the Chain	133
2.8 Perform basic survey of short distribution line extension to produce field notes.....	136
Re-Engineering the Transmission Line Design Process	140
INTRODUCTION	151
SURVEYING	151
ENGINEERING	153
DRAFTING	158
PROCUREMENT	159
CONCLUSIONS	160
REFERENCES	160
Review questions for Section 2	161
Label	164
3.1 Describe the construction features and insulation abbreviations of under ground cable..	168
Cables.....	168
The conductor	168
The conductor is made of either copper or aluminium	168
Types of Cables	169
Current Rating of Cables.....	170
Sheath Currents.....	170
3.2 Calculate cable voltage drop in relation to length of cable run (Part 1)-----	173
Calculation of voltage drop, Calculation of unit voltage drop, Single & 3 phase voltage drop, Maximum Voltage drop, Cable size selected, Practical exercises, Selection of cable based on voltage drop	
3.3 Recall techniques to reduce electrical stress on cables-----	183
Cable stand, Bending of cable, Temperature rating, Enclosure of cable, Type of conductor	
3.4 Recall cable rating factors, method of cable joining-----	187
Stripping cable, Basic terminating method, Soldering	
3.5 Apply cable schedules for underground cable installation scheme-----	190
Underground cable, Types of cables, Laying, Insulation resistance, Effect of inter-sheath on stress Capacitance grading, PF of single core cable, Capacitance of 3 core cable, Breakdown voltage and mechanical breakdown	
3.6 Describe techniques used to install cable and associate equipments-----	219
Ducts, Service box, Cable manhole, Transformer manhole, Design loading on manhole, Underground equipments	
3.7 Recall cable testing techniques and methods used to find the location -----	226
of cable fault	
Sectionalizing, Time domain reflectory method, Megger test	
4.1 Recall Terminology used in relation to voltage profile-----	231
Voltage regulation, Off load tap changer, On load tap changer, Booster transformer, Quadrature booster Induction voltage regulator	
4.2 Describe the reasons effects and limitation of voltage variation-----	232
Voltage control, Voltage drop, SAA Rules, Power loss	
4.3 Recall methods used in controlling voltage level Part 1-& 2-----	233
Method of voltage control, Voltage control equipments, Induction Voltage regulator, Constant ratio transformer, Voltage regulation by control current, Voltage profile	
Review Questions for section 3 and 4-----	245
References-----	260

Section 1 – Distribution System

1.1 Describe the common system for electrical distribution

The major electrical items encountered in most types of industrial commercial plants are listed below.

1. Power generation equipment, or purchased power switching, or substation.
2. Primary and secondary distribution systems, including feeders, transformers, switchgear, protective equipment and standby generating plant.
3. Motor drives, heaters, ovens and the associated wiring and control equipment.
4. Lighting equipment and lighting wiring circuits.
5. Electrical and electronic control and instrumentation systems.
6. Auxiliary systems (fire alarms, electric clocks, burglar alarms).
7. Communication equipment (paging, intercommunication).
8. Special items peculiar to processes such as welding, batteries, rectifiers, electroplating apparatus, elevators and lifts, industrial trucks, cranes and hoists, ventilation and air-conditioners.
9. Yard, roadway, and protective lighting.

Distribution

The limit of distribution is usually to be from substations to consumer's service lines and distribution within the consumer's premises.

System of Distribution

The systems of distribution may be classified as follows:

Overhead distribution.

Underground distribution

Combined overhead and underground distribution

Relative Merits of Overhead and Underground Systems

Overhead lines are less expensive than the underground cables throughout the whole range of system voltages, the difference being extreme at the higher voltages encountered in the field of transmission.

Overhead lines operate under continual stress and exposure to varying climatic conditions. This results in progressive deterioration because of both mechanical wear and corrosion. Line components must therefore be periodically replaced.

The greater spacing of overhead line conductors enables higher current ratings to be used but this produces higher circuit inductance.

The load capacity of an overhead feeder can be readily increased at relatively low cost by replacing it with larger conductors, or by using parallel feeders; however the

Section 1 – Distribution System

swamping effect of inductive reactance should be considered for low voltage conductors greater than 100mm² aluminium.

Poles and lines are considered unsightly, especially in built up areas.

Section 1 – Distribution System

Standard Voltages

The Australian Standard C1 1969 – *Standard Voltage and Frequency for a.c. Transmission and Distribution Systems* sets out the voltages which are to be regarded as standard. These are shown in the following tables:

Standard Voltages for Three Phase Systems

415 volts (voltage to neutral 240 volts)

11 kV

22 kV

33 kV

66 kV

Voltages of 3.3 kV and 6.6kV previously used for distribution are not considered satisfactory with the greater use of electricity. Such existing installations tend to be replaced by 11 kV and 22 kV.

Distribution Systems

Electricity supply systems follow a relatively uniform pattern.

The voltages vary with different authorities, and spacing and size of substations are dependent on the density of population.

A typical distribution system illustrated in Figure 1 Comprises:

Sub-transmission circuits operating at 33 kV or above which deliver energy to the zone substations.

Spacing of Substations

For a residential area the zone substations may be spaced at intervals of about 3-10 km and have a capacity of 7.5 MVA to 30 MVA.



The distribution centres would be spaced 400 – 600 metres apart and each would need to have a capacity of 500 kVA. The sizes and spacings are appropriate only, and in city areas one building may need in excess of 5 MVA.

Single Phase Systems

For rural systems economical distribution is usually accomplished by means of single phase systems.

The high voltage distribution can be of the standard three phase type for rural areas adjacent to suburban areas, but as the distance from such areas increases, the single wire earth return (SWER) system proves the most economical method. This involves only one high voltage conductor at 12.7 kV or 19.1 kV above earth potential. The low voltage system can then be a two wire system at 240 volts or three wire system at 480 volts – 240 volts to neutral. A typical distribution is shown in Figure 2.

Section 1 – Distribution System



Types of Feeders

Three types of feeders are commonly used for distribution systems.


These are:

- Radial feeders
- Parallel feeders
- Ring main feeders

Radial Feeders (Figure 3)

These are the simplest and least expensive both to construct and protect, particularly in overhead areas. The occurrence of faults results in a number of customers being without service until the fault has been located and cleared. To minimise interruptions to customers, reclosing breakers and sectionalisers are used, but if the fault is not self clearing all customers will be affected.

Section 1 – Distribution System




Parallel Feeders (Figures 4 and 5)


If separate routes are taken in either underground or overhead construction, the capital cost is double that of a radial feeder. If, however, the two cables are laid in the one trench or a double circuit overhead line is built, the first cost is about 140 per cent of that of radial construction. Protection is more complicated.

The big advantage of this system is that it ensures a firm supply to distribution centres with underground high voltage systems.

With overhead systems the reliability of a double circuit line is considerably below that of two separate routes since both circuits are likely to be affected by lightning, storm damage or structural failures. There is great advantage, however, in the maintenance of lines and circuit breakers.




Section 1 – Distribution System



Ring Main Feeders

Feeders are usually taken by different routes and the system gives a firm supply to all distribution centres. The feeders are usually designed to allow supply of the total load from either end of the ring.



Substation Busbar Arrangements


The form of busbar layout selected for any application must depend on the flexibility of operation required, and the price the user is prepared to pay for this flexibility of operation as regards maintenance and continuity of supply.

Busbar arrangement may be classified as:

- Single busbar systems
- Sectionalised busbar systems
- Ring busbar systems
- Duplicate busbar systems
- Duplicate ring busbar systems

Section 1 – Distribution System

The most common systems are shown below in single line form for three phase systems. It is important in all systems to be able to isolate circuit breakers and transformers so that maintenance can be carried out. Means must be provided for isolators for circuit breakers, and earthing switches for the earthing of high voltage equipment during maintenance.



Electrical Power System Considerations

Societies must use energy resources in the form in which they appear, whether as water, wind, oil, coal, or uranium, to accomplish the tasks the societies consider desirable. The desirable tasks may be heating, cooling, lighting, manufacturing, or transportation of people and materials. Finding and converting the raw energy that allows the raw energy resources and the equipment that converts energy to work to be separated by great distances.

Section 1 – Distribution System

Electricity does exist in nature as lightning and static electricity, but it cannot be controlled well enough to be put to practical use. Thus electricity must be generated by converting another raw energy resource. Electricity can be stored in batteries, but only in relatively small quantities. Therefore, at least for the present time, electricity must be produced at the same time it is used.

Reserve, diversity, and economical dispatch

Reserve is that portion of an electric utility's available generating capacity that is not producing electricity at a given time. *Spinning reserve* is the generating capacity that is being driven at the proper speed to provide proper voltage, but is not producing power. Spinning reserve can provide power to the system almost instantaneously if the system load is increased or a generator must be taken out of service. The FERC established a requirement that each electric power company construct sufficient excess capacity that it can supply its largest normal load with its largest generating plant off line. This rule has been modified for some circumstances, as will be discussed later. Spinning reserve should be sufficient to meet any sudden load changes anticipated by the utility.

Diversity is the term used to refer to load changes during a period of time. Load varies during the day because people get up, go to work, and return in the evening using different amounts of electricity to support their various activities. Similarly, industrial and commercial power use will vary during the day. There are also weekly and seasonal variations in electricity usage. In warm climate such as that along the Gulf Coast air conditioning results in high electricity consumption in the summers that peaks daily in the late afternoon. Figure 1.2 shows a 24 hour diversity curve for electric power consumption. The result of diversity is that the electric utility must supply varying amounts of power depending on the time of day, day of the week, and season.

Industrial Heating

Industrial heating may include large space heaters, ovens (baking, heat treating, enamelling, etc), furnaces (steel, brass, etc.), welders and high frequency heating devices. The first two are resistance type loads and operate much as the smaller residential devices, with operation at 120 or 240 V, single phase, and at unity power factor. Ovens, however, may be operated almost continuously for reasons of economy, and some may be three phase units.

Electric Furnaces

Furnaces may draw heavy currents more or less intermittently during part of the heat process and a fairly steady lesser current for the rest; on the whole, the power factor will be fairly high since continuous operation is indicated for economy reasons. The power factor of a furnace load varies with the type of furnace from as low as 60 percent to as high as 95 percent; with the greater number about 75 or 80 percent. Sizes of furnaces vary widely; smaller units with a rating of several hundred kilowatts, are usually three phase. Voltage regulation, while not critical, should be fairly close because of its possible effect on material in the furnace.

Section 1 – Distribution System

Electronic Loads

The electronic load category includes radio, television, x-rays, laser equipment, computers, digital time and timing devices, rectifiers, oscillators for high frequency current production, and many other electronically operated devices such as transistors semiconductors, etc. Practically all of these devices operate at voltages lower than the commercial power sources and employ transformers or other devices to obtain their specific voltages of operation. They are all affected by voltage variations.

Power Factor

The ratio of power (in watts) to the product of the voltage and current (in volt amperes) is called the power factor. It is a measure of the relation between current and voltage out of phase with each other brought about by reactance in the circuit (including the device served). Since facilities must be designed to carry the current and provide for losses which vary as the square of the current, it is necessary that current values be known. The power factor enables loads and losses designated in watts to be converted to amperes. Transformer sizes, wire and cable sizes, fuses, switch ratings, etc., are all based on values of current they must carry safely and economically.

Consumer Classification

As aids in planing, consumers may be conveniently classified into certain categories and certain ranges of load densities expressed in kVA per square mile (where this unit is too broad to be useful, watts per square foot for specific occupancies may be used).

Consumer Factors

It is obvious that an individual consumer is not apt to be using all of the electrical devices that constitute his or her “connected load” at the same time, or to their full capacity. It would evidently be unnecessary to provide facilities to serve such a total possible load, and much more economical to provide only for a probable load, the load creating the demand on the distribution facilities.

Maximum Demand

The actual load in use by a consumer creates a demand for electric energy that varies from hour to hour over a period of time but reaches its greatest value at some point. This may be called the consumer’s instantaneous maximum demand in practice, however, the maximum demand is taken as that which is sustained over a more definite period of time, usually 15, 30, or 60 min. These are referred to as 15-, 30-, or 60-min integrated demands, respectively.

Diversity Factor

The diversity factor is the ratio of the sum of maximum demands of each of the component loads to the maximum demand of the load as a whole (or the coincident maximum demand). For example, each of the loads mentioned above may have a

Section 1 – Distribution System

maximum demand of 100 kW, while the coincident maximum demand on the system supplying the three may be only 150 kW. The diversity factor is then $300 (100 + 100 + 100)$ divided by 150, or 2, or 200 percent. Such diversity exists between consumers, between transformers, and between feeders, substations, etc. Note that the *demand factor* is defined so that it is always less than 1 or 100 percent, while the *diversity factor* is the reciprocal of the demand factor and is always greater than 1 or 100 percent. This is a most important factor in the economical planning and design of distribution facilities.

Coincidence Factor

The coincidence factor is the ratio of the maximum coincident total demand of a group of consumers to the sum of the maximum demands of each of the consumers.

Utilisation Factor

The ratio of the maximum demand of a system to the rated capacity of the system is known as the utilisation factor. Both the maximum demand and the rated capacity are expressed in the same units. The factor indicates the degree to which a system is being loaded during the load peak with respect to its capacity. The rated capacity of a system is usually determined by its thermal capacity, but may also be determined by voltage drop limitations, the smaller of the two determining the capacity.

Section 1 – Distribution System

Review questions for Section 1

1 State **three** classifications of distribution system.

2 State the standard voltages for three phase distribution systems.

3 Sketch and describe a single wire earth return (SWER) system.

4 Sketch the three types of feeders that are commonly used for distribution system.
Describe the merit of each type.

5 Sketch the following busbar arrangements:

Single busbar

Sectionalise busbar

Ring busbar

Duplicated busbar

Section 2 – Overhead Lines and Installation

2.1 Identify relevant components use in over head line design

Conductor Supports


The types of supports for overhead conductors can be listed as follows;

Wood poles


Steel poles

Concrete poles


Steel Towers





Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation

Arcing Horns

In the case of insulator flashover due to lightning, the porcelain is often cracked or broken by the power arc that follows the initial discharge.

To protect against this trouble arcing horns or rings are installed on many overhead systems. These operate so that the arc is taken up by the electrodes and held at sufficient distance from the porcelain to prevent damage by the heat of the arc.


The advantage of the ring design lies in the front that the arc can form at any point around the insulator, and in case of formation at the windward side it may be blown around without damage to the insulator. With horns, the arc may be blown under the insulator and damage it.



Insulator Ties

These consist of a number of helically formed rods, the central portions of which are shaped to provide attachment of the conductor to a line pin insulator.

Some illustrations of insulator ties, line reinforcement at disc insulators, and armour rods are shown in Figures.



Section 2 – Overhead Lines and Installation



2.2 Outline relevant factors related to installation, maintenance, cross arms, stays, pole types and choice of conductors sizes for commonly used configuration

Limiting Size of Aerial Conductors

Both the SAA Wiring Rules and the Overhead Line Construction and Maintenance Regulations impose limits on the smallest size of conductor that can be used for aerial conductors.

The SAA Wiring Rules state that the minimum size of conductors and the maximum length of spans for various conductors are as follows:

Rule 3.13.2 Every conductor installed as an aerial conductor shall have not less than seven strands and shall not be smaller than 4 mm^2 copper or 16 mm^2 aluminium.

Rule 3.13.19 The length of span of copper aerial conductors shall not exceed the values given below

Type of Conductor	Size mm^2	Maximum Span Metres
Bare hard drawn	4	25
Conductors	6	30
	16 or over	60

Section 2 – Overhead Lines and Installation

Regulation 28.(1)

The ultimate tensile strength of an aerial conductor operating at a voltage of 650 volts or less shall not be less than 3000 N.

This makes the smallest size:

Copper	7/1.25	at	3610 N	Ultimate Strength
All Aluminium	7/1.75	at	3010 N	Ultimate Strength
Aluminium Alloy	7/1.75	at	4710 N	Ultimate Strength

Regulation 28.(2)

The ultimate tensile strength of an aerial conductor operating at a voltage of 650 volts or less shall not be less than 5000 N.

This makes the smallest size:

Copper	7/1.75	at	6890 N	Ultimate Strength
All Aluminium	7/2.50	at	5750 N	Ultimate Strength
Aluminium Alloy	7/2.25	at	7780 N	Ultimate Strength

SAGS

When distribution lines are erected, the sag allowed in a conductor at the time of erection must be such that the maximum tension allowable for the particular conductor is not exceeded under the conditions specified in the regulations.

Four sag conditions are of particular interest.


These are:

- The sag and tension in the conductor at 15 C with a wind loading of 500 Pascals on the projected area of conductors.
- The sag and tension in the conductor under conditions of no wind, at an ambient temperature of 5 C
- The sag at 50 C which determines the support height to maintain the statutory clearance above the ground.
- The sag of erection which will ensure that the above conditions are fulfilled.

On short spans condition (a) is usually the determining factor while the longer spans, particularly for aluminium conductors fitted with armour rods, condition (b) is the determining factor.

Section 2 – Overhead Lines and Installation

SAG Calculations



Calculate the allowable sag for a 7/3.50 hard drawn copper overhead conductor with a span of 150 metres. The wind loading is 500 Pascals and the maximum conductor tension is to be 50 per cent of the ultimate tensile strength.

Table 1

Ultimate tensile strength	=	26600 N
Gravitational Force	=	5.949 N/m
Diameter of conductor	=	10.5 mm
Wind loading per metre	=	Diameter in metres x wind loading in Pascals
	=	$10.5 \times 10^{-3} \times 500$
	=	5.25 Pa

Combined load due to wind and weight of conductor

$$\begin{aligned}
 W &= \sqrt{w_0^2 + w_1^2} \\
 &= \sqrt{5.949^2 + 5.25^2} \\
 &= \sqrt{62.95} \\
 &= 7.934 \text{ N/m}
 \end{aligned}$$

Section 2 – Overhead Lines and Installation

$$\begin{aligned} &= \frac{w^2 l^3}{8} \\ &= \frac{7.934 \times 150^2}{8 \times 26600 \times 0.5} \\ &= 1.678\text{m} \end{aligned}$$

Erection Sags

Since the line will never be erected under the conditions of wind and temperature as stated in the regulations, it is necessary to calculate the tension and sag under conditions at the time of erection.

There are two factors which vary the sag and tension, namely, elasticity and temperature. The load at erection may be less than it would be under regulated conditions. This lack of load will lessen the tension, so that the sag will be reduced because of elastic contraction. An increase in temperature will cause the length of the conductor to increase so that the sag will increase.

Sag Measurement

Sags may be measured by the following methods:

1. Sight Boards

The sight boards are fixed to two poles of the span at the appropriate height for the desired sag. The conductor is then pulled up to line with a sight taken between the two boards.

2. Wave Timing

For this method the conductor is struck at one end of the span and the time taken for the wave to travel the span six times is measured. The sag is then calculated from the formula


$$t = \sqrt{\frac{\text{Sag in metres}}{0.03408}}$$

t = time in seconds for 3 return waves

Sometimes the approximate formula is used

$$t = 5.42 \times \sqrt{\text{Sag in metres}}$$

Section 2 – Overhead Lines and Installation



Wave Timing Chart
Based on Formula


$$\text{Time (seconds) for 3 Return Waves} = \sqrt{\frac{\text{Sag in metres}}{0.03408}}$$

Figure 11

3. Optical Range Finders

Optical range finders are available for measuring the height of the conductor at the pole and the height of the conductor at mid span, while standing on the ground. From these readings the sag can be obtained from the difference, provided allowance can be made for any variations in ground level.

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation

From Table 1 – Open Supply Lines

	Voltage		
	0 to 750	750 to 15,000	15,000 to 50, 000
Required clearance over specified items			
Railroad Tracks	27	28'	30
Public streets, alleys or roads	18	20	22
Driveways to residential garages	10	20	22
Areas accessible to pedestrians only	10	15	17
Parallel to streets	18	20	22
Parallel to rural roads	15	18	20

From Table 4 – Clearance of supply lines from buildings

Voltage of supply conductors	Horizontal clearance	Vertical clearance
300 to 8,700	3	8
8,700 to 15,000	8	8
15,000 to 50,000	10	10

From Table 8 – Separation in inches required for line conductors #2 AWG or larger versus span sag

Voltage between conductor	Span sag in inches				
	36	48	72	96	120
2,400	14.5	16.5	20.5	23.5	26.0
7,200	16.0	18.0	22.0	25.0	27.5
13,200	18.0	20.0	23.5	26.5	29.5
34,500	24.0	26.5	30.0	33.0	35.5
69,000	36.6	36.5	40.5	43.5	46.0

Section 2 – Overhead Lines and Installation

Wood Poles

The simplest and cheapest support structures are wood poles. These were the first extensively used electrical conductor support structures. Wood poles have been made from larch, spruce, cedar pine, and fir trees, selected for height and straightness. The most commonly used trees for poles are Southern Yellow Pine (SYP) about 70%, and Douglas Fir, about 25%. All of the others comprise only about 5% of the wood poles used. Poles from 25 to 65 feet are generally SYP while poles over 65 feet are generally Douglas Fir. Wood poles are available in heights from 25 to 130 feet (or more on special order) in 5 foot increments.

Wood pole heights and strengths have been codified from tests, and tables prepared to make distribution design easier. A reliable average for maximum longitudinal fibre stress in both pine and fir is 8000 psi. That is the psi at which the wood fibres will start to split or slide past each other. So all design strengths have been calculated from this value. As force is gradually increased, a pole will fail first by splitting along the pole and then by breaking.

Poles are designated by strength and degree of straightness as class 1 (best through 5 (worst). Larger poles have their own classification as extra heavy duty classes 0,00,000, and 0000, with more zeros being heavier duty. The zeros are usually written as H1, H2, H3, H4.

AAC (All Aluminium Conductor)

All aluminium conductor is available in 7, 19, 37, 61, and 91 strands of #1350 aluminium wire. AAC has slightly better conductivity at low voltages than ACSR, but it has less strength and more sag per span length. It is used for lines with short spans. AAC costs about the same as ACSR.

Distribution spans are generally short because the lines are built on public roads, streets, and easements. It is not permissible to serve a building with service drops across streets or across property of another land owner. This means two lot widths is the general span for residential and light commercial and business districts. This is typically between 120 and 200 feet.


Section 2 – Overhead Lines and Installation

TABLE 9.1 Electrical characteristics of bare aluminum conductors steel-reinforced (ACSR)*

Code Word	Aluminum area, cmil	Stranding Al/St	Layers of aluminum	Outside diameter, in	Resistance			GMR D_g , ft	Reactance per conductor 1-ft spacing, 60 Hz	
					D_C , 20°C, $\Omega/1,000$ ft	Ac, 60 Hz			Inductive X_L , Ω/mi	Capacitive X_C , $M\Omega \cdot mi$
						20°C, Ω/mi	50°C, Ω/mi			
Waxwing	266,800	18/1	2	0.609	0.0646	0.3488	0.3831	0.0198	0.476	0.1090
Partridge	266,800	26/7	2	0.642	0.0640	0.3452	0.3792	0.0217	0.465	0.1074
Ostrich	300,000	26/7	2	0.680	0.0569	0.3070	0.3372	0.0229	0.458	0.1057
Merlin	336,400	18/1	2	0.684	0.0512	0.2767	0.3037	0.0222	0.462	0.1055
Linnet	336,400	26/7	2	0.721	0.0507	0.2737	0.3006	0.0243	0.451	0.1040
Oriole	336,400	30/7	2	0.741	0.0504	0.2719	0.2987	0.0255	0.445	0.1032
Chickadee	397,500	18/1	2	0.743	0.0433	0.2342	0.2572	0.0241	0.452	0.1031
Ibis	387,500	26/7	2	0.783	0.0430	0.2323	0.2551	0.0264	0.441	0.1015
Pelican	477,000	18/1	2	0.814	0.0361	0.1957	0.2148	0.0264	0.441	0.1004
Flicker	477,000	24/7	2	0.846	0.0359	0.1943	0.2134	0.0284	0.432	0.0992
Hawk	477,000	26/7	2	0.858	0.0357	0.1931	0.2120	0.0289	0.430	0.0988
Hen	477,000	30/7	2	0.883	0.0355	0.1919	0.2107	0.0304	0.424	0.0980
Osprey	556,500	18/1	2	0.879	0.0309	0.1679	0.1843	0.0284	0.432	0.0981
Parakeet	556,500	24/7	2	0.914	0.0308	0.1669	0.1832	0.0306	0.423	0.0969
Dove	556,500	26/7	2	0.927	0.0307	0.1663	0.1826	0.0314	0.420	0.0965
Rook	636,000	24/7	2	0.977	0.0269	0.1461	0.1603	0.0327	0.415	0.0950
Grosbeak	636,000	26/7	2	0.990	0.0268	0.1454	0.1596	0.0335	0.412	0.0946
Drake	795,000	26/7	2	1.108	0.0215	0.1172	0.1284	0.0373	0.399	0.0912
Tern	795,000	45/7	3	1.063	0.0217	0.1188	0.1302	0.0352	0.406	0.0925
Rail	954,000	45/7	3	1.165	0.0181	0.0997	0.1092	0.0386	0.395	0.0897
Cardinal	954,000	54/7	3	1.196	0.0180	0.0988	0.1082	0.0402	0.390	0.0890
Ortolan	1,033,500	45/7	3	1.213	0.0167	0.0924	0.1011	0.0402	0.390	0.0885
Bluejay	1,113,000	45/7	3	1.259	0.0155	0.0861	0.0941	0.0415	0.386	0.0874
Finch	1,113,000	54/19	3	1.293	0.0155	0.0856	0.0937	0.0436	0.380	0.0866
Bittern	1,272,000	45/7	3	1.345	0.0136	0.0762	0.0832	0.0444	0.378	0.0855
Pheasant	1,272,000	54/19	3	1.382	0.0135	0.0751	0.0821	0.0466	0.372	0.0847
Bobolink	1,431,000	45/7	3	1.427	0.0121	0.0684	0.0746	0.0470	0.371	0.0837
Plover	1,431,000	54/19	3	1.465	0.0120	0.0673	0.0735	0.0494	0.365	0.0829
Lapwing	1,590,000	45/7	3	1.502	0.0109	0.0623	0.0678	0.0498	0.364	0.0822
Falcon	1,590,000	54/19	3	1.545	0.0108	0.0612	0.0667	0.0523	0.358	0.0814
Bluebird	2,156,000	84/19	4	1.762	0.0080	0.0476	0.0515	0.0586	0.344	0.0776

*Most used multilayer sizes.

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation

2.3 Determine mechanical limitations and physical dimensions of lines – Part 1

Overhead Line Conductors

Material

The material for conductors is determined by the following:

Electrical properties such as resistance, reactance and current carrying capacity.

Mechanical properties such as tensile strength and weight.

Price of the material in relation to the return in the investment.

The following range of materials is suitable for overhead lines.

Hard drawn copper conductors

All aluminium conductors (AAC)

All aluminium alloy conductors (AAAC)

Aluminium conductors steel reinforced (ACSR)

Steel conductors galvanised (SC/GZ)

Steel conductors aluminium clad (SC/AC)

Cadmium copper

When steel is used as reinforcement or as a conductor or stay it must be protected against corrosion. The standard methods are galvanising or coating with aluminium – aluminium clad. An aluminium conductor, steel reinforced should have some indication of the corrosion prevention method; ACSR/GZ indicates that the steel core is galvanised, whereas an ACSR/AC indicates an aluminised steel core.

Of the above, the aluminium alloy conductors have a financial saving over copper, particularly in suburban work where span lengths are relatively short allowing for lower line tension.

Aluminium conductors require more precautions during erection than copper conductors because they are softer and more easily damaged. Aluminium tape is required at each tie, and joints must be cleaned and greased.

Conductor Current Rating

The current rating of overhead conductors depends upon:

Heating

Voltage drop

Power losses

Section 2 – Overhead Lines and Installation

Heating

The current carrying capacity of an overhead conductor is limited by:

- The annealing temperature of the conductor;

- The expansion due to temperature rise which causes a reduction of statutory clearance.

- A temperature rise which might occasion injury to any insulation.

For installations covered by the SAA Wiring Rules a table of maximum current values is given in the appendix of these rules.

For installations outside the scope of the SAA Wiring Rules the above table is still used as a guide, but various authorities have their own formula for current rating based on the maximum allowable operating temperature.

Reasonably accepted values for the maximum operating temperatures are:

- 75 C for continuous rating

- 100 C for one hour rating

Conditions Affecting Maximum Conductor Temperature

The factors which determine the maximum conductor temperature are:

- The ambient temperature

- Wind velocity

- Heat absorbed from solar radiation

- Heat lost by convection

- Heat lost by radiation

For this course it is not necessary to be able to calculate maximum allowable current ratings on a basis of the above factors as the information is usually available from the Energy Authority of NSW in the form of graphs.


Fault Conditions

Overhead line conductors may be overheated under fault conditions unless satisfactory protection is provided.

The graphs, figures 11 and 12 show the relationship between short circuit current and maximum time duration which this current can be allowed to flow without damage to the conductor.

The calculation of prospective fault currents will be dealt with later in this subject

Section 2 – Overhead Lines and Installation



The conductor must operate so that when the maximum current is being conveyed the fall in voltage along the line is within certain limits.

The value of fall in potential for a consumer's overhead line must be taken into account when ensuring that the fall in potential from the consumers mains to any point on the installation does not exceed five per cent of the voltage at the commencement when full current is flowing. This is required by the SAA Wiring Rules.

For supply authorities distribution there is more latitude because voltage regulating equipment can be installed to allow for fall in voltage.

The Australian Standards specification AS – C1 Standard Voltages and Frequencies for AC Transmission and Distribution Systems gives an indication of the limits to be aimed for.

Section 2 – Overhead Lines and Installation

For medium voltages, the variation at the consumer's terminals should not exceed six per cent and for higher voltages the variations should not exceed ten per cent.

Power Losses

The power lost in distribution feeders depends on the square of the current and the resistance of the feeder. This loss must be considered in relation to the capital cost involved in the erection of the distribution line.

Apart from voltage and weather designation the factors to be considered in the selection of an insulator are:

- a. Minimum mechanical strength
- b. Minimum impulse withstand voltage at power frequency
- c. Minimum wet withstand voltage at power frequency
- d. Minimum puncture voltage at power frequency
- e. Minimum creepage distance between conductor tie and pin

Pin Insulator Designation

Pin insulators are designated by a series of letters and numbers

First letter	S	-	Standard
	F	-	Fog Type
	A	-	Aerodynamic
Next two letters	LP	-	Line Pin Insulator
First number			Nominal voltage kV
Second number			Minimum creepage distance
Example			ALP 33/920

This is an aerodynamic type line pin insulator for 33 kV with 920 mm creepage distance.

Shackle Insulators

Shackle insulators are used for terminations and angle construction mainly on low voltage lines. The high voltage shackle insulator is now displaced by the disc insulator.

Two types of low voltage shackle insulators are common: the SH, LVI with a minimum failing load of 9 kN and the SH. LV2 with a minimum failing load of 20 kN.

Disc Insulators

Disc insulators are used on high voltage lines for both intermediate and strain constructions. They may be used in combination and as a general rule one disc is suitable for 11kV, two for 22 kV and 3 for 33kV. The discs are available with minimum failing loads of 44 kN and 66 kN.

Disc insulator assemblies are identified by the use of suitable abbreviations of the description and number of the components forming the assembly.

Section 2 – Overhead Lines and Installation

S	-	Suspension
A	-	Anchor shackle
B	-	Hanger bracket
D	-	Disc
E	-	Eye bolt
N	-	Eye nut
P	-	Pole band
P1	-	Pole band termination
P2	-	Pole band through construction
S	-	Straight tongue

Example EA/2D represents a disc insulator unit with an eye bolt support, a shackle between the eye bolt and disc, and having two discs.

Stay Insulators

There are four standard types of stay insulators and these are tabulated below:

Stay Insulator Type	Line Voltage	Steel Wire Size	Minimum Failing Load kN
G Y 1	LV + 11 kV	7/2.75	27
G Y 2	11 kV	19/2.00	71
G Y 3	22 kV	19/2.75	222
G Y 4	33 kV	19/2.75	222

Insulator Pins

Insulator pins are made from hot rolled carbon steel and galvanised as shown in Figure 23

These pins are fitted with lead alloy heads composed of 95 per cent lead and 5 per cent antimony which are threaded to one of four standard forms. These are shown in Figure 24 and are designated as A, B and C.

Pattern B is used mainly for insulators of voltages up to 600 volts while pattern C is used mainly for high voltage insulators. Pattern A may be used for both medium and high voltage insulators.


The pin is designated by a reference number which gives the lead head pattern, as denoted by the letter representing the thread type, the stem length in millimetres, and the failing load for the pin kilonewtons. This reference number is usually stamped on the collar. The recommended working load for the pin is one third the failing load.

Section 2 – Overhead Lines and Installation

Standard pins are as follows:

Pin Type	Shank Size
B / 100 / 3.5	140 x 16 mm
A / 130 / 7	165 x 20 mm
C / 150 / 7	165 x 20 mm
C / 150 / 11	165 x 24 mm
C / 200 / 11	165 x 24 mm
C / 300 / 7	165 x 24 mm

For example, a C/300/7 insulator pin would have a C type thread, stem length would be 300mm and the transverse failing load for pin would be 7 kN.



Section 2 – Overhead Lines and Installation

Causes of Insulator Failure

The following is a list of some of the causes of insulator failure:

1. Deterioration by cracking of the porcelain
2. Porosity of the porcelain
3. Puncture of weak porcelain
4. Shattering of insulator caused by power arc
5. Flashover of insulator caused by dust or salt deposits
6. Failure of insulator from excessive mechanical stress
7. Short circuits caused by birds or animals

Mechanical Properties of Overhead Conductors

Reference

Overhead lines must be erected in accordance with the Overhead Line Construction and Maintenance Regulations set out under the Electricity Development Act and published by the Energy Authority of NSW. A copy of these regulations is necessary for the course.

Working Strengths

The ultimate strengths of copper, all aluminium, and all aluminium alloy conductors are given in Australian Standards publications AS 1746, AS 1531 Part 1 and AS 1531 Part 2 respectively and the values listed in these publications must be used in conjunction with the working conditions laid down in the Overhead Line Construction and Maintenance Regulations. Tables 1, 2 and 3 give the properties of these conductors.

Maximum Tensions

The maximum tension to be allowed on a conductor is specified for two conditions, namely:

1. The maximum conductor tension shall not be more than fifty per cent of the ultimate tensile strength under a wind loading of 500 pascals at 15 C, and
2. The maximum conductor tension in still air at 5 C is not to exceed the following:
 - 25 per cent UTS for hard drawn copper conductor
 - 18 per cent UTS for hard drawn all aluminium, steel cored aluminium and hard drawn cadmium copper conductors, and
 - 18 per cent UTS for aluminium alloy conductors

If vibration dampers are fitted the percentages rise to 33 1/3 per cent for hard drawn copper conductors and 25 per cent for hard drawn aluminium, steel cored aluminium and hard drawn cadmium copper.

Vibration dampers are fitted to transmission lines rather than distribution feeders.

Section 2 – Overhead Lines and Installation

2.3 Determine mechanical limitations and physical dimensions of lines – Part 2

Armour Rods and Vibration Dampers

Overhead conductors are subjected to mechanical vibrations caused by change of wind pressure. This may take the form of swinging of the conductors, or of high frequency vibrations caused by the formation of eddies on the leeward side of the conductor. These high frequency vibrations can cause metal fatigue at the points where the conductor is supported at the insulator, thus ultimately causing failure of the conductor.

Such failure is reduced greatly where the conductor is reinforced at the point of support, and by carefully designed conductor clamps.

Such reinforcing takes the form of armour tape or armour rods. Aluminium armour tape should be applied in aluminium and aluminium alloy conductors.

Helically Formed Fittings

At various points on overhead lines it is necessary to fix conductors and stay wires in position. For example, conductors must be fixed to line pin insulators, at terminations, conductors must be fixed to the shackle or disc insulators, and stay wires must be fixed to the pole and stay anchorages. For these purposes various methods of splicing or the use of wire rope grips have in the past been main methods.

Helically formed fittings are now common for these applications. These consist of elastic rods which have been formed into an open helix and are wrapped around a conductor or stay having a diameter somewhat greater than the internal diameter of the helix. The rods then firmly grip the conductor or stay.

Helically formed fittings are sometimes called preformed fittings. The following gives some types of fittings available.

Armour Rods

These are helically formed rods of relatively large diameter wire and are applied to sheath a conductor at support points. The reason for using armour rods was given in an earlier paragraph.

Line Guards

These are shorter in length and of smaller diameter wire than armour rods. They are used at conductor supports to protect the conductor against chafing or flash over burns

Vibration Dampers

A helically formed vibration damper is manufactured which has somewhat similar properties to the Stockbridge damper

Section 2 – Overhead Lines and Installation

Terminations or Dead Ends

These are helically formed wires, bent at the centre to form a hairpin shape. The free ends are interleaved on to the conductor or stay wire during application, leaving a loop to which tension is applied.

Insulating Materials for Electrical Conductors

In distribution networks the purpose of an electrical conductor is to carry the current from one point to another and the purpose of the insulating material is to confine the current to the conductor. A variety of insulating materials has been processed and developed to withstand the conditions under which conductors operate, such as

1. Temperature extremes – high and low
2. Moisture
3. Gaseous, dirty and abrasive environments
4. Mechanical vibration and impact
5. Transient high voltages

The electrical insulation of cables is protected by the addition of a sheath and, where required, by the further addition of serving, armouring bitumen and inhibitors as referred to in the section on cables to follow.

Insulating materials that are at present most commonly used for cables are:

Polyvinyl Chloride (P.V.C)

Vinyl chloride is a colourless gas derived from acetylene and hydrochloric acid, the basic raw materials being lime, salt and coke. At low temperatures the gas becomes liquid and can be distilled to obtain the desired degree of purity. On polymerisation a white powder is formed, this being the basic material or polymer to which a number of chemicals is added to obtain the thermoplastic known as polyvinyl hydrochloride (P.V.C). The additives have a marked effect on the physical and electrical properties of the finished product. Properties such as flexibility, abrasion resistance, embitterment at low temperatures, tear ability, oil resistance, termite resistance and colour are readily controlled.

Thermoplastic insulants are less tolerant than other materials to overload and short circuit conditions. Fuses and other protective devices must be sufficiently sensitive to prevent the P.V.C approaching softening point, even for a few seconds.

Black compounds are always recommended for aerial use and exposed installations. This is due to the screening effect on ultraviolet rays which would cause deterioration of coloured compounds.

As with physical, electrical properties are controlled to a marked extent by the nature and quantity of the additives. Variations in temperature and frequency cause marked changes in electrical characteristics.

Cross-Linked Polyethylene (XLPE)

This material is one of the most commonly used insulants for power cables. It is a thermosetting material and, as such, possesses extremely good thermal and electricity stability.

Section 2 – Overhead Lines and Installation

This material is one of the most commonly used insulants for power cables. It is a thermosetting material and, as such, possesses extremely good thermal and electrical stability.

Low cost, ease of fabrication and excellent mechanical and chemical resistant properties have led to its wide use as cable insulation for all types of applications.

Because of its excellent resistance to heat, XLPE cables are suitable for continuous operation at 90 C, short time operation at 130 C and short circuit performance up to 250 C. These characteristics, combined with high continuous and short circuit current ratings, lightness, robustness and ease of use have been responsible for their world wide use acceptance and use. The cross linking of polyethylene is achieved by chemical means. XLPE has a very small power factor and dielectric constant when compared to other insulants. It also shows good resistance to chemicals such as ordinary acids, greases and oils.

Compacted conductors are generally used for 1.9 / 3.3kV cables and above. High voltage XLPE cables are compacted to reduce the size of the interstices which in turn tends to prevent the semi conductive screen material moving into the air spaces. Compacting is achieved by passing the stranded cable through a tight die. Reducing its overall diameter by approximately 10%. Material is not removed from the metallic conductor, thus maintaining the same resistance, but the small amount of cold working of the material tends to increase its tensile strength and makes the cable a little stiffer.

Ethylene Propylene Rubber (EPR)

EPR insulation is a thermosetting material and possesses excellent thermal and electrical properties. Although EPR has a higher dielectric constant and power factor than XLPE, it has greater resistance to corona, ozone and fire and has more flexibility than XLPE. Because of high raw material costs EPR is used in preference to XLPE only where EPR's greater flexibility is required.

Impregnated Paper


The paper used is of uniform texture and long fibre and is free from any imperfections. It does not contain chemical impurities or loading materials and has low ash content. It has been selected to give high dielectric strength when impregnated, and to last without any deterioration of electrical properties. It is generally cheaper than other forms of insulants and has an exceptionally long life span. Further information on this type of material is provided in the next section on cables.

Section 2 – Overhead Lines and Installation

Insulation	Specific Gravity	Relative Permittivity	Thermal Resistivity <i>cm/W</i>	Volume Resistivity At 20 C <i>m</i>	Dielectric Loss Factor At 20 C	Maximum Conductor Temperature <i>C</i>	Maximum Short Circuit Temperature <i>C</i>
PVC	1.47	5.0-8.0	5.0-6.0	10^{12}	0.08	75	15-160
PE	0.92	2.3	3.5	10^{14}	0.0001	70	130
XLPE	0.92	2.5	3.5	10^{14}	0.0008	90	250
EPR	1.20	3.0	3.5-5.0	10^{13}	0.004	90	250
Impregnated Paper	1.10	3.3-3.9	6.0	10^{13}	0.004	65-80	160-250

Section 2 – Overhead Lines and Installation

2.4 Determine leading limitation using design schedules and calculations (Part 1)



Wood Poles


The simplest and cheapest support structures are wood poles. These were the first extensively used electrical conductor support structures. Wood poles have been made from larch, spruce, cedar pine, and fir trees, selected for height and straightness. The most commonly used trees for poles are Southern Yellow Pine (SYP) about 70%, and Douglas Fir, about 25%. All of the others comprise only about 5% of the wood poles used. Poles from 25 to 65 feet are generally SYP while poles over 65 feet are generally Douglas Fir. Wood poles are available in heights from 25 to 130 feet (or more on special order) in 5 foot increments.

Wood pole heights and strengths have been codified from tests, and tables prepared to make distribution design easier. A reliable average for maximum longitudinal fibre stress in both pine and fir is 8000 psi. That is the psi at which the wood fibres will start to split or slide past each other. So all design strengths have been calculated


Section 2 – Overhead Lines and Installation

from this value. As force is gradually increased, a pole will fail first by splitting along the pole and then by breaking.

Poles are designated by strength and degree of straightness as class 1 (best through 5 (worst). Larger poles have their own classification as extra heavy duty classes 0,00,000, and 0000, with more zeros being heavier duty. The zeros are usually written as H1, H2, H3, H4.



Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation

Table 7.2 Wood Pole Strength Tables

50 Ft. Pole, Douglas Fir or SYP

Class H1, WL = 2,200 lb.			Class 1, WL = 1,970 lb.		
Distance From top (feet)	Diameter (inches)	Moment (ft.-k)	Distance From top (feet)	Diameter (inches)	Moment (ft.-k)
0	9.23	51.5	0	8.59	41.5
10	10.57	77.3	10	9.90	63.4
30	13.28	152.1	30	12.50	127.9
40	14.58	203.0	40	13.80	149.6
50	15.92	264.2	50	15.11	179.2

50 Ft. Pole, Douglas Fir or SYP

Class 2, WL = 1,700 lb.			Class 3, WL = 1,220 lb.		
Distance From top (feet)	Diameter (inches)	Moment (ft.-k)	Distance From top (feet)	Diameter (inches)	Moment (ft.-k)
0	7.96	33.0	0	7.32	25.7
10	9.19	50.8	10	8.48	39.9
30	11.65	103.4	30	10.79	82.3
40	12.88	139.4	40	11.95	111.7
50	14.11	183.7	50	13.11	147.4

70 Ft. Pole, Douglas Fir or SYP

Class H1, WL = 3,640 lb.			Class 1, WL = 3,225 lb.		
Distance From top (feet)	Diameter (inches)	Moment (ft.-k)	Distance From top (feet)	Diameter (inches)	Moment (ft.-k)
0	9.23	51.5	0	8.54	41.5
30	12.96	142.5	30	12.18	118.1
50	15.45	241.3	50	14.56	202.1
70	17.93	377.6	70	16.95	318.7


70 Ft. Pole, Douglas Fir or SYP

Class 2, WL = 2,840 lb.			Class 3, WL = 2,470 lb.		
Distance From top (feet)	Diameter (inches)	Moment (ft.-k)	Distance From top (feet)	Diameter (inches)	Moment (ft.-k)
0	9.23	33.0	0	7.32	25.7
30	11.00	96.7	30	10.60	78.0
50	13.68	167.5	50	12.79	137.0
70	15.97	266.3	70	14.698	220.0


Section 2 – Overhead Lines and Installation

Steel Poles

Steel poles have been used now for a long time, and are well proven. They do not have the elasticity of wood poles, nor do they have the lifetime. The life of a steel pole is governed primarily by the quality and thickness of the galvanising. There are special paints to make a steel pole look better longer, but it is impractical to paint the inside of the pole, so that galvanising sets the pole life. Steel poles typically last from 25 to 30 years.



Section 2 – Overhead Lines and Installation





A steel pole requires an embedment depth of 10% of the height plus 2 feet for standard soil. Thus a 50 foot pole has an embedment of 7 feet while a 70 foot pole has an embedment of 9 feet. The soil must be tamped to 100% compaction, meaning to the density it was before the hole was dug. Specifications usually require two tampers for each shoveler when the soil is filled in around the pole. A pole set in soil can be loaded immediately.


Embedment can be reduced if concrete stabilised sand, rock, or concrete are used for fill. Concrete stabilised sand is a mixture of $\frac{3}{4}$ sand and $\frac{1}{4}$ concrete used for fill where the soil has too much give to support a pole well. The concrete stabilised sand essentially increases the size of the pole end so that the loading per unit area on the soil is lower. The concrete must set up before the pole can be loaded. Reinforced concrete foundations for steel poles can be very expensive, costing more than the pole for some dead end poles. They are necessary in soils that are particularly corrosive to steel. Figure 7.6 is a sketch of a reinforced concrete steel pole foundation. Anchoring is much cheaper and is used on wood and directly imbedded steel poles.

Poles and embedment are designed to support forces that are balanced on either side of the pole. Down guy wires and anchors are used to balance the forces on the pole in situations in which balanced pole loading is not possible.


Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation




Main Street Feeder Conversion

The voltage change over for the Main Street feeder is done as follows;

Temporary framing for 12.47 kV is installed below the present line as shown in Figure 7.22. Generally a 12 to 14 foot cross arm is used for 12.47 kV lines. This can be done without killing power.

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation

2.4 Determine leading limitation using design schedules and calculations (Part 2)

Criteria

The mechanical design of the distribution system, and its several parts, must not only be adequate to sustain the normal stresses and strains, but must safely sustain them during abnormal conditions brought about by the vagaries of nature and people. While design criteria for overhead systems are substantially different from those for underground systems, in both instances prudent design takes into account economic and other non technical considerations.

In general, the code specifies:

1. Clearance between conditions and surrounding structures for different operating voltages and under different local conditions.
2. Strength of materials and safety factors used in proposed structures.
3. Perhaps the most basic, the probable loading imposed on the conductors and structures based on climatic conditions, approximately defined by geographical areas.

Type of loading	Radial thickness of ice		Wind load on projected area of conductors		Temperature	
	in	cm	lb/ft ²	Kg/m ²	⁵ F	⁵ C
Heavy	0.5	1.27	4	20	0	-18.0
Medium	0.25	0.63	4	20	+15	-9.4
Light	0.0	0.0	9	44	+30	-1.1

Poles

Stresses

The forces acting on a pole stem from the vertical loading occasioned by the weight it has to carry and from the horizontal loadings applied near the top of the pole. These latter are exerted by the conductors as a result of uneven spans.

Both vertical and horizontal loadings include the effects of ice collecting radially about the conductors.

The vertical force on the pole is the dead weight of the conductors with their coatings of ice, cross arms, insulators, and associated hardware. This vertical force exerts a compressive stress that may be considered uniformly distributed over the cross section of the pole. This loading, however, is almost always overshadowed by the requirements of the horizontal loadings, and is usually not given further attention. Even a very light pole can safely carry the dead weight of a multi-circuit, large conductor line.

Section 2 – Overhead Lines and Installation


From wire manufacturer's tables, no. 4/0 copper wire has a diameter of 0.528 in and a weight of 640.5 lb per 1000 ft; and 397.500-cmil ACSR has a diameter of 0.806 in and a weight of 620.6 lb per 1000 ft. The total weight, including ice, for 200 ft (100 ft on each side of pole) for the copper conductors is 2120 lb plus 500 lb allowed for four cross arms, insulators, etc., or 2620 lb. For the ACSR conductors, it is 2840 lb, plus the same 500 lb, or 3340 lb.

The cross sectional area at the top of a class 5 pole is

$$2 \frac{19^2}{2} \frac{90.25}{3.14} = 28.7 \text{ in}^2$$

This may be rounded off to 25 in².

Conservatively, the dead weight of the copper conductors is 2750 lb divided by 25 in², or 110 lb/in²; that of the ACSR conductors is 3500 lb divided by 25 in² or 140 lb/in².



Section 2 – Overhead Lines and Installation

Bending Moment

The bending moment M is equal to the horizontal force applied P , multiplied by its perpendicular distance to the point where failure may occur, h , usually taken at the ground line.

$$M = Ph$$

Maximum Fibre Stress

The maximum fibre stress f at any cross section is

$$f = M \frac{c}{I}$$

Where c is the distance from the extreme fibres of cross section to the neutral axis and I is the moment of inertia of the cross section. For a circular cross section, where d is the diameter.

$$c = \frac{1}{2}d$$

$$I = \frac{d^4}{64} = 0.491d^4$$

So that

$$f = \frac{M}{0.0982d^2}$$

$$\frac{I}{c} = \frac{d^3}{32} = 0.0982d^3 \quad (\text{called the section modulus})$$

Wind Pressure

In arriving at M , if P is the wind pressure on the length of the conductor, including its coating of ice, and h the distance or height from the ground at which the circular cross section is to be determined, the total moment for the several conductors that may be supported is the sum of the values of Ph for all the conductors.

To this must be added the wind pressure on the pole itself. Here, the longitudinal cross section of the pole may be broken down into a rectangle and a triangle, as indicated in Fig. 5.2.

The pressure on the rectangle (P_x) will be

$$P_x = P_1 d_2 h$$

Where P_1 is the unit pressure in pounds per square inch. Its moment M_x about the base will be

$$M_x = P_1 d_2 \frac{h^2}{2}$$

The pressure on the triangle (P) will be

$$P = P_2 d_2 \frac{h}{2}$$

Section 2 – Overhead Lines and Installation

And its moment about the base will be

$$M_2 = P_2 d_2 \frac{d_2}{2} \frac{h^2}{6}$$

And the load pressure on the pole (P_2) will be

$$P_2 = P_2 h \frac{d_2}{2} \frac{d_2}{2}$$

And the total moment on the pole (M_2) will be

$$M_2 = P_2 h^2 \frac{d_2}{3} \frac{d_2}{6}$$

The total moment the pole must accommodate will be the sum of the moment for the several conductors and the moment on the pole itself.

Examples 5-2

Assume a 40 ft pole (required for clearance) set 6 ft in the ground with three no. 4/0 stranded copper conductors on a cross arm with the conductors level at the top of the pole, and 150 ft balanced spans, in a heavy loading area (see Table 5-1)

The moment due to wind on the conductors when ice coated is as follows. No. 4/0 stranded copper wire has a diameter of 0.528 in; allow 1 in of ice, for a unit diameter of 1.528 in of area to the wind.

$$M = 3 \frac{1.528 \text{ in}}{12 \text{ in/ft}} 150 \text{ ft} 4 \text{ lb/ft}^2 40 \text{ ft} 6 \text{ ft}$$

$$= 7792.8 \text{ ft lb or } 95,513.6 \text{ in lb}$$

The moment on the pole itself due to wind (for an estimated diameter at the top of 8 in, and 12 in at the bottom) is as follows;

$$M = \frac{4}{144} 34 12^2 \frac{8}{3} \frac{12}{6} = 21,580 \text{ in lb or } 1798 \text{ ft lb}$$

Say 1800 ft lb. The total for both is 115,093 ft in lb: say 115,000 in lb, and

$$f = \frac{115,000}{0.0982 12^2} 678 \text{ lb/in}^2$$

Say 700 lb/in²

The ultimate fibre stress for several woods and the resultant factors of safety for those woods are as follows.

Section 2 – Overhead Lines and Installation

Wood	Ultimate Stress, lb/in^2	Factor of Safety
Northern White Cedar	3,600	5+
Western Red Cedar	5,600	8
Long-leaf Yellow Pine	7,400	10+
Wallaba	11,000	15+

The total moment at the pole is 9591 ft lb, say 9600, multiplied by a factor of safety of 2, it is 19,200 ft lb, say 20,000.

From the ASA Standards Table of Wood Pole Classification, for a 40 ft class 5 pole, the resisting moments at 6 ft from the butt, nearest to this value but greater, are shown in Table 5-2. Any of these poles will sustain the loading due to wind.

As a check, the pole circumference C , in inches, required to withstand a bending moment M , in foot-pounds, for a wood having a permissible fibre stress f , in pounds per square inch, is

$$C = \sqrt{\frac{5790M}{f}}$$

Assume long leaf yellow pine, $f = 7400 \text{ lb}/in^2$, is used

$$C = \sqrt{\frac{3790 \cdot 20,000}{7400}} = 21.71in$$


This is the minimum required, as opposed to the 31.5in actual circumference. The difference provides a margin which insures the performance of the pole should it rot at the ground line and reduce the cross sectional area there.

Table 5-2 Resisting Moments and Data for 40ft Poles

Wood	Class	Resisting moment, ft-lb	Circumference, in	
			Minimum, at top	6 ft from butt
Northern White Cedar	5	60,800	19	40.0
Western Red Cedar	5	60,700	19	34.5
Long-leaf Yellow Pine	5	60,900	19	31.5

From ASA Standards Table of Wood Pole Classifications

Section 2 – Overhead Lines and Installation



Example 5-4

Assume that the 40-ft pole in Example 5-2 supports three no. 4/0 bare stranded copper conductors in one direction and three no. 2/0 bare stranded copper conductors in the other in a straight line; there are 150 ft spans in both directions. Refer to Fig 5-3

The moment on the pole caused by the wind for the three no. 2/0 conductors is as follows;

$$M = 3 \frac{1.418}{12} \frac{150}{2} \cdot 34 = 3616 \text{ ft}\cdot\text{lb}$$

For the three no. 4/0 conductors (from example 5-2)

$$M = \frac{1}{2} \cdot 7792 = 3896 \text{ ft}\cdot\text{lb}$$

Assume that the ultimate strength of the copper conductors is 37,000 lb in^2 and that they are sagged to one half their ultimate strength. The total moment on the pole caused by conductor tension, for the three no. 2/0 conductors is:

$$M = 3 \cdot 0.418 \frac{37,000}{2} \cdot 34 = 788766 \text{ ft}\cdot\text{lb}$$

For the three no. 4/0 conductors,

$$M = 3 \cdot 0.528 \frac{37,000}{2} \cdot 34 = 996,336 \text{ ft}\cdot\text{lb}$$

Section 2 – Overhead Lines and Installation

The difference between the two is 207,570 ft-lb (say 207,600 ft-lb). The total moment on the pole from the conductor tension and wind is:

$$M = \sqrt{M^2 + M^2} = \sqrt{207.6^2 + 9.3^2} \times 10^2 = 207.8 \times 10^2$$

Multiplied by 2 for a factor of safety, $M = 415.6 \times 10^2$; say 420,000 ft-lb.

To find the pole circumference required to withstand this bending moment, assume $f = 7400 \text{ lb/in}^2$ for long leaf yellow pine:

$$C = \sqrt{\frac{3790 \times 420 \times 10^2}{7400}} = 59.91 \text{ in at ground line}$$

This is beyond the strength of a 40-ft pole of the maximum class, 00; a guy should be installed.

Check for the possibility of using a wallaha pole, $f = 11,000 \text{ lb/in}^2$

$$C = \sqrt{\frac{3790 \times 420 \times 10^2}{11,000}} = 52.50 \text{ in at ground line}$$

A 40 ft wallaha pole of maximum class 00 will not accommodate this loading; a guy is still required.

Section 2 – Overhead Lines and Installation

2.4 Determine leading limitation using design schedules and calculations (Part 3)




FIG. 5-4 Loadings due to (a) offset in line and (b) bend in line. (c) Loading due to dead end.

Example 5-5

Assume the same 40-ft pole and three no. 4/0 stranded copper conductors level with the top of the pole, with equal 150-ft spans on each side, as in Example 5-2, but with the line offset this time by 30 ft, as shown in Fig 5-4a. The moments on pole B due to the conductors, from A toward B, and B toward C, are 996,336 ft-lb, and;

$$X = \sqrt{150^2 - 30^2} = 146.96 \text{ ft}$$

Where X is the portion of the conductors exposed to wind. The moment on pole B, the portion in line with BC, is;

$$M_{BC} = \frac{146.96}{150} \times 996,336 = 976,144 \text{ ft-lb}$$

The moment on pole due to wind for one 150-ft span, from Example 5-4, is 3896 ft-lb, and

$$M_{BX} = 3896 \times \frac{146.96}{150} = 3896 \times 0.9797 = 3813 \text{ ft-lb}$$

The total moment on pole B, in line, is 996,336 – 976,144, or 20,192 ft-lb. At right angles, it is 199,267 ft-lb, or (30ft = 146,96 ft) x 976,144. The wind moment is 7713 ft-lb, and the total right angle moment is 206,980 ft-lb.

Section 2 – Overhead Lines and Installation

$$M_B = \sqrt{20,192^2 + 206,980^2}$$

Multiply by 2 for the factor of safety; the result is 416,000 ft-lb. For pine.

$$C = \sqrt[3]{\frac{3790 \cdot 416,000}{7400}} = 59.73 \text{ in at ground line}$$

This is beyond the strength of the 40-ft maximum pole class, 00; a guy is required.

Check for possible use of a wallaha pole, $f = 11,000 \text{ lb/in}^2$

$$C = \sqrt[3]{\frac{3790 \cdot 416,000}{11,000}} = 52.33 \text{ in at ground line}$$

This is also beyond the strength of the 40-ft maximum pole class, 00; a guy is still required.

Example 5-6

Assume that the 40-ft pole in Example 5-2 supports three no. 4/0 bare stranded copper conductors dead ended on the pole, with a span of 150 ft, as shown in fig. 5-4c.

The moment on the pole due to three no. 4/0 conductors with a 150 ft span, from Example 5-5, is 996,33 ft-lb. The moment on the pole due to wind on the conductors is 3896 ft-lb, and that due to wind on the pole is 1798 ft-lb. The total moment on the pole due to wind is 5694 ft-lb.

$$\text{Total moment on pole} = \sqrt{996.3^2 + 5.694^2} \cdot 10^2 = 996,316 \text{ ft-lb}$$

Multiply by 2 for a factor of safety:

$$M = 1,992,632 \text{ ft-lb}$$

For pine,

$$C = \sqrt[3]{\frac{3790 \cdot 1,993 \cdot 10^2}{7400}} = \sqrt[3]{1,020,000} = 100.65 \text{ in}$$

The circumference is much beyond any 40-ft pole, pine or wallaha (from the conclusions in Example 5-5). Guying must be used or other means employed to accommodate the loading safely.


Equipment on Poles

Poles supporting transformers, capacitors, regulators, switches, or other equipment also adds to the wind loading. Since the centre of gravity projects out from the pole, a moment is created on the upper portions of the pole, pivoting about its lower point of support. Ordinarily, the pole class selected for supporting the conductors, with its factors of safety included, is capable of carrying this additional load safely. For the larger scale equipment installations, however, a pole one class greater than that adequate for the conductors is specified.

Section 2 – Overhead Lines and Installation

Cross Arms

Cross arms are now almost limited to carrying polyphase circuits in areas where appearance is not of paramount importance. They are also used where lines cross each other or make abrupt turns at large angles to each other. They are used as alley or side arms in which the greater part of their lengths extends on one side of the pole to provide adequate clearances where pole locations may be affected by limited space rights of way. Cross arms are shown in.




Bending Moment

The total bending moment M is equal to the sum of all the individual loads multiplied by their distances from the cross section under consideration. Ordinarily, the weakest section should be at the middle of the arm where it is attached to the pole. At the pin holes, however, the cross section of the cross arm is reduced and may, under unusual circumstances, be the weakest point in the cross arm. The determination can easily be made by computing unit fibre stress at the several points. Like the pole, the cross arm acts as a beam and the same formula for determining stresses may be employed.

Section 2 – Overhead Lines and Installation

$$f = \frac{M}{I/e}$$

Where f = maximum unit fibre stress occurring at extreme edges of cross section, lb/in^2
 M = total bending moment, in lb
 I = moment of inertia of cross section



Modulus becomes;

$$\frac{I}{c} = \frac{1}{6}d b^2 \frac{a^2}{b}$$

Where a is the diameter of the hole.

Example 5-7

Assume a standard 8ft six pin arm mounted at its centre on a pole, supporting six conductors, each of which, with a half inch coating of ice, has a maximum weight of 100 lb. The lengths, or moment arms, from the centre of the arm to each of the pins are respectively 15, 29 1/2, and 44 in.

The moment about the first pin hole from the pole is:

Section 2 – Overhead Lines and Installation

$$M = 100lb \cdot 14\frac{1}{2}in = 100lb \cdot 29in = 4350in.lb$$

With the 3 ½ x 4 ½-in cross section reduced by a 1-in pin hole, the section modulus at that point is;

$$\frac{I}{c} = \frac{1}{6} (3.5)^3 - 1.0 \cdot 4.5^2 = 8.4375$$

And the fibre stress is:

$$f = \frac{M}{I/c} = \frac{4350}{8.4375} = 515.56lb/in^2$$


Double Arms

When fibre stresses approach the maximum safe values for a particular kind of wood (always keeping in mind a factor of safety of 2), two arms or double arms are used. Ordinarily, these are found at dead ends, at points where loads are greatly unbalanced (such as large offsets or bends in the line), and at intermediate points along a long line to limit damage in the event that conductor breaks creating severe load unbalances on the supporting structures.

The two arms are placed one on each side of the pole and bolted together near the ends, and often at intermediate points. Properly constructed, with spacers of wood or steel between the arms, the structure created would act as truss with strengths of 10 to 12 times that of a single arm, or 5 to 6 times that of the two arms considered individually. Since such quality trusses may not always be constructed in the field, prudence dictates that only the ultimate fibre strength equivalent to that of two cross arms be considered. Where the loadings on the arms may exceed their fibre strengths, the arms may be guyed, as shown in Fig 5-8, or steel arms may be substituted for wooden ones.

Douglas fir and long leaf yellow pine are the most popular kinds of wood used for cross arms, though other kinds may also be found in use. Their ultimate bearing strengths are listed in Table 5.3 .

Section 2 – Overhead Lines and Installation



Bearing strength on an inclined surface at an angle to the direction of the grain is given as follows:

$$f_a = f \sin^2 a + n \cos^2 a$$

Where a is the angle of the inclination of the load to the direction of the grain.


Cross Arm Brace

Cross arms fastened to poles are usually steadied in position by braces. Flat braces, usually flat strips of galvanised steel bolted to the cross arm and fastened

Section 2 – Overhead Lines and Installation

Table 5-3 – Ultimate Bearing Strength of Wood

Wood	End-grain bearing f	Cross-grain bearing
Long-leaf Yellow Pine	5000	1000
Douglas Fir	4500	800
Western Red Cedar	3500	700
Cypress	3500	700
Redwood	3500	700
Northern White Cedar	3000	700



The maximum unit pressure must not exceed the bearing value of the wood, or distortion will take place. As the ultimate strength of the wood is approached, the bolt will tend to bend as the fibres of the wood begin to give way, as shown in Fig.5-9b.

Pins

Loading

Pins are subject to both vertical and horizontal loadings. The vertical loading results from the weight of the conductor and its half inch radial coating of ice. The horizontal loading stems from the wind, from differential tensions in adjacent conductors spans,

Section 2 – Overhead Lines and Installation

from nontangent spans, or from broken wire conditions in which the tensions in the conductor spans become unbalanced.

Under vertical load, the pin acts as a simple column, transmitting its load to the cross arm at the shoulders resting on the cross arm. The stress is equal to the load divided by the area under pressure, the area of the shoulder resting on the cross arm. This component is usually not large compared with the other components acting on the pin and is often neglected.

Under horizontal loadings, the pin acts as a cantilever beam, and the maximum stress occurs at the point where the pin rests on the arm. The bending moment M is equal to the load P multiplied by the distance of the conductor above that point (h):

$$M = Ph$$

The maximum fibre stress is usually considered to be at the point where the shoulder comes in contact with the cross arm. Its unit value, in pounds per square inch, may be calculated.

$$f = \frac{Ph}{0.0982d^2}$$

Where d is the diameter of the shank of the pin.

Since the balancing of moments may occur at the edge of the shoulder of the pin (for either wood or metal) rather than at the edge of the shank of the pin, some crushing effect may take place on the wood of the cross arm, which may affect its strength substantially. In such instances, the weak point may occur at the cross section of the pin above the cross arm; the value may be found by substituting the diameter of the pin at about one third of the distance down from the point of the conductor attachment, approximately the diameter at the weak point.

Double Pins




Double pins, one on each of the double arms, are used where the strength of one pin is inadequate.

Pins in Lieu of Cross Arms

The advent of wye primary systems employing a common neutral with the secondary (situated on the pole in the secondary position) allowed single phase primary conductors to be supported on a steel ridge pin, as shown in Fig 5-11. The vertical loading on the pin, the weight of the ice-coated conductor, is transmitted to the pole through the bolt by which the pin is attached to the pole. Horizontal loadings, from both wind and conductor tension, act on the pin as a cantilever beam, and the same analysis of stresses in the pin, bolt, and pole applies here as with cross arms.

In polyphase systems, the conductors may be supported on pins attached directly to the pole, eliminating the use of cross arms (this method of support is sometimes referred to as "armless construction"). This not only makes for a neater appearance, but, as indicated earlier, improves electrical performance by mitigating the voltage drop due to the reactance of the line. (The arrangement and spacing of the conductors accounts for the lessened reactance. Also, this construction employs bucket trucks or platforms for easier access to the conductors.)

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation

Insulators

Insulators used on overhead distribution systems are made of porcelain, glass, and, more recently, synthetic materials. Glass insulators, though no longer widely installed, exist in abundant numbers and will probably remain in service for.

Loadings

In general, porcelain has relatively little tensile strength but excellent strength in sustaining compressive stresses, properties substantially true also of glass. Lines are therefore so designed that the insulator materials will be in compression when carrying the (mechanical) loads imposed on them.

Pin Type

As the name implies, pin type insulators are mounted on pins (of either wood or metal) and the conductors are fastened to them. Their strengths (in compression) are usually greater than those of the pins upon which they are mounted. The dimensions of the insulating material necessary to meet the mechanical requirements are usually ample in meeting the electrical requirements, including surge voltages when wet.

Post Type

The post type insulator is essentially a pin type insulator that incorporates its own steel pin. Vertical loads are provided for by the porcelain, while horizontal loads act to create a moment about the point of attachment to the pole. Stress is transmitted by its steel core (or pin) to the cross arm or pole.

Suspension or Strain Type

The suspension or strain type insulators are also known as disk or string insulators. They are not generally used on distribution circuits except at turning points and at dead ends, where pins and pin type insulators may not provide sufficient strength; they are particularly useful in providing for the unbalance of stresses caused by broken conductors where pins, and even double pins, may be adequate and some form of insulated clamp or other means of attachment is required. Here the conductors are dead ended on each side of the pole, and the disk insulator, designed for heavy loadings of 10,000 to 20,000 lb (and similar to those used for transmission lines, but smaller in diameter), serves this purpose. Often, two or more such disks are assembled as a unit to accommodate higher operating voltages.

Strain Ball Type

The strain ball type of insulator has been used to dead end lower voltage primary and secondary conductors, and as an insulator in guy wires in older installations; many still exist. Here, the porcelain is under compression, accommodating the stresses imposed on it. Standard ratings include strengths (in compression) of 10,000, 12,000, and 15,000 lbs

Spool Type


Insulators of the spool type are associated with secondary racks, described earlier, and are standardised in design. The compressive strength of the spool porcelain is usually greater than the strength of the other parts of the rack.

Section 2 – Overhead Lines and Installation

Guys and Anchors

Stresses

When the horizontal loads imposed on poles and cross arms may exceed the safe carrying strengths of the wood involved (or holding power of the soil), guys of steel wire are usually installed to take up or counteract the excessive stress. The various types of guys are shown in Fig. 5-15. Note that the guys take up the horizontal stresses and distribute them to the other cross arms, to other poles and into the ground, or directly into the ground. The structural and environmental conditions peculiar to each situation dictate the type of guy used. Fig 5-15




Section 2 – Overhead Lines and Installation

Anchor Guy

The most commonly used guy is the anchor guy, of which one end is fastened to the pole and the other end to a rod to which is attached an anchor that is buried in the ground. The anchor selected depends on the holding power of the soil: from poor in swamps to excellent in hard and dry earth.

Span Guy

In the span guy, the guy wire extends from the head of the pole under load horizontally to an adjacent pole; since this merely transfers the load through the guy wire to the other pole, the receiving pole must be strong enough to take the additional load, or the receiving pole must be guyed.



Loading

The loads imposed on guys are generally due to the tension in the conductors and the angle between adjacent conductor spans, if any; the magnitude of the tension depends on the size of the conductor, its loading (including wind and ice), and the sag in the span. The design limits are usually based on the elastic limit of the conductors (e.g., 50 to 60 percent of the ultimate strength of copper).

The usual stress is generally less than that, as the design limits are based on the worst assumed loading conditions, which are approached only occasionally.

The stress on the pole at an angle in the line is also due to tension in the conductors, but only a component of that tension is handled by the guy; the amount depends on the size of the angle in the line. Refer to Fig. 5-17a.

If T is the total tension caused by all the conductors, and a is the angle of

$$T_a = T \sin \frac{a}{2}$$

And the total stress handled by the guy is twice that, or


Section 2 – Overhead Lines and Installation

$$T_a = 2T \sin \frac{a}{2}$$

If the tensions in the two spans are not balanced, then the resultant stress will be the vector sum of the two, and will be the stress handled by the guy. Wind pressure on the pole itself must also be taken into account in determining the total load to be handled by the guy.

If the angle is large, usually more than 60° , the loading on the guy bisecting the angle will be greater than the dead end loading of the line, and it is generally better to install two guys, considered as dead end guys, if practical.

The guy should be attached as near as practicable to the centre of loading of the loads it supports. Where the individual loads act at different elevations, they should be converted into an equivalent single load at the point of attachment of the guy. If T is the loading (say the primary) at height h , T_1 is the loading (say of the secondary) at height h_1 , P is the wind pressure on the pole assumed to be concentrated at height h , and L is the equivalent horizontal loading. Fig 5-17a & b



Since the guy is not usually horizontal, the actual tension in it will be greater than L , If b is the angle the guy makes with the horizontal, then the loading in the guy, L_a is:

$$L_a = \frac{L}{\cos b}$$

Section 2 – Overhead Lines and Installation

The vertical component L_v is:

$$L_v = L \tan b \text{ or } L \sin b$$

Assume three no. 4 medium hard drawn copper primary conductors dead ended at the top arm 33 ft above the ground, and 4 no. 2 soft drawn copper cabled secondaries dead ended 2 ft below, or 31 ft above the ground; a pole face area of 25 ft²; and a wind pressure of 4lb/ft² applied one third the distance down from the top arm, or 22 ft above the ground. The guy is attached 30 ft above ground at an angle of 45°.

$$\begin{aligned} T_p &= 3 \times 950 = 2850lb \\ T_1 &= 4 \times 990 = 3960lb \\ P_w &= 25 \times 4 = 100lb \\ L_H &= \frac{2850 \times 33 + 3960 \times 31 + 100 \times 22}{7300} = 7300lb \\ L_G &= \frac{7300}{\cos 45^\circ} = \frac{7300}{0.707} = 10,325lb \end{aligned}$$

If the guy is attached at a point too far from the centre of the load, a significant stress may be imposed on the pole, as the section of the pole above that point acts as a beam, and the moment at that point will be approximately

$$M = T_p h_p + h T_1 + h P_w (h - h_w)$$

And the fibre stress in the pole at the point of attachment of the guy will be

$$f = \frac{M}{0.0982d^3}$$

Where d is the diameter of the pole at this point

Guy Wires

Guy wire is made of stranded steel cable (usually 7 or 19 strands) so that the failure of one or two strands will not cause the immediate failure of the cable. The strands are usually galvanised or copper clad to resist the effects of weather. The strands may be of mild steel or high strength steel, but must be of sufficient strength to support the loads imposed on the guy. Such steel wires usually come in four grades of strength, and standards further specify that guy wires not be stressed beyond 75 percent of their ultimate strengths. Wires are manufactured in diameter differences or steps of $\frac{1}{11}$ in, but sizes less than $\frac{1}{4}$ in or greater than $\frac{1}{2}$ in are seldom, if ever used, two or more guys being employed if stresses greater than the maximum strength of the guy wire are required. In practice, however, only three sizes are usually stocked and specified: light, medium, and heavy. They are often referred to by their maximum permissible strengths, eg 6,000lb, 10,000lb, and 20,000lb (6M, 10M, and 20M)

The characteristics of steel wire used for guys are given in Table 5-4.

Guy wires are attached to poles and cross arms by eye bolts, thimbles, clamps, clips, hooks and plates, and special guy bolts which have the eye shaped and bent at an angle to accommodate the wire.

Section 2 – Overhead Lines and Installation


Wire Class	Ultimate Strength. lb/in^2	Elastic limit lb/in^2
Standard	47,000	24,000
Regular	75,000	38,000
High strength	125,000	69,000
Extra high strength	187,000	112,000

Weight of steel wire: $0.002671 lb/in^2$

Modulus of elasticity: 29×10^2

Coefficient of linear expansion:

Within the $\frac{1}{2}$ to $\frac{1}{4}$ in range, for the four classes of wire, ultimate strengths vary from a minimum of 1,900 lb to a maximum of 27,000 lb



Anchors

The holding power of the anchor should obviously match the strength of its associated guy wire. In general, the holding power will depend on the area the anchor offers the soil, the depth at which it is buried as a function of the weight or resisting force of the soil, and the kind and nature of the soil.

Section 2 – Overhead Lines and Installation

2.4 Determine leading limitation using design schedules and calculations (Part 5)

Table 5-5A Classification of Soils

Class	Description
1	Hard rock; solid
2	Shale, sandstone; solid or in adjacent layers
3	Hard, dry; hardpan, usually found under class 4 strata
4	Crumbly, damp; clay usually predominating. Insufficiently moist to pack into a ball when squeezed by hand
5	Firm, moist; clay usually predominating with other soils commonly present. Sufficiently moist to pack into a firm ball when squeezed by hand (most soils in well drained areas fall into this classification)
6	Plastic, wet; clay usually predominating as in class 5, but because of unfavourable moisture conditions, such as in areas subjected to seasonally heavy rainfall, sufficient water is present to penetrate the soil to appreciable depths and, though the area be fairly well drained, the soil becomes plastic during such seasons, and when squeezed will readily assume any shape (a soil not uncommon in fairly flat areas)
7a	Loose, dry; found in arid regions, sand or gravel usually predominating (filled in or built up areas in dry regions fall into this class, and as the name implies there is very little bond to hold the particles together).
7b	Loose, wet; same as loose, dry for holding power; high in sand, gravel or loam content. Holding power in some seasons is good, but during rainy seasons soil absorbs excessive moisture readily with resultant loss of holding power, especially in poorly drained areas. This class also includes very soft wet clay
8	Swamps and marshes

Type of anchor and rod rise						
Screw		Expanding			Swamp	
Soil class	8 in 1 in x 5.5 ft	Eight way 8 in ½ x 8 ft	Eight way 10 in 1 in x 10 ft	Four way 12 in 1 1/2 in x 10 ft	13 in 2 in pipe	15 in 2 in pipe
1	NR	NR	NR	NR	NR	NR
2	NR	NR	NR	NR	NR	NR
3	NR	26,500	31,000	40,000	NR	NR
4	11,000	22,000	26,500	34,000	NR	NR
5	8,000	18,500	21,000	26,500	NR	NR
6	6,500	13,000	16,500	21,500	NR	NR
7	3,500	10,000	12,000	16,000	NR	NR
8	NR	NR	NR	NR	12,000	13,000

Section 2 – Overhead Lines and Installation

Straightaway Poles

- Step 1. Determine the grade of construction applying, B or C.
- Step 2. Determine the factor of safety required for transverse loading, and calculate the total load on the pole
- For grade B construction, the factor of safety is 4 and the total load is $4 c d e f$.
 - For grade C construction, the factor of safety is 2 and the total load is $2 c d e f$.
 - For grade C construction at crossings, the factor of safety is 2.66 and the total load is $2.66 c d e f$.
- Step 3. Calculate the total ground line moment on the pole by multiplying the total load (step 2) by the average height of the conductors or equipment.
- Step 4. Select the pole class having a ground line resisting moment at least equal to that calculated in step 3.
- Step 5. If the pole is to support equipment, determine the pole class required by the weight of the equipment. If it exceeds that selected in step 4, the larger class should be specified.
- Step 6. If the transverse loading is too great for the unsupported pole, proceed to the section Guying Requirements in this appendix.

Angle Poles

- Step 1. Determine the grade of construction applying.
- Step 2. Determine the factor of safety required for the type of loading, and calculate the total load on the pole
- For grade B construction, the factors of safety are 4 and 2 and the total load is $4 c d e f + 2b$.
 - For grade C construction, the factors of safety are 2 and 1.33 and the total load is $2 c d e f + 1.33b$.
 - For grade C construction at crossings, the factors of safety are 2.66 and 1.33 and the total load is $2.66 c d e f + 1.33b$.
- Step 3. Calculate the total ground line moment on the pole by multiplying the total load (step 2) by the average height of the conductors.
- Step 4. Select the pole class having a ground line resisting moment at least equal to that calculated in step 3
- Step 5. If the pole is to support equipment, determine the pole class required by the weight of the equipment. If it exceeds that calculated in step 4, the larger class should be specified.
- Step 6. If the calculation in step 4 results in a class 5 pole, guying or cribbing will generally not be required unless soil conditions are poor. If the

Section 2 – Overhead Lines and Installation

result is other than class 5, proceed to the section Guying Requirements.

Dead End Poles

- Step 1. Determine the grade of construction applying, B or C
- Step 2. Determine the factors of safety required for dead end loading, and calculate the total load on the pole
 - a. For grade B construction, the factor of safety is 2 and the total load is 2a.
 - b. For grade C construction, the factor of safety is 2 and the total load is 1.33a.
- Step 3. Calculate the total ground line moment on the pole by multiplying the total load (step 2) by the average height of the conductors.
- Step 4. Select the pole class having a ground line resisting moment at least equal to that calculated in step 3
- Step 5. If the pole is to support equipment, from Table 5-18 determine the pole class required by the weight of the equipment. If it exceeds that calculated in step 4, the larger class should be specified.
- Step 6. If the calculation in step 4 results in a class 5 pole, guying or cribbing will generally not be required unless soil conditions are poor. If the result is other than class 5, proceed to the section Guying Requirements.

Guying Requirements

General

Smaller poles may be specified on the assumption they will be used with guying; this is possible because the pole acts as a strut only, the horizontal load being supported by the guy wire. Poles supporting equipment, or placed at a turn angle greater than 10^5 , however, should not be smaller than class 4.

The steps enumerated above under Pole Class Requirements should cover all extreme cases of transverse or longitudinal loading. If the loading is too great for the unsupported pole, the following additional steps for each classification of pole, designed to determine guying requirements, should be considered.

Straightaway Poles

- Step 7. Determine the factor of safety required for transverse loading, and calculate the total load on the pole.
 - a. For grade B construction, the factor of safety is 2.66 and the total load is 2.66c.
 - b. For grade C construction, the factor of safety is 2 and the total load is 2c
- Step 8. From Table 5-20, calculate the guy tension.

Section 2 – Overhead Lines and Installation


Step 9. From table 5-21 , select the proper guy wire for the tension

Table 5-20 Multipliers for determining tension in guy wire when tension in line wire is known

Applicable to conditions A to D inclusive; see illustrations below

H.	D. ft												
	5	6	7	8	10	12	14	16	18	20	25	30	35
15	3.16	2.69	2.36	2.12	1.80	1.60	1.46	1.37	1.30	1.25	1.16	1.12	1.09
16	3.35	2.85	2.47	2.24	1.89	1.67	1.52	1.41	1.34	1.28	1.19	1.13	1.10
17	3.54	3.00	2.63	2.35	1.97	1.73	1.57	1.46	1.37	1.31	1.21	1.15	1.11
18	3.75	3.16	2.76	2.46	2.06	1.79	1.63	1.50	1.41	1.35	1.23	1.17	1.12
19	3.93	3.32	2.89	2.58	2.15	1.87	1.68	1.55	1.49	1.38	1.26	1.19	1.14
20	4.12	3.48	3.05	2.69	2.24	1.94	1.74	1.60	1.49	1.41	1.28	1.20	1.15
21	4.32	3.64	3.17	2.81	2.33	2.01	1.80	1.65	1.54	1.45	1.31	1.22	1.17
22	4.51	3.80	3.30	2.93	2.42	2.09	1.86	1.70	1.58	1.49	1.33	1.24	1.18
23	4.71	3.96	3.44	3.04	2.51	2.16	1.92	1.75	1.62	1.52	1.36	1.26	1.20
24	4.90	4.12	3.57	3.16	2.60	2.24	1.98	1.80	1.67	1.56	1.39	1.28	1.21
25	5.10	4.28	3.71	3.28	2.69	2.31	2.04	1.85	1.71	1.60	1.41	1.30	1.23
26	5.529	4.45	3.84	3.40	2.79	2.39	2.11	1.91	1.76	1.64	1.44	1.32	1.25
27	5.51	4.62	3.99	3.32	2.88	2.46	2.17	1.96	1.80	1.68	1.47	1.34	1.26
28	5.69	4.78	4.13	3.64	2.97	2.54	2.24	2.01	1.85	1.72	1.50	1.37	1.28
29	5.89	4.94	4.28	3.76	3.07	2.61	2.30	2.06	1.90	1.76	1.53	1.39	1.30
30	6.08	5.09	4.41	3.88	3.16	2.68	2.36	2.12	1.95	1.80	1.54	1.41	1.32
31	6.28	5.26	4.54	4.04	3.26	2.77	2.42	2.18	1.99	1.84	1.59	1.44	1.33
32	6.48	5.42	4.68	4.13	3.36	2.85	2.49	2.24	2.04	1.89	1.62	1.46	1.35
33	6.68	5.59	4.82	4.24	3.45	2.93	2.56	2.29	2.09	1.93	1.65	1.48	1.37
34	6.88	5.75	4.96	4.36	3.54	3.01	2.62	2.34	2.14	1.97	1.69	1.51	1.39
35	7.08	5.92	5.10	4.48	3.64	3.09	2.69	2.40	2.19	2.02	1.72	1.53	1.41
36	7.27	6.08	5.24	4.60	3.74	3.16	2.76	2.46	2.24	2.08	1.75	1.56	1.44
37	7.63	6.28	5.38	4.73	3.85	3.24	2.83	2.52	2.26	2.10	1.79	1.59	1.46
38	7.66	6.40	5.52	4.86	3.93	3.32	2.89	2.58	2.34	2.15	1.82	1.61	1.48
39	7.87	6.59	5.66	4.98	4.03	3.40	2.96	2.64	2.39	2.19	1.85	1.64	1.50
40	8.07	6.74	5.91	5.10	4.12	3.49	3.28	2.69	2.44	2.24	1.89	1.67	1.52

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation

Table 5-21 Allowable Guy Tensions

Material	Guy Wire		Ultimate strength, lb	Loading, lb			
	Reference	Strand		Dead end and angle		Transverse	
				Grade C, SF=1.14	Grade B, SF=1.50	Grade C, SF=2.00	Grade B, SF=2.44
Copperweld	6M	3 #8	6,280	5,500	4,100	3141	2360
	11M	11/32"	11,280	9,860	7,520	5640	4240
	17M	7/16"	7,210	6,330	4,810	3605	2710
Aluminium weld	6M	3 #8	7,210	6,330	4,810	3605	2710
	11M	11/32"	12,960	11,370	8,640	6480	4870
	17M	7/16"	19,060	16,720	12,700	9530	7160

Dead end loadings or 60⁵ angles primary

Copper	Loading, lb	Aluminium	Loading, lb
No.6 bare	640	No.1/0 bare	1200
No.3 bare	1070	No.1/0 HDPE or PVC	1500
No.3 PVC	1230	No.3/0 bare	1450
No.1/0 bare	1550	No.3/0 HDPE or PVC	1800
No.1/0 HDPE or PVC	2000	336,400 cmil bare	2000
No.4/0 bare	1650	336,400 cmil HDPE or PVC	2000

Construction

Concrete Poles

Concrete poles are manufactured in several cross sectional shapes; round, square, and polygons (usually six or eight sides). Moreover, they may be solid or hollow. The method of pouring the hollow poles involves spinning the form while the concrete is being poured, and forcing it to the outside while leaving the centre hollow; the result is a highly uniform, compact, prestressed concrete of high strength and texture.

As concrete has a higher strength under compressive loads than under tensile loads, the overall strength of the concrete poles depends a great deal on the steel reinforcement. Its strength also depends considerably on the mixture of cement and how it is cured.

Where cross arms or other distribution devices and equipment are to be mounted directly on the pole, provision is made for the necessary bolt holes when the concrete is being poured.

Besides their appearance and greater strength, hollow poles provide a means for electrical risers to be installed inside the pole out of sight and not readily accessible to the public. Other advantages claimed include resistance to fire, birds, rot, and vandalism; also the elimination of harm and clothing damage to the public from contact with some wood preservatives. A variety of colours and finishes also is possible with concrete poles; these may contribute to their acceptance.

Section 2 – Overhead Lines and Installation

2.5 State pole and line installation techniques

11.3.2 Structure construction procedures

Each special structure and each special piece of equipment must have a particular established procedure that accounts for the capabilities of the equipment, and the requirements of the task at hand.

An $\%P + \dot{A}$ is the principal structure in rural areas for voltages between 115 kV and 50kV. We will use a 230kV “H” structure as an example. The procedure is as follows:

1. All pole framing material must be delivered in the ROW to exact, designated positions.
 2. All structures must be assembled or framed and placed so as to be set without moving the equipment.
 3. All holes are dug.
 4. The setting rig must come by, set the pole and hold it until the tamping or back fill crew can secure it.
-
1. Prepare foundation (types of foundations and methods will follow),
 2. Deliver material to site
 3. Assemble, and
 4. Erect.

11.6.1 Tension definition

The tensions shown in Table 11.1 should be approached as closely as the special conditions will allow in order to reduce the number of structures, but rarely exceeded. There are several conditions at which maximum conductor tension limits are specified.

The initial unloaded tension refers to the state of the conductor when it is initially strung and is under no ice or wind load. After a conductor has been subject to the assumed ice and wind loads, and /or long time creep (the inelastic elongation of a conductor that occurs with time under load), it receives a permanent or inelastic stretch. The tension of the conductor in this state, when it is again unloaded, is called the *final unloaded tension*.

The loaded tension refers to the state of a conductor when it is loaded to the assumed simultaneous ice and wind loading for the National Electrical Safety Code (NESC) loading district concerned.

The vertical load on a conductor is the weight of that span of wire with its ice loading. The horizontal load is the load due to the pressure of the wind. The total loading is the vector sum of both loads. The NESC requires that a constant be added to the vector sum to reach the standard loaded tension as follows;

Section 2 – Overhead Lines and Installation

	Heavy	Medium	Light
Newton/meters	4.4	2.9	0.73
Pounds/foot	0.3	0.20	0.05

Table 11-1

Wire and Temperature Limits for ACSR & 6201 AAAC

A. Temperatures

1. Tension limits 1, 2, and 3 below must be met at the following temperatures:

Heavy loading district	$17.8^{\circ}C$	$(0^{\circ}F)$
Medium loading district	$9.4^{\circ}C$	$(15^{\circ}F)$
Light loading	$1.1^{\circ}C$	$(30^{\circ}F)$

2. Limit 4 must be met at the temperature at which the extreme wind is expected.

3. Limit 5 must be met at $0^{\circ}C$ ($32^{\circ}F$)

B. Tension Limits in Percent of Conductor Rated Strength

Tension Condition (See text for exp.)	Phase Cond.	OHWG High	High
		Strength Steel	Strength Steel
1. Max. initial unloaded	33.30*	25	20
2. Max. final unloaded	25.00x	25	20
3. Standard loaded (usually NESC district loading)	50.00	50	50
4. Max. extreme wind (A)	70.00°	80	80
5. Max. extreme ice (A)	70.00	80	80

NOTE: (A) These limits are for tension only. When conductor stringing sags are to be determined, limits 1, 2, and 3 should be considered as long as tensions at conditions 4 and 5 are satisfactory.

NOTE: Tension limits do not apply for self damping and other special conductors

* In areas prone to vibration, a value of approximately 20 percent of the average annual maximum temperature is recommended if vibration dampers or other means of controlling vibration are not used.

x For 6201 AAC, a value of 20 percent is recommended.

° For ACSR only, 6201 aluminium use 60 percent.

Line Planning

The steps for planning the construction of a transmission line are discussed in the following section.

Section 2 – Overhead Lines and Installation

11.10.1 Plan-profile Drawings

Plan-profile drawings that show a topographical contour map of the terrain along and near the ROW, and a side view profile of the line, showing elevation and towers. Figure 11.6 shows a section of a plan-profile drawing.

The transmission line plan-profile drawings serve as a worksheet, and eventually an expository sheet, which shows what is to be done and the problems involved. Initially, the drawings are prepared based on a route survey showing land ownership, the locations and elevations of all natural and man made features to be crossed or that are adjacent to the proposed line (all affect ROW), line design, and construction. The drawings are then used to complete line design work such as structure spotting. During material procurement and construction, the drawings are used to control purchase of materials and serve as construction specification drawings. After construction, the final plan-profile drawings become the permanent record of property and ROW data, which is useful in line operation and maintenance, and in planning future modifications.

Beginning with the initial preparation, accuracy, clarity, and completeness of the drawings should be maintained to ensure economical design and correct construction. All revisions made subsequent to initial preparation and transmittal of the drawings should be noted in the revision block by date and with a brief description of the revision.

Drawing preparation begins with an aerial survey followed by a ground check. The proper translation of these data to the plan-profile drawings is critical. Errors that occur during this initial stage affect line design because a graphical method is used to locate the structures and conductor. The final field check of the structure site should reveal any error. Normally, plan-profile sheets are prepared using a scale of 200 feet to the inch horizontally and 20 feet to the inch vertically. On this scale, each sheet of plan-profile can conveniently accommodate about 1 mile of line with enough overlap to connect the end span on adjacent sheets.

The sample format for a plan-profile drawing is shown by Figure 11.6 with units and stations in customary United States units. Increase in station and structure numbering usually proceeds from left to right with the profile and corresponding plan view on the same sheet.

Existing features to be crossed by the transmission line, including the height and position of power and communication line, including the height and position of power and communication lines, should be shown and noted by station and description in both the plan and profile views. The magnitude and direction of all deflection angles in the line should be given and referenced by P.I. station in plan and elevation.

Section 2 – Overhead Lines and Installation




FIGURE 11.6 Plan profile drawing (a) Profile with towers spotted and (b) Contour




FIGURE 11.8 Sag low point, vertical spans, and uplift

Section 2 – Overhead Lines and Installation

A rapid method to determine uplift is shown by Figure 11.8. There is no danger of uplift if the cold curve passes below the point of conductor support on a given structure with the curve on the point of conductor support at the two adjacent structures.

Designing for uplift or minimising its effects is similar to the corrective measures listed for excessive insulator swing, except that adding excessive weights should be avoided. Double dead-ends and certain angle structures can have uplift as long as the total force of uplift does not approach the structure weight. If it does, hold-down guys are necessary. Care should be exercised to avoid locating structures resulting in poor line grading.

11.10.7 Final Drawings

The conductor and ground wire sizes, design tensions, ruling span, and the design loading condition should be shown on the first sheet of the plan-profile drawings. A copy of the sag template should be shown. The actual ruling spans between dead ends should be calculated and noted on the sheets.

As conductor sags and structures are spotted on each profile sheet, the structure locations are marked on the plan view and examined to ensure that the locations are satisfactory and do not conflict with existing features or obstructions. To facilitate preparation of a structure list and the tabulation of the number of construction units, the following items, where required, should be indicated at each structure station in the profile view:

1. Structure type designation
2. Pole height and class or height of tower
3. Pole top, cross arm, or brace assemblies



Section 2 – Overhead Lines and Installation




FIGURE 11.13 Views of a tensioner for bundle of two stringing





Figure 11.14 Two views of a three drum wire puller for tension wire stringing

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation






FIGURE 11.17 Conductor clipping with a high-reach

Section 2 – Overhead Lines and Installation




ITEM NO.	MATERIAL	ITEM NO.	MATERIAL
A	3 INSULATOR, PIN TYPE	CU	2 BRACE, WOOD, 2x
B	1 PIN, POLE TOP, 20'	J	2 BOLT, CARRIAGE, 3/4" x 4 1/2"
C	3 BOLT, MACHINE, 3/8" x REQ'D LENGTH	J	1 SCREW, LAG, 1/2" x 4" (C1 ONLY)
D	5 WASHER, 2 1/4" x 2 1/4" x 3/16", 3/16" HOLE	BS	1 BOLT, SINGLE UPSET, (C1 ONLY)
F	2 PIN, CROSSARM, STEEL, 3/8" x 10 1/4"	EC	1 BRACKET, OFFSET NEUTRAL (C1A ONLY)
G	1 CROSSARM, 3 1/2" x 4 3/8" x 8'-0"	J	3 SCREW, LAG, 1/2" x 4" (C1A ONLY)
EK	LOCKNUTS, AS REQUIRED	12.5/7.2 kV	
CM	1 SPOOL INSULATOR	3-PHASE CROSSARM CONSTRUCTION SINGLE PRIMARY SUPPORT	
DESIGN LIMITS			
MAX. TRANSVERSE LOAD: 500 LBS. PER CONDUCTOR		C1, C1A	



Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation





Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation







Figure 21

Low voltage supported shackle construction

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation






Figure 23

Strain construction for medium voltage lines such as terminations or where the line deviation is between 30° and 90° .


Section 2 – Overhead Lines and Installation





Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation




Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation

2.6 Recall regulations pertaining to overhead lines

Notes and comments on some of the overhead line construction and maintenance regulations


Regulation 12 - Protection against corrosion

All iron and steel fittings must be protected by galvanising or other suitable means. It is necessary to have a minimum deposit of 460 grams of zinc per square metre and hot dip galvanising should be called in for in any specification for line fittings.

Regulation 13 – Insulators

These must be of adequate strength. Pin insulators must not be used for strain or termination construction.

Where the direction of an overhead conductor is changed there is a resultant load acting on the insulators in addition to the possible wind loading.



When a pin insulator is used, a bending moment is placed on the pin and this must be limited so that the pin is not excessively stressed.

As explained in Unit 1, pin insulators are designed for a failing load of 7kN or 11kN with a maximum working load of 40 per cent of the ultimate strength.

Section 2 – Overhead Lines and Installation

The permissible line deviation for pin type insulators is calculated as follows:

$$\begin{aligned} \text{Let } w_3 &= \text{wind load on the conductor in newtons per metre} \\ 3 &= \text{span length in metres} \\ &= \text{maximum tension in the conductor in newtons} \\ &= \text{angle of line deviation} \end{aligned}$$

The resultant force on the pin

$$= 2 \sin \frac{\theta}{2} w_3 3 \cos \frac{\theta}{2}$$

For small angles such as associated with pin insulators $\cos \frac{\theta}{2}$ can be taken as unity and the expression reduces to:

$$\text{Force on pin} = 2 \sin \frac{\theta}{2} w_3 3$$

Example

Determine the maximum deviation allowed on an 11 kN pin insulator for a 7/3.50 hard drawn copper conductor with a span of 150 metres. The ultimate strength of the conductor is 26600 N, the wind load is to be taken as 500 Pa and the diameter of the conductor is 10.5 mm. The tension in the conductor must not be more than 50 per cent of the ultimate strength. The transverse loading on the pin insulator is not to exceed 40 per cent of the ultimate strength.

$$\text{Wind load} = 500 \cdot 10.5 \cdot 10^{-3} = 5.25 \text{ N/m}$$

$$\text{Pin load} = 2 \sin \frac{\theta}{2} w_1 3$$

$$\frac{40}{100} \cdot 11000 = 2 \frac{26600}{2} \sin \frac{\theta}{2} + 5.25 \cdot 150$$

$$\sin \frac{\theta}{2} = \frac{3612.5}{26600}$$

$$= 0.1358$$

$$\frac{\theta}{2} = 7.8^\circ$$

$$\text{Maximum angle of deviation} = 15.6^\circ$$

To standardise line construction many supply authorities specify a limiting line deviation such as 10° for pin type insulators. For line deviations in excess of this, strain construction must be used.

As a comparison, the SAA Wiring Rules (Regulation 3.13.4.4) limits the change of direction of overhead lines to 30° where pin type insulators are used. However, these lines are limited to 60 metres span without approval of the supply authority.

Regulation 14 – Loading Conditions

Section 2 – Overhead Lines and Installation

The values stated should be learnt. The value of 500 pascals has been found by experience to be satisfactory.

Regulation 15 – Aerial Conductors

All conductors must be stranded and all normally available materials are allowed.

The minimum ground clearances must be maintained under conditions of increased sag because of the heating effect of the current.

Regulation 16 – Conductor Sags and Tensions

The conditions specified in this regulation must be known.

Regulation 17 – Foundation for Supports

The foundations for supports for aerial conductors must be capable of bearing any load to which they are likely to be subjected.

The use of pole stays involves vertical component which increases the vertical load on the pole. Suitable pole footings were dealt with previously.

Staying of poles is usually necessary on high voltage lines at terminations and all intermediate poles where there is a large deviation in the line. Similar staying may also be needed for poles with lines up to 650 volts if the soil is of poor bearing quality.

The essential components for the staying of a pole are:

1. Galvanised stay wire of suitable strength.
2. Strain insulator to insulate the strain wire within eight feet of the ground.
3. Wire rope grips for strain wire, or preset fittings.
4. Stay anchorage.
5. Batten

Figure 13 illustrates the overall constructional features of a ground stay. The various stay anchorages are shown in Figure 14. A typical stay rod is shown in Figure 15. Wire clips and the method of fixing these are shown in Figure 16.

Regulation 18 – Supports

The percentage of the ultimate strengths of various parts of overhead lines are stated in this regulation. The values are 50% for steel, 25% for wood, 40% for stay wires and insulators.


For insulators, the term, electro-mechanical strength, is used. This is the maximum tension which can be applied without causing the insulator to puncture and fracture when a voltage of 75 per cent of the dry flashover voltage is simultaneously applied to the insulator.

Regulation 19 – Earthing and Insulating of Metalwork


Effectively earthed means that such earthing prevents the potential of exposed metalwork within 2.4 metres of the ground from exceeding a sustained voltage of 32 volts a.c.

Further notes on earthing will be given in a unit devoted to earthing.


Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Regulation 20 – Prevention of Unauthorised Climbing

Apart from the methods listed in this regulation, anti climbing guards may need to be fitted in areas frequented by children, and the attachment of danger notices may be desirable.

Regulations 21 – 26 – Overhead Service Lines

These cover specific applications to service lines, and examples of these regulations are illustrated in Figures 17 and 18.

Regulation 28 – Size of Conductors

Section 2 – Overhead Lines and Installation

For conductors required to operate up to 650 volts the minimum standard size would be 7/1.25 for copper, and 7/1.75 for all aluminium and aluminium alloy.

For conductors operating above 650 volts the minimum standard size conductors are 7/1.75 for copper 7/2.25 for aluminium alloy and 7/2.50 for all aluminium.

Regulations 29 and 30 – Clearance of Conductors from Ground and Structures

The clearances stated must be known.

Regulations 31 and 32 – Vertical Spacing of Different Circuits on the Same and Separate Poles

These regulations do not need further explanation; the limit for distribution is 33kV.

Regulation 33 – Separation of Conductors

Many formulae have been in use for calculating the separation required between conductors to comply with such a regulation as this. The Energy Authority of New South Wales has developed a formula and it is recommended that this should be used on all overhead line construction.

The conductors of the same or different circuits attached to a fixed support should have a minimum equivalent horizontal separation from each other at any point of the span which should not be less than the largest of either A, B, C or D for the situation concerned.

- A. For conductors of the same circuit or different circuits attached to a fixed support, the equivalent horizontal separation 'S' according to the sag at any point of the span shall be calculated as follows;

$$S = 0.0076 \frac{0.3\sqrt{D}}{2.13} \frac{0.083\sqrt{D}}{0.083\sqrt{D}} \frac{(d)^2}{(w_r)}$$

S = equivalent horizontal spacing in metres

D = Sag (metres) at 50⁵C and no wind

D = overall diameter of conductor in millimetres

^wr = resultant load (N/m) due to gravitational force on Conductors and 500 Pa horizontal wind load on the Conductor.

The Energy Authority publishes a monograph to solve this formula and reference should be made to their design manual.

Section 2 – Overhead Lines and Installation

- B. The minimum separation between conductors of the same circuit should be 0.38 m up to and including 11kV plus 10 mm per kV in excess of 11 kV.
- C. The minimum separation between conductors of different circuits should not be less than 0.6 m up to and including 650 volts, and 1.2 m up to and including 33 kV.
- D. Where suspension insulators are used, and are not restrained from movement, the separation required by A, B and C should be maintained with an insulator swing of 45 degrees from the vertical position of one string only.

While the above design factors are important in the calculation of conductor spacing, Supply Authorities usually prepare standard drawings based on the above for distribution work, to enable lines to be erected and comply with this regulation.

The spacing of the conductors determines the design of the cross arms. Common practice for distribution work is to have 450 mm clearance between the insulators on the cross arm for medium voltage and 600mm clearance at the insulators on the cross arm for 11 kV.

The SAA Wiring Rules gives the following values for medium voltage:

Span	Spacing
Not exceeding 9m	0.2m
Not exceeding 60m	0.45m

It was indicated in the summary of Regulation 13 – Insulators, that angle construction for pin insulators should be limited to an angle of the order of 10 degrees. When angles exceed 10 degrees, strain insulators should be used.

When the line deviation exceeds 30 degrees it is advisable to use twin cross arm construction with shackle insulators so that each cross arm is at right angles to the direction of the line.


If two separate cross arms are not used the spacing of the conductors may not be great enough along the span unless the insulator spacing at the cross arm is increased. This would call for non standard cross arms and so it is usually economical to use twin cross arms

Regulation 35 – Automatic Interruption to Supply in the Event of a Fault Condition.


This regulation applies specifically to overhead lines of voltages in excess of 650 volts. The automatic device should operate within two seconds for fault currents equivalent to the maximum prospective values.

While the regulation excludes conductors operating at less than 650 volts, it is preferable where problems of discrimination do not occur that these conductors should be similarly protected.

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation

2.7 Measure ground levels, deviation angles and compass bearings


Basic Survey Methods

In order to fully understand the above techniques, an appreciation of the methods of obtaining the required information is necessary. By ignoring instruments and equipment, the techniques can be broken down into *four basic methods* of collecting information. Each method relies on the simple principle that if *two* points are established, a *third* point can be located in relation to them by various forms of measurement.

- a) **Linear measurement** – measurement having only one dimension, i.e. length. Such a measurement in a straight line would give the shortest distance between any two points. When two linear measurements are multiplied together, square measure or area results (see Chapters 2 and 3).
- b) **Angular measurement** – the measurement of the angle formed when two straight lines (or directions) meet (see Chapter 6). Although an angle possesses magnitude (i.e. size), it cannot be estimated as a length, breadth, or area; therefore special units are used, i.e. degrees and radians.

In order to discuss the methods in detail, it is necessary to state the following:

- i. *The situation* In Fig. 1.3, the line AB represents a straight wall, while C is a point (say a vertical metal post) some distance way.
- ii. *The requirement* To produce a two dimensional plan, drawn to some suitable scale, showing the post in true relationship to the wall. (Note: Drawing out the measured information is known as plotting the survey.)
- iii. *The problem* How can the post be located by measurement in relation to the wall in order that the requirement may be fulfilled?




Section 2 – Overhead Lines and Installation

1.4.1 Method 1 – intersecting arcs


- i) *On site* Measure the horizontal distances AB, AC, and BC and note down the information on the sketch (Fig. 1.4(a)).
- ii) *In the office* Draw line AB to scale. Using compasses, swing an arc from A with the radius set to the scale length of AC. Similarly, swing an arc from B with the radius set to the scale length of BC. The intersection of these arcs will locate point C (Fig. 1.4(b)).

This method is the basis of *chain-survey technique* and may be used for land survey, building plans, etc. as will be discussed in Chapters 2, 3, and 7.




Method 3 – Polar Co-ordinates/radiation

- i. *On site* Measure the horizontal angle BAC the length AB and the horizontal distance from point A to point C. Note down this information on the sketch (Fig.1.6(a)).
- ii. *In the office* Draw line AB to scale. Use a protractor or an adjustable set square to set off the angle BAC. From A, scale off the distance measured to locate point C.



5 Polar co-ordinates

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation





Fig. 1.9 Ordinary levelling. The difference in height (x) between the level surface and the horizontal line can be calculated and the vertical distance (y) from horizontal line to point C can be measured. The height (z) of point C above AB is given by $(x - y) = z$.



Site Surveying and levelling

- a) The use of maps will vary with the scale and the following text gives a brief account of each of the four maps mentioned above, along with an indication of some possible uses.
 - i. 1:25 000 is a relatively small scale map and the smallest scale at which field boundaries are shown. Contour lines are drawn at 10m V, I,
 - ii. Maps at this scale would be used

When planning large scale engineering works involving gradients of roads, sewers and pipes;

Extensively when involved with the flow of rivers and streams (flooding abatement, irrigation, reservoirs);

Where the contour lines provide a means of solving problems indivisibility and clearance between points;

Section 2 – Overhead Lines and Installation

To illustrate aspects of regional planning because the small set enables an 'overview' to be given.

- iii. 1:10 000 is almost accurately drawn to scale although some times widths are increased to accommodate road names. Conventions (signs and symbols) are used to represent features in a semi pictorial manner, e.g. orchard, quarry, cutting, embankment, etc, whilst individual parcels of land are shown, together with fences and fields. Contour lines are drawn at 5m V.I., although this is increased 10m V.I. in mountainous areas.

Maps at this scale would be used

By the surveyor involved in estate management because individual tenant holdings can readily be distinguished;

For design of schemes for water supply;

For geological surveys;

By town planners and urban designers to illustrate initial proposals.

- iv. 1:2500 is a highly detailed map providing accurate information to a fairly large scale. A distinctive feature of the map is that each parcel of land is identified by a number and has its area printed below (hectares and acres) which makes the map extremely useful for rating and valuation purposes as well as location plans for local Authority submissions.

- v. 1:1250 is the result of a double enlargement of the 1:2500 sheet which renders it no more accurate than the smaller map. It is the largest scale of mapping published by the O.S., although in the 19th century and early 20th century 1:500 scale maps were produced and are still to be found in many offices. At 1:1250 scale all streets are named, as are public and other buildings having a specific name. Remaining buildings are numbered.


Maps at this scale are used.

In part, as block plans or location plans when making applications for planning and building regulation approval;

By designers for initial layouts;

By statutory undertakings to record the positions of power lines.

Section 2 – Overhead Lines and Installation



Chain lines: AB, BC, CD, DA, DB, and AC

2.1.2 Survey Stations



A survey station is a point of importance at the beginning or end of a chain line, or at the junction of one line with another. It is usually marked by the insertion into the ground of a vertical ranging pole. On hard surfaces this point may be marked by a stud, while on normal ground where a more permanent mark is required, a wooden peg (50 mm square) should be driven in, which can be easily located at all times. It is not a bad idea to make a dimensioned sketch of the position of the pegs so that these may be relocated if a peg is lost or accidentally removed. For station points on hard ground which are not to be of a permanent nature, a stand should be used to support the rod vertically.

Stations should be placed as may be found convenient at the corner of areas or at prominent points, so that the lines joining them are as close as possible to the boundaries of the site in order to keep offset measurements short (See Section 2.1.7)

2.1.3 The Base Line

This is normally the longest of the chain lines forming the *pattern of triangles*, and should, if possible, be laid off on level ground through the centre of the site and encompass the whole length of the area. A compass bearing should be taken to fix its direction, which in turn will fix the direction of all other lines and allow the position of north to be determined. All survey drawings require a drawn north point.


Section 2 – Overhead Lines and Installation



2.3.6 Tapes

A tape is used for taking subsidiary measurements in the field. It is suitable for taking offsets, which are measurements taken from, and at right angles to, the chain line, or to fix adjacent points as on a boundary.

Section 2 – Overhead Lines and Installation



2.4.4 Laying-down the Chain

The leader, equipped with his ten arrows, drags the chain until he is brought up by a gradual pull and directed into line by the follower. Once alignment is effected, an arrow is inserted which marks the measurement of one chain length. Care must be taken to ensure that arrows are inserted *vertically* and on the side of the *vertical handle*, so that no error equal to the thickness of an arrow or the thickness of the handle is .


- b) **On hilly ground** Very often, due to undulations of some size, the last station point cannot be seen from the first, yet intermediate poles must be positioned for lining in the chainmen. The difficulty may be resolved by tying two poles together, although this is not very accurate or satisfactory. Two other methods may be adopted, as follows.

Section 2 – Overhead Lines and Installation

- i. In Fig. 2.8, A and B are the two stations seen in plan, with the hill between them (as shown by the section). Two assistants with poles take up positions, one each side of the hill, at C_1 and D_1 and facing each other so that the observer at C_1 can see the pole at station A and the observer at D_1 can see the pole at station B. By successfully directing each other into line, their positions will be altered until finally the finish at C and D exactly on the line AB and then the poles are inserted.
- ii. In Fig.2.9. A and B are again the two stations with the hill intervening so that A cannot be seen from B and vice versa. A trial line (known as a random line) is set out from A with poles erected at C_1 , D_1 , etc. and will end at B_1 (unless by the greatest of good fortune the line ends on B, where there would be no problem), There is therefore an error at the end of the line amounting to BB_1 , which measured, AC_1 AD_1 and AB_1 , are also measured. By application of the principle of similar triangles, it is found that triangle ADD_1 is similar to triangle ABB_1

$$\frac{DD_1}{AD_1} = \frac{BB_1}{AB_1} \text{ or } DD_1 = BB_1 \frac{AD_1}{AB_1}$$

Similarly the shift for any other pole is calculated.



Section 2 – Overhead Lines and Installation





Fig. 2.9 Ranging out over a hill – method 2

$$DD_1 = \frac{10 \text{ m} \times 300 \text{ m}}{400 \text{ m}} = 7.500 \text{ m}$$

Section 2 – Overhead Lines and Installation

2.8 Perform basic survey of short distribution line extension to produce field notes



Section 2 – Overhead Lines and Installation






Fig. 2.14 Types of cross-staff. The one shown at (a) will also set out 45° angles.

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation

By Cross Staff Unlike the optical square or the prism, the right angle is set out by direct observation of all poles. The cross staff is placed on a tripod with a special receiving head, and the slots are made vertical. By use of a plumb line, the cross staff can be placed over the exact spot C in the chain line (Fig. 2.17) Poles P_1 and P_3 are observed through the slots as a test that the staff is on the chain line. When the surveyor is satisfied that the cross staff is in line, he then observes through the slots at 90 degrees to the line and when he can see pole P_2 through the appropriate slot this signifies that P_2C is perpendicular to the chain line.




Fig. 2.18 Testing the optical square

2.6.2 Measuring slope angle


a) **By clinometer** To measure the ground slope of a line AB , the surveyor stands at point A holding the Watkin's clinometer to his eye. The assistant stands at B with a pole having a clear marking which is the same height above the ground level at B as that of the surveyor's eye level at A . This mark is observed through the instrument and, if it is *higher* than the surveyor's eye level at A , the instrument will be tilted upwards (elevated). Since the scale is

2.7 Measure ground level, deviation angles and compass bearing

Linear measurement



Measurement having only one dimension

Section 2 – Overhead Lines and Installation



Angular measurement

The measurement of the angles formed when two straight lines meet.



Site surveying and levelling

Scale of map

1:25000---- Small scale map.

Planning large scale engineering works involving gradient of roads, sewers , pipes

Involve with the flow of rivers, street

When contour lines provide a means of solving problems intervisibility and clearance between points

To illustrate aspects of regional planning

Section 2 – Overhead Lines and Installation

1:10000---Almost accurate drawn to scale. To accommodate road names.

Estate management, design of schemes for water supply
Geological surveying
Town planning

1:2500-----Highly detailed map providing accurate information to fairly large scale

1:1250----- Double management of 1:2500

All streets are named
Block plan , location plan when marking application for planning and building regulation approval
By designers for initial layout.
By statutory undertakings to record the positions of power lines.

Survey stations

A survey station is a point of importance at the beginning (or) end of a chain (or) at the junction of one line with another.

It is usually marked by an insertion into the ground of a vertical ranging pole. On the surface , this point may be marked by a stud. Stations should be placed as may be found convenient at the corner of area (or) at prominent points so that the lines joining them are as close as possible.

The base line

This is normally the longest of the chain line forming the pattern of triangle. It should , if possible be laid off on level ground through the center of the site and encompass the whole length of the area. A compass bearing should be taken to fix its direction which in turn will fix the direction of all other lines and allow the position of north to be determined. All survey drawings require a drawn north point.

Survey equipments

Chain

Typical chain pattern The tags shown are for 20 m chain and may be of brass or plastics. Plastics tag may be attached at each whole metre positions with a different colour used at each 5 m position. This is usual for chains longer than 20 m.


Tapes

Section 2 – Overhead Lines and Installation

A tape is used for taking subsidiary measurements in the field. It is suitable for taking off sets which are measurements taken from and at right angles to the chain line or to fix adjacent points as on a boundary.

Laying down the chain

The leader equipped with his ten arrow drags the chain until he is brought up by a gradual pull and directed into line by the followers. Once alignment effected, an arrow is inserted which marks the measurement of one length, care must be taken to ensure that arrows are inserted vertically and the side of vertical handle so that no error equally to the thickness of arrow or the thickness of the handle is in trouble.



On hilly ground

Very often, due to undulations of some size, the last station point can not be seen, the first, yet intermediate poles must be positioned for lining in the chain man.

Section 2 – Overhead Lines and Installation

The difficulty may be resolved by tying two poles together although this is not very accurate or satisfactory, two other methods may be adopted as follows.

Prism in Theodolite

To see pole

Clinometer

To measure height

Required drawing equipments


Long steel straight edge parallel ruler, protractor 360 degree. French curve, Offset scale

2.8 Perform basic survey of short distribution line , extension to produce field notes

Surveying software

Read the article

“ Re- engineering the Transmission Line Design Design Process in 2.8 Perform basic survey of short distribution line extension to produce field notes handout.



2.8 Site Surveying

Surveying Meanings

Level Datum—It is the level line or surface that has been given to a value to which the heights of points above or below can be referred.

Section 2 – Overhead Lines and Installation

Reduced Level (RL)—It is a value given to a point or surface that represents its height above or below , an assumed level datum.

Bench Mark- Bench Marks are the points that have a reduced level value.

Back Sight--- Back sight is the first reading taken from any instrument set up. It is always taken to a point which has a known RL

Fore Sight – It is the last reading taken from an instrument set up . It is taken to a point where RL is known or where RL is required for further levelling.


Intermediate Sight—It is any other reading taken from an instrument set up.

Change Point—It is a point where RL may not be required but is used in series levelling so that the levelling process can be proceeded.


Inverted Level-- It refers to the bottom inside RL of a pipe

Temporary Bench Mark (TBM)—It is a location normally transferred from a bench mark as a convenient location for other heights to be noted or positioned. For example, they may be positioned close to a building being erected.

Section 2 – Overhead Lines and Installation



Section 2 – Overhead Lines and Installation



Determination of height difference between two points

Reading		Difference Height
Station 1	Station 2	
0.812	1.013	0.201
0.566	0.764	0.198
	ADD The Difference	0.399
	Average--- / 2	0.195

Rise and fall calculation

FALL


Second point value is bigger than first point----- FALL

RISE

Second point value is smaller than first point-----RISE

Section 2 – Overhead Lines and Installation

Calculation of reduced level from known point by field surveying



Section 2 – Overhead Lines and Installation

Back sight	Intermediate	Fore Sight	Rise	Fall	RL	Prism
(1) 1.325					100	A
	(1.a) 2.55			1.225	98.775	B
	(1.b) 3.125			0.575	98.2	C
	Difference			-		
(3) 0.9		(2) 4.75		1.625	96.575	D
		Difference				
	(3.a) 1.875			0.975	95.6	E
	Difference					
(5) 3.375		(4) 0.25	1.625		97.225	F
		Difference	+			
		(6) 0.595		2.78	100.005	Closed A
		Difference				
ADD ALL 5.6		ADD ALL 5.595	ADD ALL 4.405	ADD ALL 4.4		

Rules

1. Data Entry Table

Back sight	Intermediate	Fore Sight	Rise	Fall	RL	Prism
(1) 1.325					100	A

2. Flow Direction of Data Entry

3.

Back Sight

Intermediate

Ever start

4.

I

↓

I

Section 2 – Overhead Lines and Installation

5.

Back Sight ←————— Fore Sight

6.

If Second point > First Point----- FALL

If Second point < First Point-----RISE

7.

BS
↘
FS

8. Calculation of reduced level

First RL \pm Fall = Second RL

First RL + Rise = Second Level

9. To Adjust

ADD----- ALL -----FS -----BS
↓
RISE
↓
FALL

Re-Engineering the Transmission Line Design Process

Otto J. Lynch, P.E.

Black & Veatch.

8400 Ward Parkway, Kansas City, MO 64114

(913) 339-7549 (913) 339-2888 Fax lynchoj@bv.com

Peter Hilger, E.I.T.

The Empire District Electric Company

P.O. Box 127, Joplin, MO 64802

(417) 625-5100 (417) 625-5165 Fax

Section 2 – Overhead Lines and Installation

INTRODUCTION

Traditionally, transmission line design practices have been comprised of conservative assumptions which easily model an elaborate and complex structural system. Continued developments in computers and software have given us the capability of breaking these normally inflexible traditions, and have allowed the industry the opportunity to re-engineer the entire transmission line design process. Finally, the seamless integration of all aspects associated with transmission line surveying, engineering, drafting, procurement, and construction is essential to maximize the full benefits of the re-engineering effort.

Black & Veatch (B&V) is an engineer/constructor headquartered in Kansas City, Missouri. The firm has provided engineering, construction, and related services for electric power transmission and distribution throughout its 80-year history. The firm's Transmission & Distribution Division forms one of the largest T&D staffs among engineering and construction firms in the United States. By utilizing state-of-the-art resources and techniques, B&V continually strives to improve the transmission line engineering, procurement, and construction (EPC) process to produce better designs in the fastest, most economical manner.

The Empire District Electric Company (E.D.E.) is an independent, investor owned, electric utility providing quality electric service in the four-state area of Kansas, Oklahoma, Arkansas, and Missouri. E.D.E. is dedicated to providing its customers with the highest reliability possible, while maintaining its low rates.

B&V and E.D.E. have selected the PLS-CADD software suite developed by Power Line Systems, Inc., Madison, Wisconsin, to support their needs for a "better, faster, cheaper" transmission line design environment. The line design software selected has the capability of meeting all the objectives required for the full integration of the transmission line design and drafting environment.

SURVEYING

Recent developments in surveying technologies have allowed the industry to re-think the station-elevation-offset formats that designers have traditionally used for transmission line profile modeling. Today's generally accepted method of surveying is some form of three-dimensional geographical information system (GIS) type representation. Data are usually collected in electronic format, and the transmission line software must be capable of reading the data intelligently in any form. Total Station, Geographical Positioning System (GPS), Photogrammetry, electronic topographical maps (USGS), and scanned or digitized existing profile drawings have all been employed to develop quick and relatively accurate terrain models for transmission lines.

B&V and E.D.E. utilize a state-of-the-art technology, the FLI-MAP™ laser mapping system. FLI-MAP was developed by John E. Chance and Associates of Lafayette, Louisiana. This advanced technology system incorporates On-The-Fly (OTF) Kinematic GPS, GPS aided attitude, a reflectorless laser range finding sensor, and a helicopter to quickly gather topographical and other pertinent aboveground data. This method yields about 10 data points per square meter over a 65 meter wide corridor

Section 2 – Overhead Lines and Installation

under the flight path. This technology produces points with an accuracy better than 12 cm vertical and 15 cm horizontal of all points on and above the ground. Approximately 100 kilometers of continuous line can be surveyed in a day, and the data can be available in the desired coordinate system and elevation datum on the same day if dictated by the client. The information can then be directly imported into PLS-CADD in a matter of minutes. Transmission line design can commence immediately using extremely accurate profile, significantly more accurate than even a very dense, time and labor intensive ground survey can produce.

The design software selected has the capability of taking any three-dimensional survey format and "cutting" the profiles. The centerline and up to 20 left and right profiles at any offsets can be generated and shown. This process is nearly instantaneous, so Points of Intersection (P.I.s) can be moved or added at any time, and the new stationing and profiles are updated immediately. This allows for the typical last minute reroutes to be made quickly and effortlessly without delays caused by having to wait for new profile surveying, stationing changes, and engineering modifications. Station equations (equalities) will be obsolete.

In addition, the software has the capability of creating interpolated points on these profiles by creating a triangular irregular network (TIN). This TIN can also be rendered to present a graphical three-dimensional representation of the transmission line, which can be used for permit and public hearing requirements or any other forum where graphical representations are required of the line (See Figure 1).




Figure 1 - Three-dimensional rendering of a double-circuit 500 kV transmission line.

Section 2 – Overhead Lines and Installation

ENGINEERING

A critical component in any re-engineering effort is the simplification and centralization of all activities. In the transmission line engineering arena, all parameters governing any part of the line design should be available in one common package. Engineers cannot and should not be expected to learn multitudes of software programs, keep current in each of their independent updates, and maintain support with each of the programs. In addition, any data transfers between such programs, whether manual or electronic, leave room for error. Finally, it is critical that the software be on a computer platform that is user friendly and commonly accepted across the engineering and business worlds. Managers, engineers, technicians, drafters, and secretaries should be able to use any form of the programs or their outputs using a common interface, without having to learn complex drafting programs or obsolete operating system languages.

Another area of the software used in the re-engineering process that should not be overlooked is that it be technically sound. Software that merely duplicates assumptions and errors of the past is only as good as those assumptions. In today's computer environment, these programs will allow an error or mistake to be made faster than ever before. It is imperative that all calculations be made using state-of-the-art technologies and methodologies, and to the highest level of accuracy that is reasonably achievable. These criteria should not be sacrificed in an effort to simplify or expedite the design process.

PLS-CADD allows the engineer to completely design and lay out a transmission line without having to use any other external software. Due to this integration, all design criteria which will be imposed on the transmission line system are developed in one place. Loads which will be used to develop a sag-tension analysis and check sag clearances, uplift considerations, blowout criteria, cable tension limits, insulator swing criteria, structure design, insulator design, guying design, and foundation design are developed in one place. Overload factors (OLFs) can be applied in the transverse, longitudinal, and vertical directions and on the wire tensions. The loads can be selected to be applied to any component of the transmission line system. This allows PLS-CADD to be adaptable to any code or manufacturer requirement where different OLFs are required for each component of the transmission line system.

Structure design and spotting are indicative of the re-engineering effort making tremendous strides. Traditionally, structures have been designed by developing allowable spans, wind and weight, under all the loading cases applicable to the structure. For example, due to terrain factors, a structure family may be designed for a vertical to horizontal span ratio (H/V) of 1.5. Using this criteria, an example tangent structure may have limitations of a maximum wind span of 300 meters and a maximum weight span of 450 meters, where the maximum wind span was probably dictated by an extreme wind condition and the maximum weight span was probably dictated by a heavy ice condition. When spotting this structure on a line, either by hand or by less sophisticated spotting software, the structure location is acceptable if the wind and weight spans are both below the allowable span limitations.

However, in the "real world", the wind and weight spans are rarely maximized simultaneously for any given structure on a line. While we may think that we are

Section 2 – Overhead Lines and Installation

maximizing the use of the structure by approaching 100% use of either the allowable wind or weight span, there is actually additional strength available due to the contra allowable span not being utilized to its capacity, thus creating an interaction between the allowable wind and weight spans. Coupling this interaction phenomenon on a loading case by loading case basis, it can be seen that traditional methods used to spot structures can be as much as 70% or more conservative in their application. The associated reduction in structure costs on a large transmission project can quickly translate into a substantial overall project cost reduction.

Weight spans are another area where traditional assumptions are invalid. It has long been standard practice that wind has no effect on computed weight spans. Sags are calculated with the wind loading, templates are developed with the corresponding sags, and these sags are then applied in the vertical plane. This is simply not the case in a three-dimensional environment. When wind is blowing on a span, the conductor assumes a swung-out catenary. In a level span, this swung-out catenary produces a wind and weight span equivalent to that in the vertical plane, so traditional assumptions are correct. In an inclined span, the weight span effect actually shifts and the traditional assumption is no longer valid (See Figure 2).




Figure 2 - A profile and associated three-dimensional view of a line illustrating weight span differences due to wind acting on the wire. All other constants remain the same.

The exact weight span in this swung out condition on an inclined span is difficult to determine by traditional methods of finding low points in elevation views, but computers and three-dimensional technology can easily make these determinations.

Section 2 – Overhead Lines and Installation

Using the traditional method, weight spans can be in significant error when considering any wind loaded condition (See Table 1).

The software allows the selection of either the traditional method or exact method for calculating effective weight spans when using the wind and weight span options. It is recommended that the traditional method only be used when comparing PLS-CADD to traditional calculations or on extremely flat terrain. The exact method provides for an accurate three-dimensional line design and should be used on new projects.

Section 2 – Overhead Lines and Installation

		Weight Span	Weight Span	Weight Span
Structure	Wind Span	w/o Wind	w/ Wind	Change
Number	(m)	(m)	(m)	(%)
31	184	146	102	-30%
32	230	287	349	22%
33	190	221	249	13%
34	165	183	199	9%
35	201	87	-19	-122%
36	232	190	159	-16%
37	180	190	196	3%
38	164	120	89	-26%
39	252	428	499	17%
40	242	112	64	-43%
41	78	99	123	24%
42	53	73	89	22%

Table 1 - Calculated weight spans from Figure 2. Traditional calculation of weight spans under wind conditions are in significant error and can lead to expensive field problems if not accounted for properly.

Another significant aspect of any transmission line design program is the ability to incorporate the structure analysis of any type of transmission line structure. Important to the re-engineering effort, these structural programs also must be able to accommodate seamless integration into the line design. The PLS software has the capability to perform a full linear and non-linear finite-element analysis of wood, steel, concrete, and lattice structures. In keeping with the previously described criteria that any process in the re-engineering effort be technically accurate, it is essential that the structural analysis be performed as not merely a simplified replication of traditional hand analysis methods, but one that is rigorous. Traditional analysis methods can yield inaccurate results, sometimes on the conservative side and sometimes not.

An example of a simplified and imprecise method is designing single pole structures by calculating and analyzing the groundline moment only. In actuality, the maximum stresses in the pole usually occur at a point somewhere above the groundline, which can be verified by simple statics and observations of actual structure failures subjected to extreme transverse loading. In addition, it is imperative that any guyed structures and extremely flexible structures be analyzed using a non-linear analysis platform. The PLS software meets all objectives required to fully analyze structures correctly.

The current re-engineering movement has made major strides in analyzing existing lines for upgrade capabilities or fiber optic replacements and additions. Traditionally,

Section 2 – Overhead Lines and Installation

these analysis are performed by examining the structures independently of their location in the transmission line. Loads that are created by the maximum span limitations are recalculated for the replacement conductors and static wires based on those maximum wind and weight span limitations. Structure modifications are then designed and made to every structure on the entire line regardless of its physical application. However, as described earlier, very rarely are structures placed where the maximum span limitations are simultaneously utilized. By expanding our parameters and factoring in the placement of the structures in the line, we begin to realize those modifications may not be required on every structure. The PLS software has the capability of placing actual structure designs in a line and analyzing them directly on a site-by-site basis. This capability allows a full analysis to be made on the transmission line, allowing modifications to be designed on a structure specific basis using the actual loads that are applied to that specific structure at that specific site (See Figure 3). Considering the gross conservativeness of maximum wind and weight span modeling, many lines analyzed using this method can actually meet significant upgrading requirements with little or no structure modifications being required.




Figure 3 - Finite element structural analysis on an in-line lattice structure using the actual loads imposed on the structure.

Optimization of transmission lines is key to any design re-engineering effort. It is a necessary component for any true line design program. In addition, with many constraints imposed by physical obstructions, land owner desires, and environmental controls, the optimization process must allow for user defined controls to be handled

Section 2 – Overhead Lines and Installation

easily. Even on lines where there are many constraints, finding the least expensive combination of structures is still paramount to the project. Constraints usually fall under four categories: prohibited, extra cost, required structure location, and required structures.

Prohibited zones are simply areas where it is physically not possible to put a structure such as driveways, roads, wetlands, and inaccessible areas. Extra cost zones are areas where structures may be placed, but at additional cost to standard construction practices. An ideal example of this situation is a river crossing, where structures in the water are possible but the construction of the water crossing foundations can be a significant factor. Using an optimization routine, it can be determined whether it will be less expensive to place tall river crossing structures on each bank, or to place several standard structures in the river itself. PLS-CADD is capable of finding the least-cost design when accounting for all constraints imposed on the transmission line.

DRAFTING

Transmission line drawings, while being somewhat complex, are very simple in that they are usually repetitious. There are several commercial programs available and many utilities and consultants have written in-house programs capable of incorporating all the various facets of the typical plan and profile (P&P) transmission line drawing. Plan views have P.I.s, structure locations, and often geographical maps. Profile views have terrain profiles, structure specific information such as type, height and stationing, span lengths, clearance requirements, and wire catenaries. In addition, maps are often incorporated into the plan view, which requires placing the proper terrain information on the drawings. In a true re-engineered environment, the drawing generation should be merely an extension of the engineering process, eliminating the need for tedious and time-consuming drawing generation.

The P&P drafting of the design software is exactly that - an extension of all surveying and engineering activities. Drawings are formatted to fit client standards only once and include:

- Drawing Size
- Scales
- Plan Size and Location
- Profile Size and Location
- Drawing Overlaps
- Structure Text Contents
- Other Standards

All subsequent drawings are automatically generated using these same standards. Geographical maps created in other formats can be imported and placed under the plan view, automatically being cut and placed within the plan view area (See Figure 4). Electronic USGS maps, economically available today for most parts of the US, also are being imported into PLS-CADD. Finally, these drawings can be plotted directly within the software package, eliminating the need for any other drafting program. As an option, drawings can be exported to other popular drafting programs for further customization and archiving in those formats.

Section 2 – Overhead Lines and Installation




Figure 4 - Plan & profile drawing created in PLS-CADD. All design information on the drawing was obtained internally from the engineering process. The geographical map was directly imported and automatically cut and placed in the correct position.

PROCUREMENT

With any large transmission line project, the procurement process can be a project within itself. As a step towards the re-engineering effort, many self-supporting programs and spreadsheets have been developed to tabulate, quantify, and correlate the numerous parts and assemblies that make up the transmission line. PLS-CADD has adapted this ability internally. Parts, assemblies, and even labor units from existing databases can be electronically imported into the software, where the standard structures are associated with the appropriate units. The parts, assemblies, and labor (if used) can then be totaled, creating the structure cost to be used in the optimization process. This approach eliminates the need for the long and tedious process of developing the actual structure cost to use in any optimization program.

Material also can be associated on a specific structure site basis, for construction items such as gates and culverts. A material list can be generated from the line at any time for any section. This is extremely beneficial from the standpoint of determining marshaling yard locations along the line. The material list can be electronically transferred to most spreadsheet and word processing software, eliminating the need for re-entering data and thus preventing the introduction of errors and mistakes. Like drafting, material list generation is an extension of the engineering process.

Section 2 – Overhead Lines and Installation

CONCLUSIONS

Today's fast moving and economy-driven business environment has dictated that companies, both private and public, cannot be competitive without closely examining traditional design practices and taking full advantage of the tools available to help them overcome limitations. They must make conscious efforts to make paradigm shifts and welcome new ideas, technologies, and practices. The computer is the major tool of the corporate world, and PLS-CADD is the tool that has allowed the transmission line industry to make a major move within the re-engineering effort.

REFERENCES

Reed, M. D., Lynch, O. J., ""Near Field" Airborne Remote Sensing Using A Laser Mapping System on Electric Transmission Line Corridor Surveys and Capacity Analyses", Presented at the Second International Airborne Remote Sensing Conference and Exhibition in San Francisco, California 24-27 June 1996.

This article was published in the Autumn 1996 issue of Power Technology International magazine

Section 2 – Overhead Lines and Installation

Review questions for Section 2

1 Name the factors that are used in the selection for overhead line conductors

2 Name **six** commonly used materials for overhead lines.

3 Name the **three** factors that determine conductor current rating.

4 What are the factors that determine the maximum conductor temperature?

5 Name the standard methods used for protecting the steel against corrosion when it is used as reinforcement or as a conductor.

Section 2 – Overhead Lines and Installation

- 6 Name the types of supports for conductors. Describe the one that is commonly used in distribution.

- 7 Describe how wood poles are being protected against weather and fungal attack

- 8 State the governing factors that determine the stability of a pole

- 9 Define pole rake

Section 2 – Overhead Lines and Installation

10 Draw simple sketches of the following pole footings and describe their usages.

Plain footing

Concrete slab footing


Concreted footing

Baulk footing

Section 2 – Overhead Lines and Installation

11 State the factors that determine the lift of poles

12 For the wood pole label shown, describe the meaning of each item.



Label

13 Describe how pole strength is classified.

Section 2 – Overhead Lines and Installation

14 A cross arm is listed as 2.7P/16/100x100. Describe the meaning of each term in the list

15 Describe the **three** common types of insulators used in distribution systems.

16 The designation of an insulator is ALP 33/920. Describe the meaning of each item.

17 For the designation of an insulator: EA/2D, describe the meaning of each item.

18 Sketch 'creepage' of an insulator.

Section 2 – Overhead Lines and Installation

19 Describe the use of 'arcing horns'

20 Briefly describe the **three** determining factors for the mechanical properties of overhead conductors.

21 Describe briefly the **two** methods used in sag measurement.

22 Sketch the following stay anchorages

Used in solid rock formation

Used in weak rock formation

Used in soil

Section 2 – Overhead Lines and Installation

23 Using the attached table, calculate the allowable sag for a 7/3.50 hard drawn copper overhead conductor with a span of 150 metres. The wind loading is 500 pascals and the maximum conductor tension is to be 50 percent of the ultimate tensile strength.

Stranding	Sectional Area mm ²	Overall diameter mm	Ultimate tensile strength N	Mass kg/m	Gravitational force (N/m)	Wind load at 500 Pa (N/m)	Resultant load at 500 Pa (N/m)	Resistance per Km at 20 ⁵ C (OHMS)
17/1.00	5.50	3.00	2310	0.049	0.483	1.500	1.576	3.25
7/1.25	8.59	3.75	3610	0.077	0.754	1.875	2.021	2.09
7/1.75	16.84	5.25	6890	0.151	1.480	2.625	3.013	1.06
7/2.00	21.99	6.00	9020	0.197	1.931	3.000	3.568	0.815
7/2.75	41.58	8.25	16700	0.375	3.675	4.125	5.525	0.433
7/3.50	67.35	10.50	26600	0.607	5.949	5.250	7.934	0.268
19/1.75	45.70	8.75	18300	0.413	4.047	4.375	5.960	0.395
19/2.00	59.69	10.00	23900	0.538	5.272	5.000	7.266	0.302
19/2.75	12.90	13.80	44500	1.020	9.996	6.900	12.146	0.160
19/3.00	134.30	15.00	52800	1.210	11.858	7.500	14.031	0.134

Table 1

Temperature coefficient of resistance = 0.00381 per ⁵C at 20⁵C

Section 3 – Underground Cables

3.1 Describe the construction features and insulation abbreviations of under ground cable

Cables

The majority of cables used for distribution work are impregnated paper insulated cables with a lead or lead alloy sheath. These cables up to 33kV are covered by the Australian Standard 1026. This standard also recognises aluminium sheathed cables and both aluminium and copper conductors for paper insulated cables.

The conductor

The conductor is made of either copper or aluminium

Table 5 presents the properties of these two types of conductor materials.

Properties	Units	Annealed Copper	99.5% Purity Aluminium $\frac{3}{4}$ H	99.5% Purity Aluminium T.O. as Extruded
Density	g/cm^3	8.89	2.703	2.700
Resistivity	m at $20^{\circ}C$	1.7241×10^{-8}	2.8264×10^{-8}	2.803×10^{-8}
Temp. Coefficient of Resistance	$per^{\circ}C$	0.00393	0.00403	0.00403
Melting Point	$^{\circ}C$	1083	658	658
Coefficient of Expansion	$per^{\circ}C \times 10^{-6}$	17	23.8	23.8
Ultimate Tensile Strength	MPa	241	124	83

$\frac{3}{4}$ H – $\frac{3}{4}$ Hard

T.O. – SAA code symbol

Table 5

An analysis of these properties discloses that:

- 1 The electrical resistivity of aluminium is 164% of copper;
- 2 Although aluminium is only 30% of the density of copper it has 62% of its conductivity;
- 3 For equal conductivity, the ratio of
 - a) Areas is 1.64;
 - b) Diameters is 1.28 aluminium to copper.


Section 3 – Underground Cables

Types of Cables

The various types of cables are listed as follows:

- 1 Single core cables
- 2 Belted cables
- 3 Screened cables
- 4 Multicore SL cables
- 5 Multicore HSL cables
- 6 Oil filled cables
- 7 Gas filled cables
- 8 Plastic insulated cables


The main types used for distribution work are numbers 1, 2, 3 and 4 and these are described below.



Screened Cables (Power Type)

A screened cable is a multicore cable in which the insulation of each conductor is separately enclosed in a conducting film in order to ensure a radial electric field surrounding the conductor. The films are in electrical connection with one another and with the metallic sheath of the cable. They are usually earthed (see Figure 37).

Section 3 – Underground Cables



Current Rating of Cables

The current rating of cables is determined by:

- The thermal capacity of the cable
- The voltage drop
- The short circuit capacity

Sheath Currents

Sheath currents may be divided into two kinds, namely:

- Currents whose outward and return paths lie entirely in the sheath of one cable – sheath of one cable – sheath eddies.
- Currents whose outward and return paths are formed by the sheaths of separate cables - sheath circuit eddies.

The formation of sheath eddies is shown in Figure 39 where two single core cables are shown carrying a current I .

To obviate derating cables because of proximity effect, the following conditions should be considered:

- Where cables are fixed to a vertical surface or wall the distance between the wall and the surface of the cable should not be less than 20mm.
- Cables of which the cross sectional area does not exceed 185^2 should be installed at a distance between centres of not less than twice the overall diameter of the cable.

Section 3 – Underground Cables

- 3 Cables of which the cross sectional area exceeds 185^2 should be installed at a distance between centres of 90 mm.
- 4 Cables should be remote from iron and steel other than cable supports.

Conductor Temperatures

The maximum permissible continuous conductor temperatures for paper insulated cables are given in the following table

Voltage rating of cable kV	Type of cable	Maximum permissible temperature
0.6/1	All types	80
1.9/3.3		
3.8/6.6		
6.35/11	Single core	70
	Three core belted	65
	Three core screened	70
12.7/22		65
19/33	All types	

Table 6

Rating Factors

Tables of current ratings for cables always specify some ambient temperature and the number of cables which are in close proximity.

In practice the ambient temperature may be higher than that used for the design conditions, and so reduced current rating must be used.

When more than the specified number of cables are in close proximity the current rating of an individual cable must be reduced to allow for the cumulative heating effect in all adjacent cables. To allow for such conditions rating factors are used.

Rating factors for temperature changes are given in Figure 41; depth of laying in Figure 42; while proximity rating factors are given in Figure 43.

Section 3 – Underground Cables

Rating factors for ground air temperatures

Maximum Conductor Temperature ⁵ C	RATING FACTOR									
	Ground Temperature for Cables laid Direct or in Ducts				Air Temperature for Cables laid in Air					
	15 ⁵ C	20 ⁵ C	25 ⁵ C	30 ⁵ C	25 ⁵ C	30 ⁵ C	35 ⁵ C	40 ⁵ C	45 ⁵ C	
60	1.14	1.07	1.0	0.92	-	-	-	-	-	
65	1.12	1.06	1.0	0.94	1.26	1.18	1.10	1.0	0.89	
70	1.11	1.05	1.0	0.94	1.22	1.15	1.08	1.0	0.91	
80	1.09	1.04	1.0	0.95	1.16	1.12	1.06	1.0	0.93	

Figure 41

Single or Multicore Cables in Single Way Ducts

Depth of Laying Metres	0.6/1 kV Cables		1.9/3.3 kV to 19/33 kV Cables	
	Single Core	Multicore	Single Core	Multicore
0.50	1.00	1.00	-	-
0.60	0.98	0.99	-	-
0.80	0.95	0.97	1.00	1.00
1.00	0.93	0.96	0.98	0.99
1.25	0.90	0.95	0.95	0.97
1.50	0.89	0.94	0.93	0.96
1.75	0.88	0.94	0.92	0.95
2.0	0.87	0.93	0.90	0.94
2.5	0.86	0.93	0.89	0.93
3.0 or more	0.85	0.92	0.88	0.92

Section 3 – Underground Cables

3.2 Calculate cable voltage drop in relation to length of cable run (Part 1)

When selecting cables based on voltage drop the voltage drop in all circuits in the series arrangement must be considered.

Voltage drop is likely to be the main factor for selecting cable in circuits where:

- Cables carry high currents, that is, where
- Installation conditions are such that the current carrying capacity of a cable is not greatly reduced, and
- Maximum demand for the circuit is near the current carrying capacity of the cable

Cable route lengths are long.

Calculating voltage drop (Vd)

The actual voltage drop (Vd) for a particular cable in a given circuit is calculated using the equation:

$$Vd = \frac{Vc \cdot L \cdot I}{1000}$$

Where: Vd = actual voltage drop in volts

Vc = unit voltage drop in millivolts per ampere meter (mV/A.m)

This value is listed in the current carrying capacity and voltage drop tables of *Appendix B*.

L = route length of the circuit cables.

I = current to be carried by the circuit. (usually the maximum demand)

The divisor 1000 converts millivolts in the expression *mV/A.m* to volts.

A diversity allowance is applied when calculating voltage drop in domestic installations (See Clause 2.3.3(b)).

Calculating the unit value of voltage drop (Vc)

The maximum permissible unit value of voltage drop is calculated by using the same equation used for actual voltage drop transposer Vc is the subject.

$$Vc = \frac{1000Vd}{L \cdot I} \text{ mV/A}$$

Section 3 – Underground Cables

Single and three phase voltage drop

It may be necessary to convert the voltage drop in a single phase circuit to three phase voltage drop. For example determining the voltage drop in an installation from three phase consumers' mains to a single phase final subcircuit.

Conversion of the unit voltage drop value V_c (mV/A.m)

$$\text{Three phase VC} = \text{single phase } V_c \times 0.866$$

$$\text{Single phase VC} = \text{three phase } V_c \div 0.866$$

Conversion of the actual voltage drop V_d (Volts)

$$\text{Three phase } V_d = \text{single phase } V_d \sqrt{3}$$

$$\text{Single phase } V_d = \text{three phase } V_d \sqrt{3}$$

Cable selection based on voltage drop

You may need to select a cable size based on voltage drop where the voltage drop in the other cables in the series arrangement is known. For example:

Planning to meet voltage drop requirements

The following questions and comments will help you plan to select cables that meet voltage drop requirements.

What is maximum value of voltage drop permitted in the circuit?

Supply voltage is voltage measured at consumer's terminals (Clause 2.3.3). Nominal voltage for single phase supply can generally be taken as 240 V.

Maximum value of voltage drop in the cables to be selected is:


- 5% of supply voltage V_s - sum of other voltage drops
- 5% is 0.05 in your calculator

In the circuit above this is $V_s \times 5\% - V_{d_{fsc}}$

What is the maximum unit of voltage drop (V_c in mV/A.m) that will satisfy the voltage drop requirements?


Look up Appendix B and use the voltage drop equation to calculate maximum unit value of voltage drop.

Section 3 – Underground Cables



What cable has a unit value of voltage drop (V_c) equal to or less than the value calculated above?

Look up the current carrying capacity and voltage drop (Table B2).




Will the cable size selected carry the current required by the circuit?

Check the current carrying capacity in the appropriate table (Tables B2 or B3)

Current carrying capacity of the cable must be equal to or greater than the maximum demand in the circuit.

Section 3 – Underground Cables



Alternative cable size

After all the cables in a series arrangement have been selected to satisfy current carrying capacity requirements it may be found that the voltage drop exceeds 5%. In this case it is usually only necessary to increase the size of one of the circuit cables.

What is the maximum permissible voltage drop for the installation?

Supply voltage is voltage measured at consumers terminals (Clause 2.3.3)

To convert single phase voltage drop to three phase voltage drop multiply by.


What is the voltage drop in each circuit?

Look up

- the voltage drop unit values
- (V_c in mV/A.m) for the conductor size in each circuit.
- The equation in *Appendix B*.

Use the voltage drop equation to calculate the voltage drop for each circuit.

Section 3 – Underground Cables



What is the total voltage drop for the installation?

The total voltage drop is the sum of the voltage drops in the series arrangement of consumers mains, submains and final subcircuit.

The sum must not exceed 5% of the supply voltage for any series arrangement of circuits from the consumers terminals to load device terminals.

What circuit/s should have its cable sizes increased?

Where one cable has a much larger voltage drop than the other cables, increase its size.

Where all circuits have a similar voltage drop, increase the cable size on the circuit that is likely to be least costly.


What is the maximum permitted voltage drop in the circuit which is to have its cable size increased?

This is 5% of the supply voltage minus the sum of the voltage drops in the other circuits in the series arrangement.

Section 3 – Underground Cables


What is the maximum voltage drop unit value (V_c in $mV/A.m$) that will satisfy the maximum permitted voltage drop in the circuit?

Look up Appendix B and apply the voltage drop equation.



What cable has a unit value of voltage drop (V_c) equal to or less than the value calculated above?

Look up the current carrying capacity and voltage drop table (Table B2)



Complete practical exercises 5 & 6.

Cable size

Current carrying capacity is likely to be the determining factor in selecting cable size where:

Circuit route length is relatively short, and

Derating factors apply such as circuit grouping and effect of thermal insulation.

Section 3 – Underground Cables

Voltage drop is likely to be the main consideration for selecting cable size in circuits with high currents and long route lengths.

The cable size must satisfy both current carrying capacity and voltage drop requirements.

Section 3 – Underground Cables

3.2 Calculate cable voltage drop in relation to length of cable run (Part 2)

Practical exercise 5: Select cables based on voltage drop

Task

Use AS 3000 to select a cable size based on voltage drop where the voltage drop of other cables in the series arrangements is known.

Instructions

For each of the following circuits determine:

Maximum unit value of voltage drop (mV/A.m) permitted in the circuit

Minimum cable size for the chosen circuit

Circuit 1

A lighting circuit in a single phase 240 V domestic installation with:

Consumers mains $V_d = 9\text{ V}$

Route length from switchboard: 28m

Circuit breaker rating: 6 A

Cable is TPS fully surrounded in thermal insulation.

Maximum unit value of voltage drop (mV/A.m) permitted in the circuit:

Minimum cable size: _____

Circuit 2

A 240 V caravan site supply position is 40 m from a distribution board.

Installation has:

Three phase consumers mains: $V_d = 4.5\text{ V}$

Three phase submains $V_d = 7\text{ V}$

Final subcircuit is protected by a 16 A circuit breaker and installed underground.

Section 3 – Underground Cables

Maximum unit value of voltage drop (mV/A.m) permitted in the circuit:

Minimum cable size: _____

Circuit 3

A single phase 20 A irrigation pump is located 30 m from a distribution board.

Installation has:

Single phase consumers mains: $V_d = 2 \text{ V}$

Submains $V_d = 3 \text{ V}$

Final subcircuit is protected by a rewirable fuse and is TPS cable on a catenary wire.

Maximum unit value of voltage drop (mV/A.m) permitted in the circuit:

Minimum cable size: _____

Circuit 4

A single phase 240 V 20 A appliance is wired in TP1 cable in steel conduit.

Installation has:

Three phase consumers mains: $V_d = 6 \text{ V}$

Three phase submains $V_d = 4 \text{ V}$

Appliance is located 30 m from the distribution board and is protected by a circuit breaker.

Maximum unit value of voltage drop (mV/A.m) permitted in the circuit:

Minimum cable size: _____

Section 3 – Underground Cables

Practical exercise 6: Select alternative cable size based on voltage drop

Task

Use AS 3000 to select an alternative cable size in one circuit of an installation to avoid excessive voltage drop.

Instructions

For each of the following circuits determine:

Maximum permissible voltage drop in the installation.

The voltage drop in each circuit in the series arrangement.

The total voltage drop in the installation.

The circuit you choose to increase the cable size.

Maximum permitted voltage drop in the chosen circuit.

Minimum cable size for the chosen circuit.

Installation

Consumer's mains are three phase 42 mm^2 bare copper aerials spaced 0.4 m apart. Length is 25 m and maximum demand is 200 A. Sub mains are three phase 16 mm^2 TPS cable in an underground duct. Length is 60 m and maximum demand is 75 A.

Final sub circuit is single phase 2.5 mm^2 TP1 cable in surface mounted conduit. Length is 18 m and maximum demand is 20A.

1. Maximum permissible voltage drop in the installation: _____
2. Voltage drop in each circuit: _____
3. Total voltage drop: _____
4. Circuit chosen to increase cable size: _____
5. Maximum permitted voltage drop in the chosen circuit: _____
6. Maximum unit value of voltage drop (mV/A.m) in the chosen circuit: _____

7. Minimum cable size for the chosen circuit: _____

Section 3 – Underground Cables

3.3 Recall techniques to reduce electrical stress on cables

For rules relating to specific installation requirements, consult AS 3000 Part 1 SAA Wiring Rules.

Method of removing cables from the cable drum

The cable drums should be placed on a common shaft as shown. The drums are reversed in relation to one another on the shaft as. The drums are reversed in relation to one another on the shaft. This will result in the cable of one drum being removed over the top of the drum while the cable on the second drum is removed under the drum. As the drums will revolve in opposite directions, they will tend to slow down because the friction between them acts as a brake. This prevents excess cable being wound off the drums and reduces the possibility of kinks and twists in the cables.

Many different types and varieties of cables are used in electrical installations. When a cable is selected for a given application, the appropriate Australian Standard (for example AS 3000) must be consulted to ensure that the cable chosen meets all the requirements of the different authorities concerned with the oversight and approval of electrical installation. The following combination of factors must be considered in making the correct selection of cable:

- Application and types of duty;

- Current conditions;

- Voltage drop considerations;

- Operating voltage;

- Operating environment, e.g. ambient temperature (of surrounding areas), possibility of vibration and/or mechanical damage.

Cable Stranding

Conductors may be either solid drawn or stranded. In the above example, the conductor was specified 1/1.38 mm. This is a single strand of 1.38 mm diameter conductor. The equivalent cross sectional area of this conductor as shown in the appropriate tables would be 1.5 mm^2

If a more flexible conductor was required, a 7/0.50 (e.g. a 7 strand) conductor could be used. Such a conductor would have the same cross-sectional area but also seven strands of 0.5 mm diameter conductors twisted together to form a single conductor.

The two differ mainly in cost and flexibility. The single stranded conductor is cheaper but less flexible than the stranded conductor.

Section 3 – Underground Cables

Because of its flexibility, the stranded conductor is generally used in installations prone to vibration, while the single strand conductor has wide use in domestic installations where low cost is an important factor.

Bending of Cables

Excessive bending of cables during their installation will reduce their working life. The parts of a cable especially liable to damage through undue bending are conductors, paper or cambris tapes, metal or conductive tapes, core screens and insulation of high voltage cables.

Tables in the appendix list the recommended bending radii for various cables.

Temperature Ratings

Cables have a temperature rating based on that of the insulation. Maximum operating temperatures are set out in the Appendix. However, some specific examples are:

R75 or V75 has a maximum working temperature of 75°C

These cables would be used in general wiring, i.e. normal domestic installations.

V105 has a maximum working temperature of 105°C

R-S-150 has a maximum working temperature of 150°C

These cables would be used in high temperature applications such as fluorescent strip lighting.

Heat resisting fibrous insulation has operating temperatures ranging from 110°C to in excess of 200°C , depending on the type used.

These cables would be used in high temperature incandescent lamp fittings.

Polytetrafluorethylene (PTFE) cable has a working temperature of 200°C

This type of cable would be used to connect the hot plates of an electric range to the appropriate control switch.

Enclosure of Cables

The maximum number of cables that may be enclosed in a conduit or pipe must comply with the requirements of the SAA Wiring Rules Part 1

The procedure used to determine the size conduit for a particular job is as follows:

Determine the overall cross sectional area of each cable size to be installed in conduit (Table 3 of Appendix refers)

Calculate the total overall cross sectional area of all the cables to be installed in the conduit.

Section 3 – Underground Cables

Determine the required conduit size, having regard to the space factor based on the number of cables to be installed in the conduit. (Table 2)

Check that the proposed conduit enclosure will conform to the requirements of Tables 4 and 5, regarding the maximum number of cables to be enclosed.

Types of Conductors

The two main types of material used for conductors are aluminium and copper, each having specific advantages:

Copper:

- Has high conductivity per unit area;
- Is easily mechanically joined or soldered;
- Is expensive;
- Is resistant to corrosion;
- Is stronger than aluminium.

Aluminium:

- Has high conductivity per weight;
- Must be joined with a joining paste, since aluminium oxide, an insulator, forms almost immediately after cleaning;
- Is cheaper than copper, but its coefficient of expansion must be taken into account when joining;
- Is not as resistant to corrosion;
- Is weaker than copper;
- When used in installations such as aerials, aluminium cable is usually steel cored for added strength

The cable lugs used on aluminium cables are longer and thicker, while aluminium cables require a larger bending radius than copper cables.

The performance of cable insulating material will be drastically affected if the cable is exposed to:

- Weather
- Oil
- Abrasion
- Chemicals

Section 3 – Underground Cables

Tables in the appendix detail the relative performance of various sheathing materials. A comparison of vulcanised rubber has:

- Operating temperature;
- Poorer weather resistance;
- Poorer oil resistance;
- Similar water resistance;
- Poorer chemical resistance
- Poorer solvent resistance;
- Poorer abrasion resistance;
- Similar flame and insulation resistance;
- Similar electric strength.

Section 3 – Underground Cables

3.4 Recall cable rating factors, method of cable joining

Paper insulated, lead sheathed armoured cable, PVC served, typically has the following features:

Conductors – stranded copper or aluminium

Insulation – oil impregnated paper

Covering – lead sheathing

Armouring – steel wire

Serving – PVC (as protection against corrosion)

This type of cable is mainly used for high voltage distribution systems.

The three-core plus earth, PVC insulated, steel wire armoured, PVC sheathed cable is used where cables are prone to mechanical damage. The steel wire armouring acts as a buffer to prevent damage to the conductors.

Table 14 in the Appendix provides further details.

The substitution of aluminium conductors results in a less expensive alternative.

Note that the conductors are shaped to allow maximum utilisation of space to counteract the larger aluminium cables required to match the conductivity of copper.

Aluminium cables require special joining techniques which will be discussed later.

Stripping the Cable

The correct stripping of cables is of utmost importance as an incorrect stripping method will result in a nicking of the conductor. This will impair its mechanical strength and after relatively few bends of the conductor a break may occur.

Knife

Adjustable strippers

Automatic strippers

Pliers

The Knife

To use the knife:

Cut insulation away from your body.

Slice insulation at an angle of approximately 15° to the insulation to avoid cutting into the conductor.

Continue the process until all the required insulation is removed from the conductor.

Section 3 – Underground Cables

Adjustable Strippers

To use adjustable strippers:

Rotate the adjusting screw until the strippers close and the jaws grip the cable insulation.

Rotate a further half turn until the jaws begin to cut the insulation.

Do not screw the adjusting screw too tight as this will damage the conductor.

Pull the strippers away from the cable; this will remove the insulation.

Automatic Strippers

Automatic strippers are available from most electrical wholesalers. This stripper operates automatically once the correct positions on the blade is selected and the handles compressed together.

Grip the insulation under one set of jaws.

Knick the insulation under the other set of jaws.

Remove the insulation by moving the second set of jaws away from the first by squeezing the handles.

Automatic strippers are generally used by production times requiring many cables to be effectively stripped as quickly as possible.

Pliers

Many experienced electricians use their pliers to strip cables. However, this method is not recommended for inexperienced persons, as it carries a high risk of damaging the conductor.

The pressure exerted by the plier jaws in gripping the insulation is critical; too much pressure will damage the conductor.

Replacement of insulation

Observe the following points in stripping:

Do not remove insulation further than is necessary to allow each conductor to enter and extend to the full length of the hole where it is to be clamped or joined.

Cut away insulating material damaged by soldering and replace it with insulation equipment to the original.

Basic Terminating Methods

Two widely used methods of termination are:

Soldering

Mechanical connection

Section 3 – Underground Cables

Soldering

Care must be taken when soldering to prevent the formation of a 'dry joint' which results in a high resistance joint.

To prevent a dry joint forming:

Heat the cable to solder-melting temperature and apply solder to the cable.

The melting of the solder is produced by heat from the cable rather than direct heat from the flame or the soldering iron.

Do not move the soldered connection until the solder has solidified.

The automatic preset crimping tool crimps 0.5 to 6 mm^2 cables and has an automatic predetermined depth control.

Cables from 10 to 120 mm^2 may be crimped using an adjustable crimper. The size of the crimp is set by rotating the adjusting screw and lining up the mark on the jaws with the scale on the crimper.

Large cables generally require much force to be exerted during the crimping operation. For these, hydraulic crimpers are used.

Aluminium Conductors

The use of aluminium conductors is becoming increasingly popular because aluminium:

Is cheaper than copper;

Is about 1/3 the weight of copper;

Has a larger cross sectional area for the equivalent current rating than copper;

Has a better thermal capacity than copper

The cost and weight factors are the main reasons for aluminium's growing use for aerials, busbars and large current carrying conductors.

Joining Aluminium Conductors

The major problem in joining aluminium conductors is the oxide which reforms on the surface as soon as it is removed. This oxide is an effective insulator.

To overcome oxide formation, a contact aid is used in cleaning aluminium surfaces for joining. This consists of a special grease which may contain abrasive particles to help in the removal of the oxide film. The grease prevents the oxide reforming.

NOTE:

Ordinary greases are not used as they may corrode aluminium.

Section 3 – Underground Cables

3.5 Apply cable schedules for underground cable installation scheme

Underground Cables

Introduction. In towns and densely populated areas overhead lines are clearly impossible. In the very early days of distribution the principles of overhead lines were employed in underground work. One very successful system was devised by Crompton, who stretched bare conductors between glass insulators contained in underground ducts or culverts; one such system was in use in 1926 after thirty years service. The method was successful for low voltage systems, except that explosions sometimes occurred due to pressure of gas produced by the metallic sodium which was formed by electrolysis, due to slow leakage at the insulators. The method is unsuitable for high voltages because of the flash over of the insulators. It was found advisable to insulate the conductor before it was laid, and the combination of conductor and its insulation is called a cable.

Vulcanized rubber insulated cables were then used, and because of their failure vulcanized bitumen cables. The latter are still used for low voltage distributors and in mines.

One of the earliest attempts to make a high voltage, paper insulated cable was due to Ferranti, who wrapped oil impregnated paper round copper tubes and pushed the insulated conductor into lengths of wrought iron pipes which he filled with compound

Types of Cable

There are many types of cable used at the present time; the type for a particular service is determined by the mechanical properties required and the voltage of transmission, mainly the latter.

Low Tension Cables (Below 1000 Volt)

The insulating material may be impregnated paper, varnished cambric, vulcanized rubber, or vulcanized bitumen.

Paper is the most important insulating material, and is made of wood pulp, manila fibre or rag. The impregnating compound is thin or thick oil with or without resin. The resin is added to increase viscosity at working temperatures so that drainage should not be excessive, whilst it does not increase the viscosity greatly at the temperature of impregnation. The thickness of dielectric at 660 volts is between 0.08 and 0.11 in.

Varnished cambric is coated with petroleum jelly to provide lubrication between layers so that bending of the cable is possible without damage. An advantage is that there is no drainage from the ends of the cable.

In *vulcanized bitumen* cables the refined bitumen is melted and sulphur and vegetable oils are added. On cooling, the bitumen hardens and acts as the

Section 3 – Underground Cables

waterproof envelope of the cable. No elaborate sealing is required. A major disadvantage is that the bitumen becomes soft under the action of alkaline solutions, and the conductor becomes decentralised. Vulcanized bitumen cables were once favoured for shaft and roadway cables because they are easily jointed, do not require elaborate sealing, and are light compared with lead covered, paper insulated cables. They are not now made because of the softening and decentralisation, and are being replaced by the paper cables, which are often cheaper and as suitable, and have a greater current carrying capacity

Lead sheathed, rubber insulated cables have a vast field of use in house wiring, large building, and ships.

Cables in mines are subjected to specially rough handling and they are constructed accordingly. Trailing cables must be flexible and must be capable of being dragged along without being damaged. Fig. 69 shows a 5 core trailing cable, with a tough rubber central cradle, insulated pilot, tough rubber sheath, and braided wire screen. One of the conductors acts as the earth conductor, and all the five cores are rubber insulated flexibles. The central cradle prevents a short circuit from occurring when a fall of coal or tone crushes the cable. The braided wire screen is of tinned copper and is embedded in the tough rubber sheathing; the screen is earthed but is not used as the earth conductor. The pilot wire serves for the remote control of coal cutter and other circuits.

Shaft cables should be drained and not contain free compound, otherwise the compound will settle and force its way out at the lower termination. The installation of a shaft cable is best performed in the following way, in order that the cable may not suffer a large tension due to its weight. The cleats are first fixed. Then the cable is run from a winch over pulleys into the shaft, where a short length is allowed to swing free. It is fastened to a winch rope with a spun yarn lashing and then lowered a short distance, say 30 ft. It is lashed again, and lowered a further distance. This is repeated until the cable reaches the bottom of the shaft.

Section 3 – Underground Cables




FIG. 70. PAPER-INSULATED POWER CABLES

Fig 70 Paper Insulated Power Cables




FIG. 71. "H"-TYPE CABLE
(Henley's Telegraph Works Co.)

Section 3 – Underground Cables




FIG. 72. "H.S.L."-TYPE CABLE
(Siemens Bros.)

Laying

There are three main methods of laying cables: *direct laying*, the *draw in* system, and the *solid* system.

In direct laying a trench is dug, in which the cable is laid and covered with soil. The cable may be protected by planks, bricks, tiles, or concrete slabs. It used to be the practice to armour such cables, but nowadays they are often laid with a bare sheath or with a serving of bituminized paper and Hessian over the sheath. The former method is the only safe one in places where subsidence of the soil is likely to occur; then the cable should have steel wire armouring, so as to take a considerable tension. If the ground contains harmful chemicals, the serving must be adequate to protect the cable from corrosion and electrolysis. Bituminized paper is effective. It is clear that direct laying is cheap, but an extension of load is possible only by a completely new excavation which costs as much as the original work. In most cases, digging and trenching are done manually, but in laces free from obstruction machine methods can be used.

Section 3 – Underground Cables



FIG. 78. MACHINE LAYING OF CABLES
(Wasserhülle A.-G.)

Fig. 78 shows a machine dredges a trench 18in.wide by 5 ft. deep, conveys the soil back along the top, and lays the cable. The trench is then filled and levelled.



FIG. 79. CABLES IN TRENCH PROTECTED BY CONCRETE COVERS


Fig. 79 shows a cable in a trench with concrete covers for protection.

In the draw in system a line of conduits, ducts, or tubes is laid in a trench. The conduits or ducts are of glazed stoneware, cement, or concrete (Fig 80). The tubes are of stoneware, fibre, steel, or wrought iron. The ducts being laid, the cables are pulled into position from manholes or brick pits. It is unnecessary to

Section 3 – Underground Cables

armour the cable, but a serving of Hessian tape of jute protects the cable when drawing in.

In the solid system the cable is laid in troughing in an open trench.



Section 3 – Underground Cables

The troughing is of stoneware, cast iron, asphalt, or treated wood. After the cable is placed in position, the troughing is filled with a bituminous or asphaltic compound and covered over. The cable can be laid with a bare sheath, and is immune from electrolysis as the sheath is electrically insulated from earth. Fig 81 shows a trough containing cable and covered with asphalt.

Jointing

The most common way of jointing the conductors is to insert the ends into a ferrule, which is a slotted metal tube, and solder the whole solid.

With oval cable the ferrule is made in two halves which can be turned with respect to one another, in order that the cables need not be twisted to make their major axes parallel. Packing adaptors are also being used.

Fig .82 shows a join for a 66kV., single core, “H” – type cable with oval conductor. The following is a brief description of the procedure. The lead sheath is cut back 20 5/8 in. and the paper 2 7/8 in. The lead sleeve, lead flare and paper tube are passed back along the conductors. The ferrule is put on and the parts soldered together. The paper is pencilled back 1 ¼ in., and the metallized paper is cut back to within 1 ½ in. of the lead. The paper tube is slipped into position and fixed by four narrow wedges, which are jammed in by layers of oiled silk tape. The paper tube is kept in a canted position by a kalanite spreader, which is made of two halves as shown in the cross sectional diagram. This ensures that no air will be entrapped when the joint is filled with compound. Preshaped paper stress cones are lapped on, and oilproof (Kaleoilres) tape is wrapped over the end of the lead sheath to prevent oil from flowing from the joint into the cable. The lead flare is placed in position and ¼ in. diameter lead wire is wrapped on. The lead sleeve is put in position and plumbed at the ends and the middle. The bonding strands are fixed, and then the joint is filled with oil. It is seen that the upper part of the lead sleeve is shaped so that the sleeve cannot be filled completely with oil; the air dome is left to allow for the expansion of the oil. The black sectors show in the figure represent steel reinforcing bands.

Fig. 83 shows a joint for a 66kV. Oil filled cable, single core. It is essential that no moisture or dust shall enter the jointing tent.

Fig. 84 shows the recently designed styrene joint. The styrene is added as liquid and on being heated it polymerizes and sets into a very hard solid. The method is specially useful for 3 core cables, as the joint is mechanically rigid and displacement of the cores cannot occur.

A recent type of joint, which is solid at working temperatures, employs a mixture of oil and finely powdered and cleaned sand in place of the styrene. A small lead flare is used between the plumbed joint and the lead cylinder containing the compound.

Section 3 – Underground Cables

Insulation Resistance

Consider a single core cable of conductor radius r and internal sheath radius $1/2D$. The resistance of a thin shell between radii x and $x + dx$, and axial length 1cm. is

$$dR = \frac{p dx}{2\pi x^2}$$

Where p is the resistivity or specific resistance of the dielectric, for the area of cross section is $2\pi x^2$ cm^2 and the thickness is dx .

The total resistance is thus

$$R = \int_r^{D/2} \frac{p dx}{2\pi x^2} = \frac{p}{2\pi} \log h \frac{D}{2r}$$

The insulation resistance of a length l is

$$R_l = \frac{p}{2\pi l} \log h \frac{D}{2r}$$

The value of p for impregnate paper is about 5×10^{14} ohms, and decreases exponentially with temperature, so that

$$p_t = p e^{-\alpha t} : \text{ is about } 0.05$$

Example. Find the insulation resistance per mile of a cable of conductor diameter 0.4 in. and internal sheath diameter 0.7 in. $p = 6 \times 10^{14}$

The resistance of 1 mile is

$$\begin{aligned} & \frac{p}{2\pi} \frac{2.303}{5280 \times 12 \times 2.54} \log \frac{D}{2r} \text{ ohms} \\ & = \frac{2.28 \times 10^6}{2\pi} p \log \frac{D}{2r} \text{ ohms} \\ & = \frac{2.28 \times 10^6}{2\pi} \times 6 \times 10^{14} \log 7/4 \\ & = 3.21 \times 10^8 \text{ ohms} \quad \underline{\underline{321}} \end{aligned}$$

Section 3 – Underground Cables

When the voltmeter is across the positive main and earth, the system is as shown in Fig. 85. The following currents then flow to and from the earth: (i) V_1 / R_1 downwards, (ii) V_1 / R_1 downwards, and (iii) $V - V_1 / R_2$ upwards.

Therefore

$$V_1 / R_1 + V_1 / R_1 = V - V_1 / R_2$$

Giving
$$V_1(1/R_1 + 1/R_1 + 1/R_2) = V/R_2$$

Similarly in the other case

$$V_2(1/R_1 + 1/R_1 + 1/R_2) = V/R_1$$

Therefore, by division,

$$V_1/V_2 = R_1/R_2,$$

So that

$$V/V_2 = R_1(1/R_1 + 1/R_1 + 1/R_2)$$

$$= R_1 / R_1 + R_1 / R_1 + R_1 / R_2,$$

$$R_1 / R_1 + R_1 / R_2 = V_1/V_2,$$

Giving

$$R_1 = \frac{V}{V_2} \left(1 + \frac{V_1}{V_2} \right) = r \frac{V}{V_2} \frac{V_1 + V_2}{V_2}$$

Similarly

$$R_2 = r \frac{V}{V_1} \frac{V_1 + V_2}{V_1}$$

In this case $R_1 = 10000 \frac{250 + 150 + 30}{30} = \underline{\underline{23300}}$

And $R_2 = 10000 \frac{250 + 150 + 30}{150} = \underline{\underline{4660}}$

Stress and Capacitance of Single-Core Cable

Suppose that the cable of Fig. 86 has a dielectric constant ϵ , no losses, and a charge q per cm. of axial length. Applying Gauss's theorem to a circular cylinder of radius x , we get

$$eS2\pi x = 4\pi q$$

Or

$$S = 2q/x,$$

Where S is the electric stress at distance x from the axis. If E is the potential difference between the conductor and sheath

$$\int_r^D \frac{1}{r} S dx = \frac{2q}{r} \log h \frac{D}{2r},$$

Section 3 – Underground Cables

So that the capacitance per cm. length is

$$C = \frac{q}{E} \frac{1}{2 \log h(D/2r)} \text{ electrostatic units (cm.)}$$

$$\frac{1}{2 \log D/d} \text{ cm. per cm. length}$$

Where d = the conductor diameter

Remembering that

$$1 \text{ cm.} = 10^9 \text{ F}$$

We find that

$$C = \frac{0.0388}{(\log D/d)} \text{ F per mile length}$$

Substituting for q in terms of E we see that the stress is

$$S = \frac{E}{x \log h(D/d)}$$

The stress is a maximum at the conductor where it is

$$S_{\max} = \frac{E}{r \log h(D/d)} = \frac{2E}{d \log h(D/d)}$$

For a given voltage E and internal sheath diameter D , the stress S_{\max} has a minimum value for variation of d when the differential coefficient of S_{\max} with respect to d is zero. This occurs when

$$\log h(D/d) = 1 \quad \text{or} \quad D = 2.718d$$

In low voltage cables the insulation is thin and d is greater than $D/2.718$. In high voltage cables d may be less, and then it is advantageous to increase the diameter of the conductor to this value. There are two ways of doing this without using excessive copper; by making the conductor hollow or by building it up with a lead sheath. The latter method has the advantage of eliminating at the same time the increase of stress due to stranding which may be as high as 25 per cent. If d varies from $D/2$ to $D/4$, the maximum stress varies by only 6 per cent, so that no great care need be taken to fix the ratio D/d provided it is not too great.

The stress at the lead sheath is

$$\frac{2E}{D \log h(D/d)}$$

So that the stress varies from a maximum at the conductor to a minimum (of d/D times the maximum) at the sheath. In some high voltage cables the

Section 3 – Underground Cables

dielectric is graded for strength by having a dense paper at the conductor and a less dense elsewhere. This does not appreciably alter the stress and voltage distribution unless the dielectric constants of the paper differ, but by using a paper of high electric strength near the conductor the total thickness of insulation can be reduced.

There are two main methods by which a more uniform distribution of stress may be achieved, by the introduction of intersheaths and by the use of layers of insulating material with different dielectric constants.

Effect of Intersheaths on Stress

Suppose that intersheaths of diameters d_1 and d_2 are inserted into the dielectric and maintained at potentials E_1 and E_2 . The stress between any two metallic cylinders varies inversely as the distance from the axis; this is found by applying Gauss's theorem. Thus between the conductor and the first intersheath the stress at a point distant x from the conductor is

$$S_1 = A_1 / x,$$

$$\text{For } \frac{S_{\max}}{d} = \frac{2E}{d \log h D/d} = \frac{d \log h D/d}{d^2}$$

$$\frac{2E}{d \log h D/d} = \log h \frac{D}{d} = \frac{d}{D/d} = \frac{D}{d^2}$$

$$\frac{2E}{d \log h D/d} = \log h \frac{D}{d} = 1$$

Where A_1 is a constant which is found by integrating S_1 from the conductor to the intersheath as follows

$$E - E_1 = \int_{\frac{1}{2}d}^{\frac{1}{2}d_1} S_1 dx = A_1 \log h \frac{d_1}{d}$$

So that $A_1 = (E - E_1) / \log h \frac{d_1}{d}$

And $S_1 = \frac{E - E_1}{x \log h \frac{d_1}{d}}$

The maximum stress is

$$S_{1\max} = \frac{E - E_1}{\frac{1}{2}d \log h \frac{d_1}{d}}$$

Similarly the maximum stress between the first and second intersheaths is

Section 3 – Underground Cables

$$S_{2\max} = \frac{E_1 E_2}{\frac{1}{2} d_1 \log h d_2 / d_1}$$

Whilst the maximum stress between the second intersheath and the sheath is

$$S_{3\max} = \frac{E_2}{\frac{1}{2} d_2 \log h D / d_2}$$

By choice of E_1 and E_2 the maximum stresses can be made equal, and the stress distribution is like that shown by curve A of Fig. 87 instead of curve B which represents the stress without intersheaths.

It is possible to choose d_1 and d_2 so that the stress varies between the same maximum and minimum in the three layers, by taking

$$d_1 / d = d_2 / d_1 = D / d_2$$

Equating the maximum stresses we get

$$E_2 = \frac{E}{1 - \frac{1}{3}}, E_1 = \frac{E}{1 - \frac{1}{3} - \frac{1}{3}}$$

The maximum stress is then

$$\frac{E E_1}{\frac{1}{2} d \log h} = \frac{E}{1 - \frac{1}{3}} \frac{E}{\frac{1}{2} d \log h} = \frac{E}{\frac{1}{3} - \frac{1}{2} d \log h D / d}$$

Since $\log h D / d = \log h^3 = 3 \log h$.

Without the use of intersheaths the maximum stress is

$$\frac{E}{\frac{1}{2} d \log h D / d}$$

So that the maximum stress has been reduced in the ratio

$$1 : \frac{1}{3} - \frac{1}{2}$$

Example. A single core 66kV. Cable has a conductor diameter of 2cm, and a sheath of inside diameter 5.3cm. Find the maximum stress. If two intersheaths are used, find the best positions, the maximum stress, and the voltages on the intersheaths.

Here $D / d = 5.3 / 2 = 2.65$, so that $1 - \frac{1}{3} = 0.667$

Thus $d_1 = 2.77$ cm. and $d_2 = 3.84$ cm. are the diameters of the intersheaths. The peak voltage on the conductor is $66 \sqrt{2} \sqrt{3} = 53.8$ kV., so that

Section 3 – Underground Cables

$$E_2 = \frac{53.8}{1 + \frac{1}{1.384} + \frac{1}{1.910}} = \underline{\underline{23.9kV}}$$

And

$$E_1 = 1 + \frac{1}{1.384} = 23.9 + 41 = 64.9 \text{ kV}$$

It should be remembered that in practice the system will be three phase at this voltage, and the r.m.s. neutral to voltage is $1/\sqrt{3}$ times these values. The maximum stress without the intersheaths is

$$\frac{53.8}{1 + \log h/2.65} = \underline{\underline{55.3kV}} \text{ per cm.},$$

And the maximum stress is 20.8kV per cm. With the intersheaths the maximum stress is

$$\frac{55.3}{\frac{1}{3} + \frac{1}{1.384} + \frac{1}{1.91}} = \frac{55.3}{1.43} = \underline{\underline{38.7kV}} \text{ per cm.},$$

While the minimum stress is 27.9kV. per cm. Fig 87 shows the stress distribution in both cases. The maximum stress has been reduced by the ratio 1:1.43.

Example. Suppose that in the previous example the intersheaths are spaced at equal distances from each other, the conductor and the sheath. Find their voltages for the same maximum stresses in the layers, and find the maximum stress.

$$D = 5.3 \text{ cm.}, d = 2 \text{ cm.}, \frac{1}{3} D = d = 1.7 \text{ cm.}, \text{ so that } d_1 = 3.1 \text{ and } d_2 = 4.2.$$

$$S_{1\max} = \frac{E - E_1}{\log h/1.55} = 2.28 \frac{E - E_1}{},$$

$$S_{2\max} = \frac{E - E_2}{1 + 55 \log h/4.2/3} = 2.12 \frac{E - E_2}{},$$

$$S_{3\max} = \frac{E_2}{2 + 11 \log h/5.3/4} = 2.06 E_2.$$

Equating these we get $E_1 = \underline{\underline{45.2kV}}$. and $E_2 = \underline{\underline{23.0kV}}$. The maximum stress is $\underline{\underline{47.5kV}}$. per cm. It is seen that the positions and voltages of the intersheaths are not very critical.

The use of intersheaths has not been general practice because of the complications involved. The sheaths must be supplied with the requisite potentials and must carry quite large charging currents. Jointing is made very difficult. Furthermore when there is a breakdown at one place, the stresses

Section 3 – Underground Cables

between the intersheaths containing healthy dielectric rise and breakdowns take place at other the cable, which is probably the greatest drawback.

Capacitance Grading

Suppose that the dielectric consists of two layers with a dividing diameter d_1 , the dielectric constants being ϵ_1 and ϵ_2 , as shown in Fig. 88. By Gauss's theorem the stress in the inner layer is

$$S_1 = 2q / \epsilon_1$$

Whilst in the outer layer it is

$$S_2 = 2q / \epsilon_2$$

Then

$$E = \int_{\frac{1}{2}d}^{\frac{1}{2}d_1} S_1 dx + \int_{\frac{1}{2}d_1}^{\frac{1}{2}D} S_2 dx$$

$$2q \frac{1}{\epsilon_1} \log h \frac{d_1}{d} = \frac{1}{\epsilon_2} \log h \frac{D}{d_1},$$

so that

$$C = \frac{q}{E} = \frac{1}{\frac{2}{\epsilon_1} \log h \frac{d_1}{d} + \frac{2}{\epsilon_2} \log h \frac{D}{d_1}}.$$

The maximum value of S_1 is

$$S_{1\max} = \frac{4q}{\epsilon_1 d} = \frac{2E}{d \log h \frac{d_1}{d} + \frac{1}{\epsilon_2} \log h \frac{D}{d_1}},$$

and

$$S_{2\max} = \frac{4q}{\epsilon_2 d_1} = \frac{2E}{d_1 \frac{2}{\epsilon_1} \log h \frac{d_1}{d} + \log h \frac{D}{d_1}}.$$

Example. Suppose that the cable of the last two examples has an inner layer 1 cm. thick of rubber dielectric constant 4.5 and the rest impregnated paper of constant 3.6. Find the maximum stress in the rubber and in the paper.

$$d = 2, d_1 = 4, D = 5.3, \epsilon_1 = 4.5, \epsilon_2 = 3.6.$$

$$S_{1\max} = \frac{2 \times 66}{2 \log h 2 + \frac{1}{25} \log h 1.325} = \underline{\underline{63 \text{ kV. Per cm.}}}$$

and

Section 3 – Underground Cables

$$S_{2\max} = \frac{2 \cdot 66}{4 \cdot 0 \cdot 8 \log h_2 \cdot \log h_1 \cdot 325} = \underline{\underline{39.5}} \text{ kV. Per cm.,}$$


Both to be multiplied by $\sqrt{2/3}$ of course.

Thus the maximum stress has been reduced from 67.8 to 63. The reduction is hardly worth while, and in practice the only grading used is for strength, i.e. a better quality paper is put near the conductor than near the sheath. This method of grading is quite practicable.

Power Factor of Single-core Cable

Suppose that the dielectric has a resistivity p which is independent of the stress and may be considered as constant throughout the cable. Then upon the application of an alternating voltage E of frequency $\omega/2$ there will be an in phase current of E/R per cm. length, where R is given by equation (39).

The value of p from which G is to be calculated is generally very much less than that measured by direct current, and depends upon the frequency of the voltage. This is due to the fact that the losses with alternating currents are caused mainly by absorption phenomena.



Also a charging current ωCE , where C is given by equation (40), which leads the voltage by a right angle. Fig. 89 shows the vector diagram for this case. The total current I is the vector sum of E/R and ωCE , and leads the voltage by an angle


where

$$\cot \phi = \frac{E/R}{\omega CE} = \frac{1}{\omega CR}.$$

It is usual to denote the reciprocal of R by G , which is the conductance of the cable per cm. length, so that


$$\cot \phi = \frac{G}{\omega C}$$

Section 3 – Underground Cables



The power factor of the cable is given by

$$P.F. = \frac{\text{Watts}}{EI} = \frac{E^2 / R}{EI} = \frac{E / R}{I} \cos \delta$$



In well made cables δ is so near to 90° that $\cos \delta$ and $\cot \delta$ are small and very nearly equal to each other and to δ , where δ is $\delta / 2$ and is in radians.

We may thus put


$$P.F. = G / C$$

The dielectric loss is

$$E^2 / R = E^2 G = CE^2$$


The power factor of impregnated paper varies with the electrical stress and the temperature. Fig. 90 shows how the power factor rises with the stress. At a stress of 60kV per cm. the power factor begins to rise, and above this stress it is said that the dielectric is *ionising*. The term is unfortunate, as it implies that the gaseous voids are producing ions by collision and this may not be the case; for although ionization by collision will cause a rise of power factor, it is not true that a rise of power factor is necessarily caused by this phenomenon.

Section 3 – Underground Cables




The variation of power factor with temperature depends upon the paper and oil, and also upon the completeness of drying. It was once usual for the power factor temperature curve to have a minimum of about 40°C ., as shown in Fig. 91, curve A; this is with the V-curve. With better drying and impregnation, the power factor temperature curve is nowadays more like that of curve B, which is flat up to 50°C . or higher. Fig.92 shows power factor temperature curves for various stresses on high grade impregnated paper insulation. The effect of resin is to make the power factor rise steeply at high temperatures, and the tendency in high voltage cables is to omit the resin.

The existence of the V-curve can be explained by the presence of moisture or inhomogeneities in the dielectric.



Section 3 – Underground Cables

Thus if a dielectric has a conducting path represented by R in Fig. 93 (a), a capacitance path C, and a mixed path R'C', it can be shown that it is represented by the arrangement of Fig. 93 (b), where R_1 and R_2 are of the same character as R and R' C_1 and C_2 are like C and C', i.e. they have the same temperature variations. The second arrangement is the well known Maxwell model for dielectric absorption and will exhibit the V-curve.



Capacitance of Three-core, Belted-type Cable

The three-core S.L. and H types are equivalent, as far as capacitance and stress are concerned, to three separate single core cables. In the belted type cable conductors have capacitance C_c to each other and C_s to the sheath, so that the system of capacitances and can be replaced by a Y of capacitances C_1 as shown in Fig. 95 For this is to be so, the capacitances between any two conductors in these arrangements must be the same, so that $C_c = \frac{1}{2}C_c + \frac{1}{2}C_1$, or $C_1 = 3C_c$. The centre point of the Y is the neutral, and as the sheath is at zero potential, we can consider that these capacitances act to the sheath, so that the neutral capacitance of each conductor is

$$C_c = C_1 = 3C_c$$


It is very difficult to calculate the capacitance to neutral from the geometry of the cable. The following empirical formula gives the capacitance with sufficient accuracy for design work.

$$C_c = \frac{0.048}{\log \left(1 + \frac{t}{d} \right)^{3.84} \left(1 + \frac{t}{1.70} \right)^{0.52} \frac{t^2}{2}} \text{ F. Per mile}$$

Where d = conductor diameter,
 t = thickness of conductor insulation,
 And t = thickness of belt insulation.

Section 3 – Underground Cables

The capacitances C_c and C_s are found best by measurement, and the neutral capacitance calculated in the following way.



Let conductors 2 and 3 be connected to the sheath and the capacitance be measured between conductor 1 and the rest. The value is

$$C_c + C_s = 2C_c$$

Next let all the conductors be commoned and the capacitance, C_b , be measured between them and the sheath.

$$C_b = 3C_c$$

Then

$$C_c = \frac{1}{3} C_b$$

And

$$C_s = \frac{1}{2} C_a + \frac{1}{6} C_b$$

The capacitance to neutral is thus

$$C_c + \frac{1}{3} C_b + \frac{3}{2} C_a + \frac{1}{2} C_b$$

$$= \frac{3}{2} C_a + \frac{1}{6} C_b$$

If C_b is not known it may be taken as $1.8C_a$, so that

$$C_c = \frac{1}{3} C_b = 0.6C_a$$

Example. The capacitance of a length of three phase cable is measured and is the capacitance between two cores (the third being connected to the lead sheath) is found to be 3 F . Find the charging current per core if the cable is connected to an 11kV., 50 eye., three phase alternator. Prove each step.

The capacitances are shown in Fig.96, so that the measured capacitance is

$$C_c + \frac{1}{2} C_c + C_s = \frac{1}{2} (3C_c + C_s),$$

Which is half the capacitance to neutral. The neutral capacitance is therefore 6 F . And the charging current per core is

$$C_0 E = 2 \times 50 \times 6 \times 10^6 \times 11000 \sqrt{3}$$

$$= \underline{\underline{1197A}}$$

Section 3 – Underground Cables

Stress in a Three Core Cable

Even when the dielectric is homogeneous the problem cannot be solved with accuracy, and as the dielectric is never homogeneous, because of the fillers, there is no point in quoting or working from formulae. There is a rotating electric field in the 3 core cable, and the maximum stress occurs at the point nearest the centre on the conductor at maximum voltage.

It is, however, almost certain that this stress is not the determining factor in the life of the cable, for it is normal to the paper and is easily borne than the lower stresses which occur in and near the fillers and are tangential to the papers. It was found in the 3 core 33 kV. Cables that deterioration began in the fillers and wormings, and not at the point of the maximum stress on the conductors; the H-type cable was designed to avoid these tangential stresses and solved at once the problem of the 3 core 33 kV. cable.

Inductance of Cables

The methods of calculating the inductance of overhead lines may be applied to underground cables, but the results will be in error because of the skin and proximity effects and the effect of the sheath. In low voltage cables the conductor spacings are small compared with the conductor diameters, so that the effects will not be negligible. It is then best to measure the inductances, if they are required, as calculation will be very laborious and inaccurate.


In high voltage cables the skin and proximity effects are negligible because of the increased thickness of insulation. In such cables the separate cores are often sheathed, or surrounded by metallized (H) paper which is connected to sheath. The sheaths have mutuals inductance to the conductors and influence considerably the resistance and inductance of the cores to neutral; the effects of the sheath will now be considered.

Sheath Effects


The currents induced in the sheaths are two kinds: *sheath eddies*, whose paths lie in the sheath of a single cable and which flow even when the sheaths are isolated from each other, and *sheath circuit eddies*, whose paths lie in the sheaths of separate cables and flow only when the sheaths are bonded.

Fig. 97 shows the formation of sheath eddies in the case of two single core cables with separate and insulated lead sheaths. The conductor currents I produce a flux downwards through the sheath section ABCD. When I and the flux increase there is a sheath eddy round ABCD from A to B to C to D to A. The sheath eddy at A' is outwards to B', along the outside of the sheath into the paper and back again inside the sheath to A'. The loss due to sheath eddies is a maximum when the cores are as close as possible to one another, but in practical cases it is never more than a few per cent of the copper losses and can be neglected. A much more important effect is the voltage induced in the sheaths by the currents I .

Section 3 – Underground Cables



Suppose that the sheaths are replaced by thin cylinders of radius $\frac{1}{2}D$ and we consider a circuit ABCD shown in Fig.98 The flux through ABCD is seen to be



$$0.41 \log h D \frac{1}{2}D \text{ per cm. length,}$$

where d is conductor spacing. The induced e.m.f. is thus

$$4 I \log h d / \frac{1}{2}D \cdot 10^{-9} \text{ volts per cm. length}$$

This is e.m.f. along both sheaths and we may consider that each sheath has an induced e.m.f. of half this, viz.

$$E_2 = 2 I \log h d \frac{1}{2}D \cdot 10^{-9} \text{ volts per cm. length.}$$

$$IX_m = I M, \tag{49}$$

Where M is the mutual inductance between the core and sheath and is

$$2 \log h d \frac{1}{2}D \text{ e.m. units per cm.}$$

Or $M = 0.741 \log d \frac{1}{2}D \text{ mH. Per mile.} \tag{50}$

By equation (18a) in chapter IV. It is clear from the work in chapter IV and the equation (24) given there that formulae (49) and (50) just given hold for a three phase symmetrical system with spacing d .

Section 3 – Underground Cables

Example. Find the induced sheath voltage per mile of a symmetrical three phase system with conductor spacing 15 cm and sheath diameters 5.5 cm. The current is 250 A.

$$M = 0.741 \log \frac{15}{2.75} = 0.545 \text{ mH. Per mile.}$$

$$E_2 = 250 \times 2 \times 50 \times 0.545 \times 10^{-3}$$

$$\underline{\underline{42.8 \text{ V. per mile.}}}$$

If the sheaths are bonded at one end, the voltage between them at the other is

$$\sqrt{3} \times 42.8 = \underline{\underline{74.3 \text{ V. per mile}}}$$

Currents in Bonded Sheaths

It is seen from the preceding example that large voltages are induced in the sheaths if they are open circuited, and it is very probable that arcing will occur between them. It is therefore standard practice to bond the sheaths at both ends so as to avoid the high voltages. The impedance of the sheath current path is due to the sheath resistance R_s and the sheath self inductance, which is equal to M . Thus if the sheaths are bonded the sheath current is

$$I_{sh} = \frac{E_{sh}}{\sqrt{R_s^2 + X_m^2}} = I \frac{X_m}{\sqrt{R_s^2 + X_m^2}} \quad 51$$

The magnitude of the sheath current is independent of the distance between the bonds, for X_m and R_s are both proportional to the length. The sheath losses per phase are

$$R_s I_{sh}^2 = I^2 X_m^2 R_s / R_s^2 + X_m^2 \quad 52$$

So that the effective resistance per phase is the conductor resistance plus

$$X_m^2 R_s / R_s^2 + X_m^2 \quad 53$$

The ratio of sheath losses to copper losses is

$$\frac{I^2 X_m^2 R_s}{R_s^2 + X_m^2} = I^2 R \frac{X_m^2 R}{R R_s^2 + X_m^2}$$

Where R is the resistance of the conductor. With large conductors and close spacing this ratio is approximately equal to

$$X_m^2 R_s / R R_s^2 = X_m^2 / R R_2,$$

As R_s^2 is large compared with X_m^2 . If conductor is made larger, R and R_2 diminish whilst X_m remains fairly constant, so that the ratio increases rapidly. Thus for 66kV. cables at a spacing of 6 in., the sheath losses exceed the conductor losses for conductor sections above 0.85 in^2

Section 3 – Underground Cables




FIG. 99. ELECTRICAL EQUIVALENT OF SHEATH CIRCUIT

The effect of the sheath on the inductance of the cable may be found in the following way. The conductor has resistance R and self inductance L , where

$$L = 2 \log h d / r$$

from the work in Chapter IV. This inductance is coupled to the sheath circuit by a mutual inductance M , where

$$M = 2 \log h d / \frac{1}{2} D .$$

The sheath circuit itself has a resistance R_2 and self inductance M , so that the cable impedance is represented by the network of Fig.99. By the well known theorem of the equivalent network of the transformer (see page 471) the arrangement can be replaced by that shown in Fig.100.

$$L = M = 2 \log h d / r \quad \log h d / \frac{1}{2} D$$

$$2 \log h \frac{1}{2} D / r = L_c$$

Which is the leakage inductance of the core to the sheath. The total impedance of the conductor is thus

$$R + j L_c \frac{R_s \cdot j M}{R_s - j M}$$

$$R + j L_c \frac{R_s \cdot j M R_s - j M}{R_s^2 - M^2}$$

$$R + \frac{R_s^2 M^2}{R_s^2 - M^2} + j L_c \frac{MR_s^2}{R_s^2 - M^2}$$

$$R + \frac{R_s X_m^2}{R_s^2 - X_m^2} + j L_c \frac{MR_s^2}{R_s^2 - X_m^2}$$

The resistance is thus

$$R + R_s X_m^2 / R_s^2 - X^2$$

Which we have already found in equation (53), whilst the inductance is

$$L_c = MR_s^2 / R_s^2 - X_m^2 = L + M = MR_s^2 / R_s^2 - X_m^2$$

Section 3 – Underground Cables

$$L = MX_m^2 / R_s^2 - X_m^2$$


The decrease in inductance due to the sheath is thus

$$MX_m^2 / R_s^2 - X_m^2$$

The resistivity of lead is 23×10^{-6} ohms per cm. cube at $30^\circ C$.

Given the thickness of the sheath and its diameter, R_s can be calculated and thence the resistance and inductance of the cable.

In order to avoid large sheath currents, which lower the current-carrying capacity of cables, sheaths are sometimes cross-bonded.



The sheath conductor 1 is connected to that of conductor 2 and then to that of conductor 3 at equidistant points, and the induced sheath voltage is

$$I_1 wM - I_2 wM - I_3 wM = I_1 - I_2 - I_3 wM = 0.$$

(See Fig. 82.)

There will be no sheath current and yet the sheath voltage will never be greater than IwM at any point. A combination of cross-bonding except at every third joint, which is solidly bonded and of simple reactances reduces sheath losses and voltages and also prevents the generation of third harmonic currents.

Example. Find the resistance, inductance and capacitance per mile of a 3 core belted type cable, in which the conductors are circular 37/0 093, conductor insulation is 0.17 in., and the dielectric constant is 3.6.

From tables it is found that the resistance is 0.099333 per 1000 yd. at $60^\circ F$. The resistance per mile at $55^\circ C$., which is taken as a normal working temperature, being $40^\circ C$. above the average temperature of $15^\circ C$., is

$$R = 0.09933 \times 1.760 \times 1.004 \times 39.5 = 0.202 \text{ .,}$$

Stranding having been allowed for in the tables.

The formula for overhead lines is used in this case for inductance, and no great accuracy can be claimed.

$$L = 0.085 \times 0.741 \log d/r \text{ mH. Per mile.}$$

Here $r = 0.325$ in. and $d = 2.0325 - 0.20 = 1.05$ in., so that

Section 3 – Underground Cables

$$L = 0.085 + 0.741 \log \frac{1.05}{0.325} = 0.462 \text{ mH. Per mile.}$$

The capacitance is given by equation (46)

$$C = \frac{0.048}{\log \frac{1.05}{0.325}} = 0.52 \frac{t^2}{r^2} \text{ } \mu F . \text{ Per mile}$$

Where d here is the conductor diameter, not the spacing.

$$C = \frac{0.048 \cdot 3.6}{\log \frac{1.05}{0.325}} = 0.52 \cdot 0.85^2$$

$$\frac{0.048 \cdot 3.6}{\log 2.57} = \underline{0.420} \text{ } \mu F . \text{ per mile}$$

Example. Find the resistance, inductance and capacitance of a three phase symmetrical arrangement of 66kV. single core cables, 61/0.103 (nominal 0.5in.²), insulation thickness 0.65in., sheath thickness 0.15in., serving thickness 0.15in., serving thickness 0.15in., dielectric constant 3.6; the cables are laid touching one another and the sheaths are bonded.

From the tables the resistance is 0.04913 . Per 1000 yd at 60⁵F., so that at 55⁵C, the resistance per mile per phase is

$$R = 0.04913 \cdot 1.760 = 0.08647$$

$$= 0.1005$$

$$C = \frac{0.0388}{\log(D/d)} \text{ } \mu F \text{ per mile.}$$

Here $d = 9 \cdot 0.103 = 0.927$ in.,

And $D = 0.927 + 2 \cdot 0.65 = 2.227$.

$$C = \frac{0.0388 \cdot 3.6}{\log 2.40} = \underline{0.378} \text{ } \mu F \text{ per mile.}$$

We will assume a sheath temperature of 30⁵C.

$$R_s = \frac{23 \cdot 2 \cdot 10^6 \cdot 5280 \cdot 12 \cdot 2 \cdot 54}{1 \cdot 263^2 \cdot 1 \cdot 113^2 \cdot 2 \cdot 54^2}$$

$$= 0.516 \text{ per mile}$$

The spacing is 2.227 + 4 \cdot 0.15 = 2.827in., so that

$$M = 0.741 \log \frac{2.827}{1.115}$$

$$= 0.297 \text{ mH. per mile}$$

Section 3 – Underground Cables

$$X_m = 2 \cdot 50 \cdot 0 \cdot 297 \cdot 10^{-3} \cdot 0 \cdot 0931 \text{ per mile}$$

The effective resistance per mile is therefore

$$0 \cdot 1005 \frac{0 \cdot 516 \cdot 0 \cdot 0931^2}{0 \cdot 516^2 + 0 \cdot 0931^2}$$

$$0 \cdot 1005 \cdot 0 \cdot 0167 = 0 \cdot 1172 \text{ ohms}$$

The sheath loss is 0.0167 / 0.1005 = 16.6 per cent of the conductor loss.




FIG. 101. V.T.B. CURVES OF WELL AND BADLY IMPREGNATED PAPER

The inductance is

$$L_C = \frac{MR_s^2}{R_s^2} X_m^2 = L \frac{MX_m^2}{R_s^2} X_m^2$$

$$L = 0 \cdot 031M$$

$$L = 0 \cdot 741 \log 2 \cdot 827 / 0 \cdot 583 \text{ mH. per mile}$$

Actually the inductance is slightly lower by 0.0092 mH. due to the sheath bonding, so that L is 0.574 mH. per mile.

Breakdown Voltage and Mechanism of Breakdown

The voltage required to break down a certain insulation depends upon many factors such as time of application, shape of electrodes, temperature, pressure, the presence of moisture or gaseous spaces. The dependence of voltage on time is very important, and tests are made to determine the curve relating the voltage required to break down a certain insulation depends upon many factors such as time of application, shape of electrodes, temperature, pressure, the presence of moisture or gaseous spaces. The dependence of the voltage on time is very important and tests are made to determine the curve relating the voltage and time of application; such a curve is called a V.T.B. curve, i.e. voltage-time-breakdown curve. Curve A, shows the V.T.B. curve of 1mm. thickness of very well impregnated paper. The short time breakdown voltage is about 45 kV. (stress 45 kV. per m.), but the breakdown voltage reach a steady value of 32kV. in about 5 hours. If a voltage of 31.5kV. is applied the insulation never break down. It is of the greatest advantage if asymptotic value (i.e. final value) is

Section 3 – Underground Cables

reached in a short time, for then decisive tests may be short; presumably also the cable is stable and likely to give long service. Curve *B* shows the V.T.B. curve of the badly impregnated paper which contains air spaces. The short time breakdown voltage is not much less than for the good dielectric, but the asymptotic value is much lower and is not reached even in 100 hours. With slow deterioration of this kind it is difficult to say what voltage the dielectric can maintain indefinitely.

Moisture has the same effect as gaseous voids on V.T.B. curve. A carefully impregnated cable will initially contain no voids and so it will have V.T.B. curve like a curve *A*. When however, this cable is subjected to fluctuating loads, the heating causes the oil to expand and sheath is stretched; when the cable cools, the sheath does not recover and small voids are formed by cavitation. After a number of fluctuations the voids may be such that the V.T.B. curve is like curve *B*, and eventual failure will occur if the applied voltage is greater than the new asymptotic value. In order to ascertain whether the cable V.T.B. curve is stable, the cable is subjected to the working voltage or a higher voltage whilst the cable is alternately heated and allowed to cool. Such a test is called a *stability test* and is applied to all types of high voltage cables.

The formation of voids is accompanied by ionization by collision and a rise of the power factor of the cable.

The voids are eliminated in the oil filled and pressure cables, whilst the gas cable prevents ionization by the application of hydrostatic pressure. All these cables have good V.T.B. curves.

There are two ways in which breakdown of cables usually occurs.

One way is by a progressive coring and tracking, which always starts from the conductor or sheath, and ultimately bridges the electrodes. Another way is by thermal instability; this occurs when the power factor increases so rapidly with rise of temperature, that a small rise of temperature increases the dielectric losses by a greater amount than can be conducted away. This method will be considered later in detail. A marked difference between the methods of breakdown is that coring, once it commences, will continue until the cable breaks down, although the time may be considerable for the complete action. In thermal instability, however, no damage is done until just before breakdown, so that if the load is released before breakdown the cable will not have suffered any permanent change. A very common occurrence is for coring to start and then introduce thermal instability at the centre of coring.

Thermal Characteristics of Cables

Maximum current capacity. There are several reasons why cables should not be run too hot; differential expansion may create voids with resulting ionization; the expansion of the oil may burst the sheath; the oil may lose its viscosity and drain away from higher levels; thermal instability may arise due to the rapid increase of dielectric losses with temperature. The last phenomenon is not likely to occur

Section 3 – Underground Cables

in cables up to 33 kV., but it is being reached in cables above kV. The calculation is difficult and will not be given.

In order not to incur the other harmful effects, a maximum conductor temperature of 65°C has been adopted for cables impregnated with viscous oils in this country. The maximum current that a cable can carry with a conductor temperature of 65°C is found in the following way.

Assume that the dielectric and sheath losses are negligible compared with the conductor losses, which are given by nRI^2 , where R is the conductor resistance at 65°C., and n the number of phases. Let S be the thermal resistance of the cable, i.e. between the combined conductors and sheath, and G the thermal resistance from sheath to earth surface. The heat has to pass through the two thermal paths in series, so that the temperature difference between the conductors and ground is

$$nRI^2 S + G = 65 - 0 \quad (56)$$

Where 0 is the ambient ground temperature. We may take $0 = 18$, so that

$$nRI^2 S + G = 43$$

Giving
$$I = \sqrt{43/nRS + G} \quad (57)$$

If the dielectric and sheath losses are not negligible, we can replace equation (56) by

$$65 - 0 = nRI^2 S + G + WS + G + R_a I^2 G,$$

Where W is the dielectric losses and is conservatively taken as occurring all at the conductor, and R_a is an equivalent resistance due to sheath losses. Then the current capacity is

$$I = \sqrt{\frac{65 - 0 - WS - G}{nRS + G + R_a G}} \quad (58)$$

Thermal Resistance

The unit is the thermal ohm and is that thermal resistance which requires a temperature difference of 1°C, to produce a heat flow of one watt (i.e. one joule per second). If the thermal resistivity of a cable dielectric is K , the thermal resistance of a single core cable is

$$S_1 = K/2 \log_e D/d \text{ thermal ohms per cm. length of cable} \quad (59)$$

K is taken as 750 for cables up to and including 2200 volts, and 550 for cables above 2200 volts.

The thermal resistance of a 3 core belted type cable is given by the empirical formula.

$$S_1 = \frac{K}{6n} (0.85 + \frac{0.2t}{T}) \log_e h + 1 + \frac{2T}{d} + 4 + 15 + \frac{11t}{T} \quad (60)$$

Section 3 – Underground Cables

The thermal resistance of the ground is

$$G = \frac{g^1}{2} \log \frac{h}{2h/R_2} \quad (61)$$

Where g^1 is the resistivity, h the depth of cable below ground and R_2 the overall radius of the cable. It is found that the thermal resistivity g as measured in the laboratory is too great for use in the above formula by about 50 per cent, so that $g^1 = \frac{2}{3}g$ and the thermal resistance is given by

$$G = \frac{\frac{2}{3}g}{2} \log \frac{h}{2h/R_2} = \frac{g}{3} \log \frac{h}{2h/R_2} \quad (62)$$

In practice g varies from 120 to 800 or 1000 depending on the soil and its moistness.

Example. Find the maximum current that a 3 core, 11kV, 0.25 in.^2 cable can carry; $t = 0.06 \text{ in.}$, $T = 0.15 \text{ in.}$, $K = 550$, buried 3 ft. deep, $g = 180$, ambient temperature 15°C .

$$S_1 = \frac{550}{6} = 0.85 \quad \frac{0.012}{0.15} \log \frac{h}{1} = \frac{0.42}{0.65} = 4.15 \quad \frac{0.066}{0.15}$$

33.2 thermal ohms per cm.

The lead sheath has a very small thermal resistance, but there is a serving of thickness 0.31 in. of $K = 300$. This has a thermal resistance of

$$S_2 = \frac{300}{2} \log \frac{h}{1.54/1.22} = 11 \text{ thermal ohms,}$$

As the external radius of lead sheath is 1.22 in. , and that of the serving of is 1.54 in. The ground resistance is

$$G = \frac{180}{3} \log \frac{h}{\frac{2.36}{1.54}} = 73.4 \text{ thermal ohms.}$$

$$S = G + S_1 + S_2 = 117.6$$

From tables, allowing for coring and stranding and temperature rise, $R = 1.33 \times 10^{-6}$. Per cm.

$$I = \sqrt{\frac{65 \times 15}{3 \times 1.33 \times 10^{-6} \times 117.6}}$$

$$= \underline{\underline{326 \text{ A.}}}$$

3.6 Describe techniques used to install cable and associate equipments





Ducts

To expand future installation

Iron / reinforced concrete/ steel pipe/ wood / fibre/ plastic

Section 3 – Underground Cables

Fig 6.4

Duct type	Cost of construction	Ability to radiate heat	Cost of support
	Expensive	Best	Best
	Moderate	Very good	Very good
	Moderate	Very good	Good
	Cheapest	Very poor	Very poor

Service boxes

Secondary mains are installed in ducts buried at shallower depths than those carrying primary conductor. Precast reinforce concrete is used.

Section 3 – Underground Cables


Cable manhole

Rectangular for straight line conduit construction.
Square for accommodating from 4 directions.

Fig 6.5

Transformer Manholes

Transformer manholes are designed to contain transformers and other equipments for radial or network system.



Design loading on manhole

$$\text{Concentrated load} = \frac{\text{Wheel load (1 + \% Impact / 100)}}{\text{Wheel Area}}$$

Problem

Wheel load 9576 Kg , imposed 50% for heavily travelled street under which truck traffic may be concrete. Wheel area is 15.5 cm x 30.5 cm

Calculate concentrate load on manhole cover.

$$\text{Concentrated load} = \frac{\text{Wheel load (1 + \% Impact / 100)}}{\text{Wheel Area}}$$

Section 3 – Underground Cables

Wheel Area

$$\begin{aligned} & 9576 (1 + 50 / 100) \\ = & \frac{\text{-----}}{15.5 \times 30.5 \times 10^{-4}} \\ & 14364 \times 10^4 \\ = & \frac{\text{-----}}{472.75} \\ = & 303839 \text{ Kg / m}^2 \end{aligned}$$

Roofs

Manhole roofs are designed as a series of structural steel beams or rail or reinforced concrete with extra reinforcement or structural steel to support manhole frames

Wall

Manhole wall designs are based on the horizontal component of the effect of both line and dead loads acting on the walls.

Floors

In the design of manhole, floors , the load bearing power of the soil and the height of the water tube play an important part. The soil must support the weight of the manhole structure its contents and any imposed surface level loads.

Frame / covers

- Made of cast iron/ malleable iron/ steel
- Are designed to withstand the loadings of traffic
- May be made of reinforce concrete


Ventilation

- Principal heat source is power loss in windings
- Tube ventilation is natural ventilation
- Large conductors are put in separate ducts

Section 3 – Underground Cables

XLPLE/ Lead/ Plastic insulation are used.

Cross section of joint




Underground Equipments

Transformers, oil filled cutouts and oil switches for use underground are hermetically sealed so as to be water proofed

Such submersible equipment is usually of welded construction. Wiping sleeves are welded or brazed directly to the tank or terminal chamber to which cable sheaths are attached.

Barriers in the conductors prevent the equipment oil from being siphoned into the cables.

Section 3 – Underground Cables



Section 3 – Underground Cables

Transformer Manholes

Transformer manholes are designed to contain transformers and other equipment required for radial or network systems. Their dimensions depend on the location and the equipment they are to contain. Standard transformer manholes





FIG. 6-2 Effect of radius of curvature of conduit on pulling tension (applicable to a conduit consisting of one continuous curved section). (From *EEI Underground Systems Reference Book*.)

Section 3 – Underground Cables

3.7 Recall cable testing techniques and methods used to find the location of cable fault

What method or combination of methods is best for locating underground cable faults?

Finding the location of an underground cable fault doesn't have to be like finding a needle in a haystack. There are many locating methods, coupled with new detection technologies, that make this task much easier and less time consuming. However, you should understand that there is no single method or combination of methods that is "best." Your selection of the appropriate method for the situation and your skill in employing that method are the keys to safely and efficiently locating cable faults without damaging the cable. Let's see what's involved.

Basic cable fault locating methods. There are two basic methods of locating an underground cable fault.

Sectionalizing This procedure, as shown in Fig. 1, risks reducing cable reliability, because it depends on physically cutting and splicing the cable. Dividing the cable into successively smaller sections will enable you to narrow down the search for a fault.

For example, on a 500-ft length, you would cut the cable into two 250-ft sections and measure both ways with an ohmmeter or high-voltage insulation resistance (IR) tester. The defective section shows a lower IR than the good section. You would repeat this "divide and conquer" procedure until reaching a short enough section of cable to allow repair of the fault. This laborious procedure normally involves repeated cable excavation.

Thumping When you supply a high voltage to a faulted cable, the resulting high-current arc makes a noise loud enough for you to hear above ground. While this method eliminates the sectionalizing method's cutting and splicing, it has its own drawback. Thumping requires a current on the order of tens of thousands of amps at voltages as high as 25kV to make an underground noise loud enough for you to hear above ground.

The heating from this high current often causes some degradation of the cable insulation. If you're proficient in the thumping method, you can limit damage by reducing the power sent through the cable to the minimum required to conduct the test. While moderate testing may produce no noticeable effects, sustained or frequent testing can cause the cable insulation to degrade to an unacceptable condition. Many cable fault locating experts accept some insulation damage for two reasons: First, when thumping time is minimal, so is the cable insulation damage; secondly, there is no existing technology (or combination of technologies) that can entirely replace thumping.

Newer fault locating technologies. There are some relatively new methods of locating cable faults that use rather sophisticated technology.

Section 3 – Underground Cables

Time Domain Reflectometry (TDR) The TDR sends a low-energy signal through the cable, causing no insulation degradation. A theoretically perfect cable returns that signal in a known time and in a known profile. Impedance variations in a "real-world" cable alter both the time and profile, which the TDR screen or printout graphically represents. This graph (called a "trace") gives the user approximate distances to "landmarks" such as opens, splices, Y-taps, transformers, and water ingress.

One weakness of TDR is that it does not pinpoint faults. TDR is accurate to within about 1% of testing range. Sometimes, this information alone is sufficient. Other times, it only serves to allow more precise thumping. Nevertheless, this increased precision can produce substantial savings in cost and time. A typical result is "438 ft 5 10 ft." If the fault is located at 440 ft, you only need to thump the 20-ft distance from 428 ft to 448 ft, instead of the entire 440 ft.

Another weakness of TDR is that reflectometers cannot see faults-to-ground with resistances much greater than 200 ohms. So, in the case of a "bleeding fault" rather than a short or near-short, TDR is blind.

High-voltage radar methods There are three basic methods for high-voltage radar, ranked here in order of popularity, with the most popular described first: arc reflection, surge pulse reflection, and voltage pulse reflection. The arc reflection method, as shown in Fig. 2 (on page 64N), uses a TDR with a filter and thumper. The filter limits both the surge current and voltage that can reach the cable under test, thus allowing minimal stress to the cable. Arc reflection provides an approximate distance to the fault (when there is an ionizing, clean arc produced at the fault and the TDR in use is powerful enough to sense and display a reflected pulse).

The surge pulse reflection method, as shown in Fig. 3, uses a current coupler and a storage oscilloscope with a thumper. The advantage of this method is its superior ability to ionize difficult and distant faults. Its disadvantages are that its high output surge can damage the cable, and interpreting the trace requires more skill than with the other methods.

The voltage pulse reflection method, as shown in Fig. 4 (on page 64P), uses a voltage coupler and an analyzer with a dielectric test set or proof tester. This method provides a way to find faults that occur at voltages above the maximum thumper voltage of 25kV.

The open neutral and cable fault locating Bare neutrals corrode quickly in contaminated soil that holds corrosive chemicals or excessive moisture. Open neutrals often thwart the effectiveness of high-voltage radar. Beware: In the existence of an open neutral, nearby telephone or CATV cables will complete the circuit.

One test to detect an open neutral requires shorting a known good conductor to a suspect neutral, as shown in Fig. 5 (on page 64P), then measuring the resistance with an ohmmeter. If the reading is 10 ohms or higher, you can suspect an open neutral. Remember, other objects can complete the circuit.

Another test uses a TDR. The trace on an open neutral will show a much flatter

Section 3 – Underground Cables

positive pulse than it will for an open conductor. On lower-end TDRs, this pulse may not be visible. When the conductor is completely open, the trace will almost never include a reflected pulse indicating the end of the cable.

If the TDR displays an open neutral, then an AC-voltage gradient test set can locate the break in a direct-buried unjacked cable. The test set's transmitter forces AC current to flow through the neutral, and the conducting earth surrounding the damaged section acts as an electrical jumper. An A-frame, as shown in Fig. 6 (on page 64P), then detects the resulting voltage gradient in the soil.



) [BI Communications TX2001 Graphical TDR Cable Fault Locator](#)

Made By BI Communications

The BI Communications TX2001 is a professional Time Domain Reflectometer and Toner designed to detect and locate faults on copper communication cables up to a distance of 3000m (10,000ft). Advanced signal processing techniques enable the TX2001 to find opens, short circuits, splices, taps, water ingress and other more elusive impedance mismatches. A built in oscillator also provides a tone for pair tracing and identification

Section 3 – Underground Cables



Megger®

Cable (Fault) Locators, TDRs and Cable Height Meters

Whether locating cable faults or testing the integrity of communication, power, or control cables, TDRs and Megger Cable Fault Locators provide fast and accurate results. Each unit is a safe, low-voltage tester that can be used on virtually all cable types, whatever their power rating.



Computerware UK, Europe's largest distributor of light pens is now expanding with BI Communications Test and Measurement products to offer a new range of [Time Domain Reflectometers](#) and [Cable Fault Locators](#).

These are the smallest graphical time domain reflectometers and cable fault locators in the world and include the [TX2001](#) - the **lowest cost** time domain reflectometer in its class.

Computerware UK also supply the [TX2002](#) and [TX2003](#) graphical time domain reflector and cable fault locator with 1% accuracy, the [FaultCaster](#) digital time domain reflectometer and the low cost [LanCaster](#) structured cable fault locator and troubleshooter incorporating EDT™ End Discrimination Technology.

The Computerware UK range of time domain reflectometers and cable fault locators are suitable for use by all communications engineers and technicians, telecom fault teams and linesmen, and contractors to the communication industries. More broadly, target end users include Telecom Companies (RBOC's, CLEC's, PTT's, etc.), Cable Television (CATV) and Cable Internet Service

Section 3 – Underground Cables

Providers, as well as Government and Military organisations. The FaultCaster is also aimed at Network Installers and general electrical Contractors.

Standardized VDE-switch-on procedures for operating high voltage test sets:

1. Ready for operation
2. Ready to switch on

Application

As the supply of electrical energy is getting more and more important for our society, it is necessary to make sure that power supply system works without any problems.

Cables are frequently used for the distribution of the electrical energy. Although the cables are highly developed, there are sometimes malfunctions in the cable system. To keep the consequential damages as small as possible, trained staff and efficient equipment is needed.

BAUR cable fault location instruments and systems are applicable to all types of cables ranging from 1 kV to 500 kV and all types of cable faults such as

Short circuit faults

Cable cuts

Resistive faults

Intermittent faults

Sheath faults

Water trees

Partial discharges

We distinguish between two types of cable fault location:

Pre-location

Section 3 – Underground Cables

Section 4- Voltage Regulation and Associate Equipments

4.1 Recall Terminology used in relation to voltage profile

Voltage regulation

The voltage regulation is defined as the percentage rise in voltage at receiving end when full load is thrown off, the sending end voltage is unaltered.

$$\text{Regulation} = \frac{E_s - E_r}{E_r} \times 100 \%$$
$$= \frac{I R \cos \phi_r + I X \sin \phi_r}{E_r}$$

Off load tap changer

The usual tapplings on a transformer are 2 ½ percent giving + - 2 ½ percent and + - 5 percent of the nominal voltage. However, the tapplings may all be on the minus side.

On load tap changer

On load tap changer is a transformer which is provided with equipment for changing the voltage ratio under load. The essential feature is that there must be no break in the winding circuit whilst the selector switches pass from one tapping point to the next. This requirement inevitably means that for a short period there must be connection between two adjacent tapplings at the same time and means must be provided to prevent the flow of a heavy short-circuit current.

Booster Transformer

Booster transformer is a separate transformer which is used to inject a variable voltage into a circuit for regulating purpose. Such an application could be made where it is desired to obtain additional voltage control under load on lines already existent and where new transformers are not to be purchased.

Quadrature Boosters

Quadrature Boosters or phase angle control units inject a voltage with a major component at 90 degrees to the existing voltage.

Section 3 – Underground Cables

Section 4- Voltage Regulation and Associate Equipments

Induction and Moving Coil Regulators

Tap changing transformers of the “ off load “ or “ on load” and booster type transformers are the most commonly used voltage regulating equipments for distribution work.

Power loss

The power loss in the distribution feeders depends on the square of the current and the resistance of the feeder. His loss must be considered in relation to the capital cost involved in the erection of distribution line. As costs of raw materials, cost of generation, or cost of bulk electricity vary greatly this aspect can not be considered in detail. The basis of most cost calculations is known as Kelvin’s Law, which is as follows.

On the assumption that the variable portion of the cost of the conductor is proportional to its cross sectional area the most economical size is that one for which the annual cost of energy lost is equal to the cost of interest and depreciation

Voltage profile

Voltage profile charts are useful for studying pattern and to locate causes or reasons for abnormal voltage conditions

4.2 Describe the reasons effects and limitation of voltage variation

Voltage control

All modern transmission systems with the exception of the constant current system, operate at a constant voltage . It is essential for the satisfactory operation of the consumer’s apparatus that the vltage be kept within narrow limit.

Voltage drop

The conductor must operate so that when the maximum current is being conveyed. The fall in voltage along the line is within certain limit.

The value of fall in potential for a consumer’s overhead line must be taken into account when ensuring that the fall in potential from the consumer’s mains to any point on the installation .

Section 3 – Underground Cables

SAA Rule

Fall in the potential in the consumer's mains to any point on the installation does not exceed 5 % of the voltage at the commencement when full current is flowing.


Section 4- Voltage Regulation and Associate Equipments

Medium voltage – variation within 6% (Not exceed)

Higher voltage—Variation within 10% (Not exceed)

4.3 Recall methods used in controlling voltage level

The reactance and the resistance of the line must first be determined . The effects of transformers can be represented by adding to the series line impedance, the series impedance of the transformers. The equivalent electrical circuit of the line is drawn as follows.



From the above it will be seen that

$$E_s = \sqrt{OB^2 + BD^2}$$

Section 3 – Underground Cables

$$OB = E_r \cos \phi r + IR$$

$$BD = E_r \sin \phi r + IX$$

Section 4- Voltage Regulation and Associate Equipments

Therefore

$$E_s = \sqrt{(E_r \cos \phi r + IR)^2 + (E_r \sin \phi r + IX)^2}$$

Where

E_s = Sending end voltage

E_r = Receiving end voltage

Then

$$= E_r \sqrt{(\cos \phi r + IR / E_r)^2 + (\sin \phi r + IX / E_r)^2}$$

This form is more convenient because the quantity under the radical sign is in the order of unity.

$$E_s = E_r \sqrt{1 + 2 IR / E_r \cos \phi r + 2 IX / E_r \sin \phi r + I^2 (R^2 + X^2) / E_r^2}$$

The last term is usually negligible because the denominator E_r^2 is very big.

Thus

$$E_s = E_r \sqrt{1 + 2 IR / E_r \cos \phi r + 2 IX / E_r \sin \phi r}$$


$$= E_r \{ 1 + 2 IR / E_r \cos \phi r + 2 IX / E_r \sin \phi r \}^{1/2}$$

Using the binomial theorem this gives as a first approximation

$$E_s = E_r (1 + IR / E_r \cos \phi r + IX / E_r \sin \phi r)$$

OR

Section 3 – Underground Cables



Methods of voltage control

Three general methods are available for controlling the voltage at the end of a distribution feeder . They are

1. By controlling the sending end voltage
2. By controlling the receiving end voltage
3. By controlling the current in the line that is varying the power factor

Voltage control equipments

1. Off load tap changing transformer
2. On load tap changing transformer
3. Booster transformer
4. Moving coil regulator
5. Induction regulator


Off load tap changer

The usual tapplings on a transformer are 2 ½ percent giving + - 2 ½ percent and + - 5 percent of the nominal voltage. However , the tapplings may all be on the minus side.

Plus Tapping & Minus tapping

A plus tapping is one which introduces into the active part of the winding concerned a greater number of turns while a minus tapping is one which introduces fewer turns into the winding. The taps are usually located in the centre of the winding or near the neutral end away from line surges. They are arranged so as not appreciably to displace the electrical centres of the whole windings for any tap circuit, and also not to affect appreciably the reactance of any tap circuit.

Section 3 – Underground Cables




+/- 2 ½ % to +/- 5% of nominal voltage

Position	Connecting tap terminals	per cent of winding
A	1 to 2	100
B	2 to 3	97.5
C	3 to 4	95
D	4 to 5	92.5
E	5 to 6	90

On load tap changer

Section 3 – Underground Cables





Many transformers are provided with equipments for changing their voltage ratio under load. The essential feature is that there must be no break in the winding circuit whilst the selector switches pass from one tapping point to the next. This requirement inevitably means that for a short period there must be connection between two adjacent tappings at the same time and means must be provided to prevent the flow of a heavy short-circuit current. This is achieved either by the introduction of a current limiting resistor or a reactor. Each arrangement has its merits and both are in common use.

On the smaller tap changers, the current is broken by the selector switches themselves. On the larger sizes, however, where KVA per step exceeds about 20 kVA per step per phase, special switches are used. They are provided in a separate tank usually mounted below the selector switch tank.

While the operating mechanism for on load tap changers may be manual, it is usual for it to be motor operated, and in many cases to be fully automatic.

Section 3 – Underground Cables

Automatic Voltage Control



Main Circuit

E_s	sending end voltage
E_z	line voltage drop
E_R	receiving end voltage
R_L	line resistance
X_L	line reactance
I_L	load current

Control Circuit

e_t	voltage transformer output voltage
e_c	compensator voltage drop
e_v	regulating relay voltage
R_c	compensator resistance
X_c	compensator reactance
i_c	C.T. secondary current


Section 3 – Underground Cables

Booster transformer

A separate transformer may be used to inject a variable voltage into a circuit for regulating purpose.

Quadrature booster

Injects a voltage with a major component at 90 degree to the existing voltage.



Section 3 – Underground Cables

Section 4- Voltage Regulation and Associate Equipments

Induction and moving coil regulator

Tap changing transformers of the “off load” or “on load” and booster type transformers are the most commonly used voltage regulating equipment for distribution work. Other types of equipment which could be used are the induction regulator and the moving coil regulator. These , however, are usually more expensive and liable to be damaged under a system fault.

Induction regulator

This equipment may be used by itself or in conjunction with a transformer. It consists of a stator and rotor similar to those of a wound rotor induction motor. One winding is shunt connected on the system, the voltage of which is to be controlled, whilst the other winding is connected in series.

Depending upon the relative positions of stator and rotor, the shunt winding induces a voltage in the series winding that may be in phase with the system voltage, or up to 180 degrees out of phase. The effect is that the output voltage can be varied in magnitude between limits.

$$V \pm V_1$$


Where V is the input voltage, V_1 is the injected series voltage.

The normal three phase arrangement has the disadvantage that it introduces a phase shift between input and output voltages at all positions except full boost and full back.

This is of no consequence when used on an individual supply , but it produces its use on interconnected networks.

Φ output = $\Phi 1 + \Phi 2$ depending on the position of moving coil.

Section 3 – Underground Cables



$$V_2 = V \pm V_1$$

V = Input voltage

V_1 = Injected Series voltage

Fig 7.6

$$V_2 = V \pm V_1$$

$$V \pm V_1 = V_2$$

V = Input voltage

V_1 = Injected series voltage


Moving Coil Regulator

In the construction of a moving coil regulator, there are two pairs of closely coupled shunt and series coils A1, S1 and A2 S2 respectively shown in the figure.

The four coils are mounted on a common magnetic circuit. The moving coil M is short-circuited on itself and at its limits of travel surrounds one or other of pairs of fixed coils.

The shunt coils A1 and A2 are connected additively and the series coils S1 and S2 in opposition.

Section 3 – Underground Cables



Constant ratio distribution transformer

Constant ratio distribution transformers are transformers with no variation of the transformer ratios. For a light load, the zone transformer tap changer is set at 100 percent, while for a heavy load, the zone transformer gives a 10 percent boost.

It will be seen that with 10 percent boost the voltage for a heavy load is minus 6 percent.

For light load conditions with the zone transformer at 100 percent, the voltage is minus percent.

Note

Light load, zone transformer tap changer is set at 100%.

Heavy load, transformer gives 10% boost

Section 4- Voltage Regulation and Associate Equipments

Section 3 – Underground Cables

Variable ratio distribution transformer


Variable ratio distribution provides the voltage profile with combined zone transformer voltage boost of 10 percent variation of the far distribution transformer off load tap changer to 2 ½ percent boost. With this arrangement, for a heavy load, the voltage regulation is plus 5 percent and for light load, it is minus 1 ½ percent.

Note

Zone transformer 10% boost
Variation of far distribution transformer off-load
Tap changer to 2 ½ % boost.

Voltage regulation by control of current

While voltage control by means of tap changing transformers is the usual method for distribution work, mention must be made of the use of capacitors to a load and so changing the power factor. The load conditions without capacitors is shown in full lines.



Section 3 – Underground Cables

Section 4- Voltage Regulation and Associate Equipments

4.4 Draw voltage profile using calculation to determine % voltage drop for components within the distribution feeders.

Voltage profile

Voltage profile charts are useful for studying pattern and to locate causes or reasons for abnormal voltage conditions.


To make such a chart, a common voltage level is selected for the system and the circuit constants such as resistance and reactance are converted to this voltage by means of the formula.

$$R_2 = (E_1/E_2)^2 R_1$$

R_2 = Resistance referred to voltage E_2

R_1 = Resistance referred to voltage E_1

E_1 and E_2 are respective voltage levels.




Section 3 – Underground Cables

Voltage profile example

The simplified single line diagram of a distribution system is shown in the figure. It is desired to keep the voltage within + 6 % and -4% of the nominal voltage.

Consumers

- A, B --- Distribution transformer T1
- C, D---- Distribution transformer T2



Problem

An industrial consumer takes a load of 100KVA at 0.8 Power factor lagging . Calculate the voltage at the consumer terminal . Given that supply transformer is a half kilometre away and has a sending end voltage of 433 Volts and the conductor has resistance 0.238 Ω/ km and reactance of 0.296 Ω/ km.

$$\text{Line current} = \frac{100 \times 10^3}{\sqrt{3} \times 433} = 133 \text{ Amp}$$

$$\sqrt{3} \times 433$$

$$\begin{aligned} V \text{ drop} &= I (R \cos\Phi + X \sin \Phi) \\ &= 133 (0.119 \times 0.8 + 0.148 \times 0.6) \\ &= 133 (0.0952 + 0.0888) \\ &= 133 \times 0.184 = 24.5V \end{aligned}$$

Section 3 – Underground Cables


$$\text{Receiving end voltage} = \frac{433}{\sqrt{3}} - 24.5 = 225.5 \text{ V / Ph or } 390.5 \text{ V /line}$$

Section 4- Voltage Regulation and Associate Equipments

Problem

From the given graph, determine the minimum voltage rating required for the direct laid single core cable so that a voltage rating of 0.6/ 1 KV can be achieved when

- (a) 2 circuits are in each group with spacing of 0.6 m
- (b) 3 circuits exist in two touching groups.



(a)

$$\text{Phase to earth voltage} = \frac{0.6}{0.92} = 0.652 \text{ KV}$$

$$\text{Phase to phase voltage} = \frac{1}{0.92} = 1.087 \text{ KV}$$

Section 3 – Underground Cables

(b)

$$\text{Phase to earth voltage} = \frac{0.6}{0.66} = 0.91 \text{ KV}$$

$$\text{Phase to phase voltage} = \frac{1}{0.66} = 1.52 \text{ KV}$$

Section 4- Voltage Regulation and Associate Equipments

Problem

For the simplified single line diagram shown, draw the voltage profile for the following full load conditions

Full load system voltage at point A is 12.19 KV

Voltage drop in 11 KV supply is 212V

Voltage drop in 11 KV transformer is 318 V

Voltage drop in main is 2 V.

Voltage drop in sub-main is 10 V

Voltage drop in final sub circuit is 6 V.

Use 415 V as nominal load voltage.

Section 4- Voltage Regulation and Associate Equipments

Formula

$$\frac{V1}{V2} = \frac{\text{Voltage drop (1)}}{\text{Voltage drop (2)}}$$

Side	Voltage drop	Side	Voltage drop
11 KV line	12.19 KV	415 V	$\frac{11000}{415} = \frac{12.19 \times 10^3}{V2}$ $V2 = 459 \text{ V}$
11 KV line	212 V	415 V	

Section 3 – Underground Cables

Problem

A phase load of 200 KVA 50 Hz is to have its power factor improved from 0.75 to 0.9. Calculate the size of capacitor bank required if the supply voltage is 415V. Sketch the connection.

Use delta capacitor bank

$$\Phi 1 = \cos^{-1} 0.75 = 41$$

$$\Phi 2 = \cos^{-1} 0.9 = 26$$

$$Kw = 200 \times 0.75 = 151 \text{ Kvar}$$

$$\text{Kvar correction} = 151 (\tan 41 - \tan 26) = 65.2 \text{ Kvar}$$

$$X_c = \frac{V^2}{Kvar} = \frac{415^2}{65.2 / 3 \times 1000}$$

$$C = \frac{1}{2 \pi f X_c} = 100 \text{ micro farad}$$

Section 3 – Underground Cables

REVIEW QUESTIONS FOR SECTION 3 AND 4

Section 3 – Underground Cables

Review questions for Section 3

1. What are the most commonly used insulating materials used for cables? Describe briefly the one that is used in distribution cables.

2. Describe briefly the following terms:

(a) Conductor screening

(b) Insulation

(c) Sheath

(d) Pre-impregnated cable

Section 3 – Underground Cables

Section 3 – Underground Cables

Review questions for Section 3

(e) Mass-impregnated cable

(f) Drain cable

(g) Non-bleeding cable

(h) Bedding

(i) Armour

3. Sketch the construction of a belted cable as used on 11 kV feeders. State the limitation to this type of cable and how has this been overcome for cables used at higher voltages.

Section 3 – Underground Cables

Section 3

1.
 - polyvinyl chloride
 - cross-linked polyvinyl
 - ethylene propylene rubber
 - impregnated paper


The majority of cables used for distribution work are impregnated paper insulated cables with a lead or lead alloy sheath.

2. (a) Conductor screening is used to evenly distribute electrical stress in the surrounding insulation.

Section 3 – Underground Cables

- (b) This consists of layers of paper tapes built up to the required thickness with a gap between each turn to allow for movement of the papers during the bending of the cable.
- (c) Sheath is a protective covering of either extruded lead, lead alloy or aluminium to exclude moisture.
- (d) The paper tapes used for insulation are impregnated before application to the conductors.
- (e) The paper tapes are applied unimpregnated, the complete cable being subsequently dried and impregnated as a whole.
- (f) A mass impregnated cable from which the free impregnated compound is removed by draining at a temperature in excess of the maximum working temperature.
- (g) An impregnated cable which will not exude the impregnated material under working conditions.
- (h) A layer/layers of fibrous material usually permeated with waterproof compound applied to the cable beneath the armouring.
- (i) Galvanised steel wire or steel tapes wound over the bedding on the lead sheath to give mechanical protection to the cable.

3.



Belted construction tends to fail at about 22 kV due to tangential stress. To overcome this problem, screen cables are used.


Section 3 – Underground Cables

Review questions for Section 3

4. The voltage designation of a distribution cable is given as 6.35/11 kV. State the meaning of each term.
-
-
-
5. Describe the associated precautions in the installation of cables.
-
-
-
-
6. A 33 kV multicore lead sheathed cable has a minimum bending radius of 18D. State the meaning of this term.
-
-
-
7. Describe briefly the sheath phenomenon. Sketch the sheath eddies where two single core cables are carrying current.

Section 3 – Underground Cables

4. 6.35 - the rated power frequency voltage to earth is 6.35 kV
11 kV - the rated power frequency voltage between conductors is 11 kV.
5.
 - drums of cable must not be dropped
 - drum must always be rolled in the direction of the arrow
 - cables should be installed only when both cable and ambient temperature are above 0°C
 - suitable supports must be used
 - bending radii for paper insulated cable should be as large as possible
 - appropriate method must be used when pulling cables into ducts or trenches
6. 18D - the bending radii must be at least eighteen times the diameter of the overall diameter of the cable.
7. It is the induced electromotive forces in the sheaths of single core cables which might cause heavy current to flow.



8.
 - the thermal capacity of the cable
 - the depth of burial in the soil
 - the type of soil (eg. sand, clay)

Section 3 – Underground Cables

Review questions for Section 4

1. Describe briefly the causes of voltage variations

2. State the limit of voltage variation in a distribution system per AS 3000, Part 1 - the SAA Wiring Rules.

3. Describe briefly the effect of voltage variations.

4. State the three general methods of voltage control.

Section 3 – Underground Cables

Review questions for Section 4

5. List **five** voltage control devices used in distribution systems.

- _____
- _____
- _____
- _____
- _____

6. Describe the use of voltage profile charts.

REFERENCES

Main text book recommended for 7762AA Electrical Distribution

2832P Distribution and Utilization A

(Published by Department of Technical and Further Education-NSW)

Unit	Contents	Module/ Learning Outcomes
Unit 1 of 2832P	Design concept, character of plant, size and character of load, type of power supply to load, service requirement + 7762AA Module book	7762-AA Learning outcome 1
Unit 2 of 2832P	Transmission line construction Mechanical properties, overhead lines conductors, damper, fitting, insulator, OH line construction and maintenance regulations, sag etc +7762AA Module book	7762AA Learning outcome 2 + Some components of Learning outcome 3
Unit 3 of 2832P	Voltage regulation, control, transformer impedance+7762AA Module book	7762-AA Learning outcome 4

Section 3 – Underground Cables

Australian Standards

AS 1026, 1023, 1034, 1042,1078,1117,1158,1190,1202, 1220,1222,1243, 1284, 1359,1360,1469,1531,1675,1680,1746,1767,1768,1798,1824,1883,1930,1931, 2005,2006,2184,2209,2263,2264,2326,2374,2421,3000,3116,3274

Other text books

Text book	Learning Outcomes of 7762AA Module
Generation, Transmission and Utilization of Electrical Power By AT Starr	Supporting reference
Basic Training Manual 16-12 Electrical Trades-Cable, conduits, busbar	Some components of Learning outcome 3
Electrical Distribution Engineering (2 nd Ed) by Anthony j Pansini, The Fairmont Press Inc 1991	Support for Learning outcome 1,3
Electrical Power Distribution & Transmission by Luceson Faulkenberry & walter Coffey , Prentice Hall, 1996	Support for Learning outcome 2,
Electrical Power Transmission System-By R Robert Eata & Edward Cohen , Prentice Hall, 1972	Support for Learning outcome 1,2,
Site Surveying & Levelling By John Clancy + Internet downloaded article-Software package for line route survey + Transmission line mechanical design	Survey for transmission line construction site and route + contour map of Learning outcome 2 especially for Line Design Project
Electrical Power Transmission System-By R Robert Eata & Edward Cohen , Prentice Hall, 1972	

7762AA Electrical Distribution (1)

Module Teacher-- U Kyaw Naing (Joe) Delivery mode= 4 hrs per weeks x 9 weeks= 36 Hrs

Main text book recommended for 7762AA Electrical Distribution

**2832P Distribution and Utilization A
(Published by Department of Technical and Further Education-NSW)**

Unit	Contents	Module/ Learning Outcomes
Unit 1 of 2832P	Design concept, character of plant, size and character of load, type of power supply to load, service requirement + 7762AA Module book	7762-AA Learning outcome 1
Unit 2 of 2832P	Transmission line construction Mechanical properties, overhead lines conductors, damper, fitting, insulator, OH line construction and maintenance regulations, sag etc +7762AA Module book	7762AA Learning outcome 2 + Some components of Learning outcome 3
Unit 3 of 2832P	Voltage regulation, control, transformer impedance+7762AA Module book	7762-AA Learning outcome 4

Australian Standards-

AS 1026, 1023, 1034, 1042, 1078,1117,1158,1190,1202,1220,1222,1243,1284,1359, 1360,1469,1531,1675,1680,1746,1767,1768,1798,1824,1883,1930,1931,2005,2006,2184,2209,2263,2264,2326,2374,2421,3000,3116,3274

Other text books

Text book	Learning Outcomes of 7762AA Module
Generation, Transmission and Utilization of Electrical Power By AT Starr	Supporting reference
Basic Training Manual 16-12 Electrical Trades-Cable, conduits, busbar	Some components of Learning outcome 3
Electrical Distribution Engineering	Support for Learning outcome 1,3
Electrical Power Distribution & Transmission	Support for Learning outcome 2,
Electrical Power Transmission System-By R Robert Eata, Edward Cohen	Support for Learning outcome 1,2,
Site Surveying & Levelling By John Clancy + Internet downloaded article-Software package for line route survey + Transmission line mechanical design (Electrical Power Transmission System)	Survey for transmission line construction site and route + contour map of Learning outcome 2 especially for Line Design Project

Day (1)

Learning Outcome 1.1 Describe common system for electrical distribution


The electrical distribution system contains the following equipments.

1. Power generating equipments
2. Primary and secondary distribution systems including feeders, transformers, switch gears, protective equipments and stand by generating plant.
3. Motor drives, heaters, oven, associated wiring and control equipments
4. Lighting equipments, lighting wiring circuits
5. Electrical and electronic control, instrumentation systems
6. \Auxiliary systems
7. Special items such as welding, batteries, rectifiers, electro plating equipments, lifts, industrial trucks, air-conditioners
8. Communication equipments

9. Yard, roadway, protective lighting

Limit of Distribution

Figure 1.1



System of distribution

- Overhead distribution
- Underground distribution
- Combined overhead and underground distribution

Learning outcome 1.2 State their relative merit and voltage levels

Overhead lines

- Less expensive
- Extreme higher voltage
- Continual stresses
- Exposure to varying climate conditions
- Subject to mechanical wears/ corrosion
- Need to be periodically replaced

Higher spacing between conductors---- Higher current rating
----- Higher circuit inductance

Larger conductor sizes----- Higher load capacity
----- Higher expenses


Standard distribution voltages ASCI 1969

Standard voltages for 3 phase system are

415V (Voltage to neutral 240V)
11KV, 22KV, 33KV, 66KV

Learning outcome 1.3 Interpret the diagrams of distribution systems


Fig 1.2



Types of feeders


Radial feeder

Fig 1.3




Parallel Feeder

Fig 1.4



Ring main feeder
Fig 1.5




Substation busbar arrangement

For easy maintenance, means must be provided for isolators and circuit breakers. Earthing switch is to be provided for earthing of high voltage equipments.


Single busbar

Fig 1.6




Duplicate busbar

Fig 1.7




Sectionalize busbar system

Fig 1.8



Ring busbar

Fig 1.9



Learning outcome 1.4 Recall terminating pertaining the distribution system

Technical terms for electrical distribution

Reserve

Reserve is that portion of an electric utility's available generating capacity that is not producing electricity at a given time.


Spinning reserve

The generating capacity that is being driven at the proper speed to provide proper voltage but is not producing power. Spinning reserve can provide power to the system almost instantaneously if the system load is increased or a generator must be taken out of service.

Diversity

Load changes during a period of time.

Fig 1.10



Demand Factor

$$\text{Demand factor} = \frac{\text{Maximum load}}{\text{Total connected load}}$$

Consumer Factor

An individual consumer is not opt to be using all of the electrical devices that constitute his or her connected load at the same time.

Maximum demand

Actual load is used by consumer creates demand for electrical energy that varies from hour to hour over a period of time but reaches its greatest value of same point. This may be called the consumer's instantaneous demand.

Coincidence factor

The ratio of the maximum coincident total demand of a group of consumers to the sum of the maximum demands of each of the consumer

$$\text{Coincidence factor} = \frac{\text{Maximum coincident total demand of a group of consumers}}{\text{Sum of maximum demands of each of consumers}}$$

Utilization factor

The ratio of the maximum demand of a system to the rated capacity of the system.

$$\text{Utilization factor} = \frac{\text{Maximum demand of the system}}{\text{Rated capacity of the system}}$$

Diversity Factor

The ratio of the sum of maximum demands of each of the component loads to the maximum demand of the load as a whole.

$$\text{Diversity Factor} = \frac{\text{Sum of maximum demands of each of the component load}}{\text{Maximum demand of the load as whole}}$$

Some natures of industrial loads

Industrial Heating

Space heater, oven baking, heat treating, enamelling, furnace, steel brass, welders, high frequency heating devices.

Electric furnances draw the heavy current of less intermittently during the part of the heat treatment process and fairly lesser current for the rest.

Electronic loads

Radio, TV, Laser equipments, digital time and timing devices, rectifiers, oscillators, high frequency current production.

TUTORIAL EXERCISES

Q1.

Discuss the relative advantages and disadvantages of the following systems of electrical distribution.

- (a) radial feeder (b) Parallel feeder (c) Ring main feeder

Answer will be discussed in the class.

Q2.

A transformer supplies a group of four feeders which have individual maximum demands of 2.5, 2.4, 4.3 and 1.6 MVA. If the diversity factor of the system is 1.82, determine the maximum demand on the transformer.

Answer

$$\text{Diversity Factor} = \frac{\text{Sum of the individual maximum demands}}{\text{Maximum demand of the transformer.}}$$

$$2.5 + 2.4 + 4.3 + 1.6$$

$$1.82 = \frac{\text{Maximum demand of the transformer.}}$$

$$\text{Maximum demand of the transformer} = \frac{2.5 + 2.4 + 4.3 + 1.6}{1.82}$$

Maximum demand of the transformer = 5.93 MVA

Q3

A house has the following loads

- 5 lights each 80watts
- 1 stove 1000watts
- 5 power points each 100 watts
- 1 air-conditioner 1000 watts

If maximum demand is 2000 watt, calculate the demand factor.

Total connected load

<u>Equipment</u>		<u>Power</u>
Light	5 x 80 watts	400 watts
Stove		1000 watts
Power point	5 x 100 watts	500 watts
Air-conditioner		1000 Watts
Total connected load		2900 watts

Maximum demand

$$\begin{aligned} \text{Demand factor} &= \frac{\text{Maximum demand}}{\text{Total connected load}} \\ &= \frac{2000}{2900} \\ &= 0.68 \end{aligned}$$

Q4

State 3 classifications of distribution system

Answer

- Overhead distribution
- Underground distribution
- Combined overhead and underground distribution

Q5

State the standard voltages for 3 phase distribution system


Answer

415V, 11KV, 22KV, 33KV, 66KV

Q6

Sketch and describe a single wire earth return (SWER) system

Fig 1.11




Q7

Sketch three types of feeders that are commonly used for distribution system and describe the merit of each type

Answer

Radial feeder

Fig 1.12




Advantage-- Simple to build and maintain

Disadvantage-- Unreliable

Parallel Feeder

Fig 1.13




Advantage-- Reliability is improved over radial feeder

Disadvantage- Expensive and more complex to operate

Ring main feeder

Fig 1.14



Advantage-- Very reliable due to multiple sources and two ways of power flow


Disadvantage-- Very expensive and complicated to operate

Q8

Draw a block diagram of a power system from generation to utilisation and on it, show typical voltages

Answer

Fig 1.15



Q9


Sketch the following busbar arrangements

- Single busbar
- Sectionalise busbar
- Ring busbar
- Duplicate Busbar

Answer


Single busbar

Fig 1.16




Sectionalise busbar

Fig 1.17




Ring busbar

Fig 1.18



Duplicate busbar

Fig 1.19



Day 2

Learning outcome 2.1 Identify relevant components used in overhead line design

Conductor support

- Wood poles
- Steel poles
- Concrete poles
- Steel Towers

Typical Pole

Fig 2,1




Fig 2.2

Fig 2.3






Fig 2.4



More angle of deviation causes the bigger resultant force to remove the cable from the pin insulator. The angle of deviation should not be more than 10 degree for pin insulator.

Fig 2.5



Arcing Horns

In the case of insulator flash over due to lightning strike, the porcelain is often cracked or broken by the power arc that follows the initial discharge.

To protect against this trouble, arcing horn or rings are installed on many overhead systems. These operate so that the arc is taken up by the electrode and held at sufficient distance from the porcelain to prevent the damage by the heat of the arc.

Fig 2.6




Fig 2.7





Fig 2.8



These consist of a number of helically formed rods , the central portions of which are shaped to provide attachment of the conductor on line pin insulator.

Outcome 2.2 Outline relevant factors related to installation, maintenance of cross arms, pole types and choice of conductor sizes for commonly used configuration.


Conductor size

SAA Wiring Rule

Rule 3.13.2

Every conductor installed as aerial conductor shall have not less than seven strands and shall not be smaller than 4 mm² copper or 16mm² aluminium.


Fig 2.9



Total CSA = 4 mm² copper or 16mm² aluminium

The length of span of aerial conductor

Fig 2.10



Rule 3.13.9

The length of span of copper aerial conductor shall not exceed the values given below,

Type of conductor	Size mm ²	Maximum span (metres)
Bare hard drawn conductors	4	25
	6	30
	16 or over	60

Learning outcome 2.3 Determine mechanical limitations and physical dimensions of lines

Overhead line conductors

- Hard Drawn Copper Conductor
- All Aluminium Conductor (AAC)
- All Aluminium Alloy Conductor (AAAC)
- Aluminium Conductor Steel Reinforced (ACSR)
- Steel Conductor Galvanized (SC/GZ)
- Steel Conductor Aluminium Clad (SC/AC)

When steel is used as reinforcement or as a conductor or stay, it must be protected against corrosion.

Protection methods

- Galvanizing
- Coating with aluminium

Note

(1)An aluminium conductor steel reinforced should have some indication of the corrosion prevention method.

ACSR/GZ indicates that steel is galvanized

ACSR/AC indicates Aluminium Steel Core.

(2)Aluminium Conductors with Steel reinforcement provides the following advantages

- Most economical

- Shorter Span
- Not so frequently used for distribution work

Steel Conductor

- Very economical for rural distribution

Aluminium/ Aluminium Alloy Conductor

- Financial saving over copper
- Use in suburban work
- Span lengths are relatively short allowing for lower line tension

Conductor current rating

The current rating of overhead conductor depends on

- Heating
- Voltage drop
- Power losses

The current carrying capacity of an overhead conductor is limited by

- Annealing temperature of conductor
- The expansion due to temperature rise which causes a reduction of statutory clearance
- A temperature rise which might occasion injury to any insulation

Reasonably accepted values for the maximum operating temperature

75° C for continuous rating

100° C for one hour rating

Conditions affecting maximum conductor temperature

- Ambient temperature
- Wind velocity
- Heat absorbed from solar radiation
- Heat lost by convection
- Heat lost by radiation

Fault current carrying capacity

Fig 2.11

Voltage

The conductor must operate so that when the maximum current is being conveyed the fall in voltage along the line is within the certain limit.

The consumer's main to any point on the installation does not exceed five percent of the voltage at the commencement when full current is flowing

For medium voltages, the variation at the consumer's terminals should not exceed six percent and for higher voltages, the variations should not exceed ten percent.

Power loss

$$\text{Power Loss} \propto I^2 \propto \frac{1}{\text{Cross Sectional Area}}$$

Where Power loss means consumer power loss and line power loss.

Cross sectional area of the conductor determines the capital cost.

Materials for over head line conductors

Materials for overhead line conductor is determined by

- Electrical properties such as resistance, reactance, current carrying capacity of the conductor
- Mechanical properties such as strength and weight
- Price of the material relation to the return in the investment

Factors to be taken for installation of insulator

- Minimum mechanical strength
- Minimum impulse withstand voltage
- Minimum wet withstand voltage at power frequency
- Minimum puncture voltage at power frequency
- Minimum creepage distance between conductor tie and pin

The minimum failing load for any line pin insulator is 7KN.

Designation of insulator

Line Pin Insulator

First letter	S- Standard F-Foy type A-Aerodynamic
Next letter	LP- Line pin insulator First number- Nominal voltage (KV) Second number- Minimum creepage distance

Example

ALP 33/920

A- Aerodynamic type
LP- Line pin insulator
33- 33 KV
920- 920mm (Minimum) creepage distance

Example


SLP 11/180

S-Standard type
LP-Line pin insulator
11-11KV
180- 180 mm (Minimum) creepage distance

Shackle Insulator

Shackle insulators are used for terminating and angle construction on mainly on low voltage lines. The high voltage shackle insulators are now replaced by disc insulator.

Fig 2.12



SH LV1- Minimum failing load 9KN
 SH LV2- Minimum failing load 20KN

Disc Insulator

Disc insulators are used in high voltage lines for both intermediate and strain construction

- 1 disc- 11KV
- 2 disc- 22KV
- 3 disc- 33KV

Minimum failing loads of 44 KN and 66 KN

S-Suspension A- Anchor shackle B- Hanger bracket D- Disc E- Eye bolt N- Eye nut
 P1-Pole band termination P2- Pole band through construction G- Straight torque

Example

EA 2/D

- E- Eye bolt
- A- Anchor shackle
- 2-2 discs
- D- Disc

Stay Insulator

Stay insulator type	Line voltage	Steel wire size	Minimum failing load (KN)
GY1	LV and 11KV	7/2.75	27
GY2	11KV	19/2.00	71
GY3	22KV	19/2.75	222
GY4	33KV	19/2.75	222

Insulator pin

- Made of hot rolled carbon steel and galvanized
- Alloy lead -- 95% lead and 5% antimony
- Pattern A, B ,C

- A- Used for both medium and high voltage insulators
- B-Used for insulator of voltage up to 600V
- C- Used for high voltage insulator

Interpretation

Type/ Stem length / Failing load

Pin Type	Shank Size
B / 100 / 3.5	140 x 16 mm
A / 130 / 7	165 x 20 mm
C / 150 / 7	165 x 20 mm
C / 150 / 11	165 x 24 mm
C / 200 / 11	165 x 24 mm
B / 300 / 7	165 x 24 mm

Example

C / 300 / 7

C Type Stem length 300 mm Transversed failing load 7 KN.

Causes of insulator failure

1. Cracking of porcelain
2. Porosity of porcelain
3. Puncture of weak porcelain
4. Shattering of insulator caused by power arc
5. Flash over of insulator caused by dust/ salt deposits
6. Failure of insulator from excessive mechanical stress
7. Short circuit caused by birds or animals

Maximum tension of conductor

Maximum tension should not be more than 50% of ultimate tensile strength under a wind loading of 500 Pascal at 15 ° C

The maximum conductor tension in still air at 5 ° C is not to exceed the followings

15%- Ultimate Strength for hard drawn copper conductor

18% Ultimate Strength for hard drawn all aluminium conductor, steel core aluminium conductor and hard drawn cadmium copper conductor

18% Ultimate Strength for all aluminium alloy conductors

Vibration dampers

33 ¹/₃ % for hard drawn copper conductor

25% for hard drawn aluminium steel core and hard drawn cadmium copper conductor.

Vibration dampers are fitted to transmission lines rather than distribution feeders


Armour rod and vibration dampers

Over head line conductors are subject to mechanical vibration caused by change of wind pressure causing swing and ultimately causing failure of the conductor.

Such failure is reduced greatly where conductor is reinforced at the point of support and by designed conductor clamp.

Helically formed fittings

Fig 2.13



Helically formed fitting is applied to a conductor at the support point.

Line Guard

Features:

- Shorter in length
- Smaller diameter wire
- Used at conductor support
- To protect the conductor against flash over burn

Termination or dead ends

- Helically formed wires
- Leaving loop to which tension is applied

Insulation material for conductor

Polyvinyl Chloride (PVC)

- Low temperature, tearability, oil resistance, termite resistance
- Fuse / protective devices must be sufficiently sensitive to prevent PVC approaching softening point.

Ethylene Propylene Rubber (EPR)

- Thermosetting, excellent thermal electrical properties
- Higher dielectric, greater resistance to corona

Impregnated Paper

- Must be free from imperfection, High dielectric strength

Cross Linked Polyethylene (XLPE)

- Used for power cables
- Extremely good chemical resistant insulation
- Short time operation at 130 °C

- Continuous operation at 90 ° C
- Short circuit performance at 250 ° C
- Lightness

Compacted conductors

- Used for 1.9/ 3.3 KV cables
- HV XLPE cables are compacted to reduce the size of interstices.

Overhead line consideration

AC transmission is mostly used. Overhead line construction are much less expensive than under ground line construction.. Steel towers are used to support the conductors. They are protected by lightning arresters.


Cable

Majority of cable used for underground distribution work are Impregnated Paper insulated with lead or lead alloy sheath. Cables up to 33KV are covered by AS 1026. Copper and aluminium are used as conductors.

Learning Outcome 2.2 Outline relevant factors related to installation

Ultimate Tensile Strength

Fig 2.14



The following regulations are extracted from Overhead Line Construction Regulations of NSW (1983)

Regulation 28.1

The ultimate tensile strength of an aerial conductor operating voltage of 650V or less shall not be less than 3000N.

Hard Drawn Copper Conductor	7/1.75	at 3610 N Ultimate Strength (UTS)
All Aluminium Conductor	7/1.75	at 3010 N Ultimate Strength (UTS)
All Aluminium Alloy Conductor	7/1.75	at 4710 N Ultimate Strength (UTS)

Regulation 28.2


The Ultimate Tensile Strength of an aerial conductor operating voltage exceeding 650V must not be less than 5000N.

Copper	7/1.75	at 6840 N Ultimate Strength
Aluminium	7/2.50	at 5750 N Ultimate Strength
Aluminium Alloy	7/2/25	at 7780 N Ultimate Strength

Learning Outcome 2.3 Determine Mechanical & Physical dimension of line

Sag

Fig 2.15



When distribution lines are erected, the sag allowed in a conductor at the time of erection must be such that the maximum tension allowable for the particular conductor is not exceeded under the condition specified in the regulations.

Four sag conditions

1. Sag and tension in conductor at 15°C with wind loading of 500 Pascal on the projected area of conductor
2. Sag and tension at no wind and ambient temperature of 5°C .
3. Sag at 5°C which determines the support weight to maintain the statutory clearance above the ground.
4. Sag of erection which will ensure that the above conditions are fulfilled.

Fig 2.16

$$S = \frac{W L^2}{8 T}$$

Where

- S = Sag in metres
- L = Length of span in metres
- W = Combined load of gravitational force and wind force on conductor at one metre length
- T = Tension in conductor (Newton)

$$\text{Length of cable (Metre)} = L + \frac{8 \times S^2}{3 \times L}$$

Problem

Calculate allowable sag for a 7/ 3.50 hard drawn copper over head line conductor span of 150 m. The wind loading is 500 Pascal. Minimum tension is 50% of Ultimate Strength.

- Ultimate tensile strength = 26600N
- Gravitational force = 5.949N / m
- Diameter of conductor = 10.5 mm
- Wind loading per metre = diameter in metre x wind loading in Pascal
- = 10.5 x 10⁻³ x 500
- = 5.25 N/ m

$$\begin{aligned}
 \text{Combined load of gravitational force and wind force on conductor at one metre length} &= \sqrt{W_o^2 + W_l^2} \\
 &= \sqrt{5.949^2 + 5.25^2} \\
 &= 7.934 \text{ N/m}
 \end{aligned}$$

$$\text{Sag} = \frac{W L^2}{8 T} = \frac{7.934 \times 150^2}{8 \times 26600 \times 0.5} = 1.678 \text{ m}$$

Erection Sag

It is necessary to calculate the tension and sag under conditions at the time of erection.

Factors to vary sag and tension


- Elasticity
- Temperature

An increase in temperature will cause the length of the conductor to increase so that the sag will increase.

Sag measurement

(a) Sight Board Method

Fig 2.16




$$\text{Sag} = h_1 - h_2$$

Sight boards are fixed to two poles of the span at the appropriate height for desired sag. The conductor is then pulled up to line with a sight taken between two boards.

(b) Wave Timing Method

Fig 2.17




For this method, the conductor is struck at one end of the span and the time taken for the wave to travel the span six times is measured. Sag is then calculated from the formula.

$$t = \sqrt{\text{Sag in metre}}$$

t = Time in seconds for 3 return waves

(c) Optical Range Finder Method

Fig 2.18



$$\text{Sag} = h_1 - h_2$$

Measure the height of the conductor at the pole . The height of the conductor at mid span.

Sag= Height of conductors at pole = Height of conductor at mid span

Wood poles

- Cheapest
- Made from larch, spruce, cedar, pine, fir trees
- Southern Yellow Pine , Douglas Pine are mostly used.

Review Questions

Review Questions are extracted from EA 153 - 7762 AA Electrical Distribution Module Book

Review Questions for Section 2-Over Head Line

Review questions for Section 2

1. Name the factors that are used in the selection for overhead line conductors.

2. Name six commonly used materials for overhead lines.

- _____
- _____
- _____
- _____
- _____
- _____

3. Name the three factors that determine conductor current rating.

- _____
- _____
- _____

4. What are the factors that determine the maximum conductor temperature?

Answers for Q1 to 4

Section 2

- electrical properties such as resistance, reactance and current carrying capacity
 - mechanical properties such as tensile strength and weight
 - Initial cost of the material used
- hand drawn copper
 - all aluminium conductor (AAC)
 - all aluminium alloy conductor (AAAC)
 - aluminium conductors steel reinforced (ACSR)
 - steel conductors galvanised (SC/GZ)
 - steel conductors aluminium clad (SC/AC)
- conductor size
 - permissible operating temperature
 - Maximum likely ambient temperature

- ambient temperature
 - wind velocity
 - heat absorbed from solar radiation
 - heat loss by convection
 - heat loss by radiation
 - heat generated by the line current

Review questions for Section 2

5. Name the standard methods used for protecting the steel against corrosion when it is used as reinforcement or as a conductor.

6. Name the types of supports for conductors. Describe the one that is commonly used in distribution.

7. Describe how wood poles are being protected against weather and fungal attack.

8. State the governing factors that determine the stability of a pole.

Review questions for Section 2

9. Define pole rake.

10. Draw simple sketches of the following pole footings and describe their usages.

- plain footing
- concrete slab footing
- concreted footing
- baulk footing

Answers for Q5 to 10

5. The standard methods are:

- galvanising
- coating with aluminium (aluminium clad)

6.

- wood poles
- steel poles
- concrete poles
- steel towers

Wood poles are the most economical for distribution work.

7.


- fitting galvanised pole caps to prevent deterioration from atmospheric condition
- using preservative oils and waterborne preservatives for full length treatment of poles
- creosote, tanalith and pentachlorophenol are used for preservative treatment.

8.

- depth of pole in the ground
- bearing properties of the soil

9. Pole rake is the inclination of the pole for a rake of pole diameter at the top of the pole when the pole is used for angle and termination poles which are stayed.


10.



Review questions for Section 2

11. State the factors that determine the life of poles.

12. For the wood pole label shown, describe the meaning of each term.



Label

13. Describe how pole strength is classified.

Review questions for Section 2

14. A crossarm is listed as 2.7P/16/100x100. Describe the meaning of each term in the list.

15. Describe the **three** common types of insulators used in distribution systems.

- ---

- ---

- ---

16. The designation of an insulator is ALP 33/920. Describe the meaning of each term.

Review questions for Section 2

17. For the designation of an insulator: EA/2D, describe the meaning of each term.

18. Sketch 'creepage' of an insulator.

19. Describe the use of 'arcing horns.'

20. Briefly describe the **three** determining factors for the mechanical properties of overhead conductors.

- ---


- ---

- ---

Answers for Question 11 to 20

11.
 - weather condition
 - probability of fungus or termite attack
 - original preservative treatment
 - maintenance program
12.
 - 1234 - pole identification number
 - 77 - year of felling (1977)
 - 12-GB-S - pole length is 12 metres, species of timber is Grey Box, Timber is from South Coast
 - 4 NR - strength is 4 kN, pole type is naturally round
 - STC - name of supplier
13. According to ultimate extreme fibre stress that is allowed.
14.
 - 2.7 - the cross is 2.7 metres long
 - P/16 - four pin type insulators of 16 mm pin diameter
 - 100 x 100 - cross section is 100 mm deep by 100 mm wide
15.
 - pin
 - shackle
 - disc
16.
 - ALP - aerodynamic type line pin insulator
 - 33 - use for 33 kV
 - 920 - the minimum creepage distance is 920 mm
17.
 - EA - use eye bolt support
 - 2D - has two disc insulator

18.



Creepage is the distance between A and B

19. Use to prevent the cracking of porcelain for an insulator in the case of flashover due to lightning. The electrodes of an 'arcing horn' provide a discharging path for the arcing caused by lightning.
20.
 - the working strength of the material used
 - maximum tensions to be exerted on the conductor
 - armour rods and vibration dampers used for reinforcing

Review questions for Section 2

21. Describe briefly the two methods used in sag measurement.

22. Sketch the following stay anchorages.

- used in solid rock formation
- used in weak rock formation
- used in soil

Anchor Type	Material	Dimensions	Weight	Strength	Notes
Rock anchor	Steel	100mm x 100mm	10kg	100kN	Used in solid rock
Rock anchor	Steel	150mm x 150mm	15kg	150kN	Used in solid rock
Rock anchor	Steel	200mm x 200mm	20kg	200kN	Used in solid rock
Rock anchor	Steel	250mm x 250mm	25kg	250kN	Used in solid rock
Rock anchor	Steel	300mm x 300mm	30kg	300kN	Used in solid rock
Rock anchor	Steel	350mm x 350mm	35kg	350kN	Used in solid rock
Rock anchor	Steel	400mm x 400mm	40kg	400kN	Used in solid rock
Rock anchor	Steel	450mm x 450mm	45kg	450kN	Used in solid rock
Rock anchor	Steel	500mm x 500mm	50kg	500kN	Used in solid rock
Rock anchor	Steel	550mm x 550mm	55kg	550kN	Used in solid rock
Rock anchor	Steel	600mm x 600mm	60kg	600kN	Used in solid rock
Rock anchor	Steel	650mm x 650mm	65kg	650kN	Used in solid rock
Rock anchor	Steel	700mm x 700mm	70kg	700kN	Used in solid rock
Rock anchor	Steel	750mm x 750mm	75kg	750kN	Used in solid rock
Rock anchor	Steel	800mm x 800mm	80kg	800kN	Used in solid rock
Rock anchor	Steel	850mm x 850mm	85kg	850kN	Used in solid rock
Rock anchor	Steel	900mm x 900mm	90kg	900kN	Used in solid rock
Rock anchor	Steel	950mm x 950mm	95kg	950kN	Used in solid rock
Rock anchor	Steel	1000mm x 1000mm	100kg	1000kN	Used in solid rock
Rock anchor	Steel	1050mm x 1050mm	105kg	1050kN	Used in solid rock
Rock anchor	Steel	1100mm x 1100mm	110kg	1100kN	Used in solid rock
Rock anchor	Steel	1150mm x 1150mm	115kg	1150kN	Used in solid rock
Rock anchor	Steel	1200mm x 1200mm	120kg	1200kN	Used in solid rock
Rock anchor	Steel	1250mm x 1250mm	125kg	1250kN	Used in solid rock
Rock anchor	Steel	1300mm x 1300mm	130kg	1300kN	Used in solid rock
Rock anchor	Steel	1350mm x 1350mm	135kg	1350kN	Used in solid rock
Rock anchor	Steel	1400mm x 1400mm	140kg	1400kN	Used in solid rock
Rock anchor	Steel	1450mm x 1450mm	145kg	1450kN	Used in solid rock
Rock anchor	Steel	1500mm x 1500mm	150kg	1500kN	Used in solid rock
Rock anchor	Steel	1550mm x 1550mm	155kg	1550kN	Used in solid rock
Rock anchor	Steel	1600mm x 1600mm	160kg	1600kN	Used in solid rock
Rock anchor	Steel	1650mm x 1650mm	165kg	1650kN	Used in solid rock
Rock anchor	Steel	1700mm x 1700mm	170kg	1700kN	Used in solid rock
Rock anchor	Steel	1750mm x 1750mm	175kg	1750kN	Used in solid rock
Rock anchor	Steel	1800mm x 1800mm	180kg	1800kN	Used in solid rock
Rock anchor	Steel	1850mm x 1850mm	185kg	1850kN	Used in solid rock
Rock anchor	Steel	1900mm x 1900mm	190kg	1900kN	Used in solid rock
Rock anchor	Steel	1950mm x 1950mm	195kg	1950kN	Used in solid rock
Rock anchor	Steel	2000mm x 2000mm	200kg	2000kN	Used in solid rock
Rock anchor	Steel	2050mm x 2050mm	205kg	2050kN	Used in solid rock
Rock anchor	Steel	2100mm x 2100mm	210kg	2100kN	Used in solid rock
Rock anchor	Steel	2150mm x 2150mm	215kg	2150kN	Used in solid rock
Rock anchor	Steel	2200mm x 2200mm	220kg	2200kN	Used in solid rock
Rock anchor	Steel	2250mm x 2250mm	225kg	2250kN	Used in solid rock
Rock anchor	Steel	2300mm x 2300mm	230kg	2300kN	Used in solid rock
Rock anchor	Steel	2350mm x 2350mm	235kg	2350kN	Used in solid rock
Rock anchor	Steel	2400mm x 2400mm	240kg	2400kN	Used in solid rock
Rock anchor	Steel	2450mm x 2450mm	245kg	2450kN	Used in solid rock
Rock anchor	Steel	2500mm x 2500mm	250kg	2500kN	Used in solid rock
Rock anchor	Steel	2550mm x 2550mm	255kg	2550kN	Used in solid rock
Rock anchor	Steel	2600mm x 2600mm	260kg	2600kN	Used in solid rock
Rock anchor	Steel	2650mm x 2650mm	265kg	2650kN	Used in solid rock
Rock anchor	Steel	2700mm x 2700mm	270kg	2700kN	Used in solid rock
Rock anchor	Steel	2750mm x 2750mm	275kg	2750kN	Used in solid rock
Rock anchor	Steel	2800mm x 2800mm	280kg	2800kN	Used in solid rock
Rock anchor	Steel	2850mm x 2850mm	285kg	2850kN	Used in solid rock
Rock anchor	Steel	2900mm x 2900mm	290kg	2900kN	Used in solid rock
Rock anchor	Steel	2950mm x 2950mm	295kg	2950kN	Used in solid rock
Rock anchor	Steel	3000mm x 3000mm	300kg	3000kN	Used in solid rock
Rock anchor	Steel	3050mm x 3050mm	305kg	3050kN	Used in solid rock
Rock anchor	Steel	3100mm x 3100mm	310kg	3100kN	Used in solid rock
Rock anchor	Steel	3150mm x 3150mm	315kg	3150kN	Used in solid rock
Rock anchor	Steel	3200mm x 3200mm	320kg	3200kN	Used in solid rock
Rock anchor	Steel	3250mm x 3250mm	325kg	3250kN	Used in solid rock
Rock anchor	Steel	3300mm x 3300mm	330kg	3300kN	Used in solid rock
Rock anchor	Steel	3350mm x 3350mm	335kg	3350kN	Used in solid rock
Rock anchor	Steel	3400mm x 3400mm	340kg	3400kN	Used in solid rock
Rock anchor	Steel	3450mm x 3450mm	345kg	3450kN	Used in solid rock
Rock anchor	Steel	3500mm x 3500mm	350kg	3500kN	Used in solid rock
Rock anchor	Steel	3550mm x 3550mm	355kg	3550kN	Used in solid rock
Rock anchor	Steel	3600mm x 3600mm	360kg	3600kN	Used in solid rock
Rock anchor	Steel	3650mm x 3650mm	365kg	3650kN	Used in solid rock
Rock anchor	Steel	3700mm x 3700mm	370kg	3700kN	Used in solid rock
Rock anchor	Steel	3750mm x 3750mm	375kg	3750kN	Used in solid rock
Rock anchor	Steel	3800mm x 3800mm	380kg	3800kN	Used in solid rock
Rock anchor	Steel	3850mm x 3850mm	385kg	3850kN	Used in solid rock
Rock anchor	Steel	3900mm x 3900mm	390kg	3900kN	Used in solid rock
Rock anchor	Steel	3950mm x 3950mm	395kg	3950kN	Used in solid rock
Rock anchor	Steel	4000mm x 4000mm	400kg	4000kN	Used in solid rock
Rock anchor	Steel	4050mm x 4050mm	405kg	4050kN	Used in solid rock
Rock anchor	Steel	4100mm x 4100mm	410kg	4100kN	Used in solid rock
Rock anchor	Steel	4150mm x 4150mm	415kg	4150kN	Used in solid rock
Rock anchor	Steel	4200mm x 4200mm	420kg	4200kN	Used in solid rock
Rock anchor	Steel	4250mm x 4250mm	425kg	4250kN	Used in solid rock
Rock anchor	Steel	4300mm x 4300mm	430kg	4300kN	Used in solid rock
Rock anchor	Steel	4350mm x 4350mm	435kg	4350kN	Used in solid rock
Rock anchor	Steel	4400mm x 4400mm	440kg	4400kN	Used in solid rock
Rock anchor	Steel	4450mm x 4450mm	445kg	4450kN	Used in solid rock
Rock anchor	Steel	4500mm x 4500mm	450kg	4500kN	Used in solid rock
Rock anchor	Steel	4550mm x 4550mm	455kg	4550kN	Used in solid rock
Rock anchor	Steel	4600mm x 4600mm	460kg	4600kN	Used in solid rock
Rock anchor	Steel	4650mm x 4650mm	465kg	4650kN	Used in solid rock
Rock anchor	Steel	4700mm x 4700mm	470kg	4700kN	Used in solid rock
Rock anchor	Steel	4750mm x 4750mm	475kg	4750kN	Used in solid rock
Rock anchor	Steel	4800mm x 4800mm	480kg	4800kN	Used in solid rock
Rock anchor	Steel	4850mm x 4850mm	485kg	4850kN	Used in solid rock
Rock anchor	Steel	4900mm x 4900mm	490kg	4900kN	Used in solid rock
Rock anchor	Steel	4950mm x 4950mm	495kg	4950kN	Used in solid rock
Rock anchor	Steel	5000mm x 5000mm	500kg	5000kN	Used in solid rock
Rock anchor	Steel	5050mm x 5050mm	505kg	5050kN	Used in solid rock
Rock anchor	Steel	5100mm x 5100mm	510kg	5100kN	Used in solid rock
Rock anchor	Steel	5150mm x 5150mm	515kg	5150kN	Used in solid rock
Rock anchor	Steel	5200mm x 5200mm	520kg	5200kN	Used in solid rock
Rock anchor	Steel	5250mm x 5250mm	525kg	5250kN	Used in solid rock
Rock anchor	Steel	5300mm x 5300mm	530kg	5300kN	Used in solid rock
Rock anchor	Steel	5350mm x 5350mm	535kg	5350kN	Used in solid rock
Rock anchor	Steel	5400mm x 5400mm	540kg	5400kN	Used in solid rock
Rock anchor	Steel	5450mm x 5450mm	545kg	5450kN	Used in solid rock
Rock anchor	Steel	5500mm x 5500mm	550kg	5500kN	Used in solid rock
Rock anchor	Steel	5550mm x 5550mm	555kg	5550kN	Used in solid rock
Rock anchor	Steel	5600mm x 5600mm	560kg	5600kN	Used in solid rock
Rock anchor	Steel	5650mm x 5650mm	565kg	5650kN	Used in solid rock
Rock anchor	Steel	5700mm x 5700mm	570kg	5700kN	Used in solid rock
Rock anchor	Steel	5750mm x 5750mm	575kg	5750kN	Used in solid rock
Rock anchor	Steel	5800mm x 5800mm	580kg	5800kN	Used in solid rock
Rock anchor	Steel	5850mm x 5850mm	585kg	5850kN	Used in solid rock
Rock anchor	Steel	5900mm x 5900mm	590kg	5900kN	Used in solid rock
Rock anchor	Steel	5950mm x 5950mm	595kg	5950kN	Used in solid rock
Rock anchor	Steel	6000mm x 6000mm	600kg	6000kN	Used in solid rock
Rock anchor	Steel	6050mm x 6050mm	605kg	6050kN	Used in solid rock
Rock anchor	Steel	6100mm x 6100mm	610kg	6100kN	Used in solid rock
Rock anchor	Steel	6150mm x 6150mm	615kg	6150kN	Used in solid rock
Rock anchor	Steel	6200mm x 6200mm	620kg	6200kN	Used in solid rock
Rock anchor	Steel	6250mm x 6250mm	625kg	6250kN	Used in solid rock
Rock anchor	Steel	6300mm x 6300mm	630kg	6300kN	Used in solid rock
Rock anchor	Steel	6350mm x 6350mm	635kg	6350kN	Used in solid rock
Rock anchor	Steel	6400mm x 6400mm	640kg	6400kN	Used in solid rock
Rock anchor	Steel	6450mm x 6450mm	645kg	6450kN	Used in solid rock
Rock anchor	Steel	6500mm x 6500mm	650kg	6500kN	Used in solid rock
Rock anchor	Steel	6550mm x 6550mm	655kg	6550kN	Used in solid rock
Rock anchor	Steel	6600mm x 6600mm	660kg	6600kN	Used in solid rock
Rock anchor	Steel	6650mm x 6650mm	665kg	6650kN	Used in solid rock
Rock anchor	Steel	6700mm x 6700mm	670kg	6700kN	Used in solid rock
Rock anchor	Steel	6750mm x 6750mm	675kg	6750kN	Used in solid rock
Rock anchor	Steel	6800mm x 6800mm	680kg	6800kN	Used in solid rock
Rock anchor	Steel	6850mm x 6850mm	685kg	6850kN	Used in solid rock
Rock anchor	Steel	6900mm x 6900mm	690kg	6900kN	Used in solid rock
Rock anchor	Steel	6950mm x 6950mm	695kg	6950kN	Used in solid rock
Rock anchor	Steel	7000mm x 7000mm	700kg	7000kN	Used in solid rock
Rock anchor	Steel	7050mm x 7050mm	705kg	7050kN	Used in solid rock
Rock anchor	Steel	7100mm x 7100mm	710kg	7100kN	Used in solid rock
Rock anchor	Steel	7150mm x 7150mm	715kg	7150kN	Used in solid rock
Rock anchor	Steel	7200mm x 7200mm	720kg	7200kN	Used in solid rock
Rock anchor	Steel	7250mm x 7250mm	725kg	7250kN	Used in solid rock
Rock anchor	Steel	7300mm x 7300mm	730kg	7300kN	Used in solid rock
Rock anchor	Steel	7350mm x 7350mm	735kg	7350kN	Used in solid rock
Rock anchor	Steel	7400mm x 7400mm	740kg	7400kN	Used in solid rock
Rock anchor	Steel	7450mm x 7450mm	745kg	7450kN	Used in solid rock
Rock anchor	Steel	7500mm x 7500mm	750kg	7500kN	Used in solid rock
Rock anchor	Steel	7550mm x 7550mm	755kg	7550kN	Used in solid rock
Rock anchor	Steel	7600mm x 7600mm	760kg	7600kN	Used in solid rock
Rock anchor	Steel	7650mm x 7650mm	765kg	7650kN	Used in solid rock
Rock anchor	Steel	7700mm x 7700mm	770kg	7700kN	Used in solid rock
Rock anchor	Steel	7750mm x 7750mm	775kg	7750kN	Used in solid rock
Rock anchor	Steel	7800mm x 7800mm	780kg	7800kN	Used in solid rock
Rock anchor	Steel	7850mm x 7850mm	785kg	7850kN	Used in solid rock

Review questions for Section 2

23. Using the attached table, calculate the allowable sag for a 7/3.50 hard drawn copper overhead conductor with a span of 150 metres. The wind loading is 500 pascals and the maximum conductor tension is to be 50 percent of the ultimate tensile strength.

BARE STRANDED HARD DRAWN COPPER CONDUCTORS

Stranding	Sectional area mm ²	overall diameter mm	Ultimate tensile strength N	Mass kg/m	Gravitational force (N/m)	Wind load at 500 Pa (N/m)	Resultant load at 500 Pa (N/m)	Resistance per Km at 20°C (OHMS)
7/1.00	5.50	3.00	2310	0.049	0.483	1.500	1.576	3.25
7/1.25	8.59	3.75	3610	0.077	0.754	1.875	2.021	2.09
7/1.75	16.84	5.25	6890	0.151	1.480	2.625	3.013	1.06
7/2.00	21.99	6.00	9020	0.197	1.931	3.000	3.568	0.815
7/2.75	41.58	8.25	16700	0.375	3.675	4.125	5.525	0.433
7/3.50	67.35	10.50	26600	0.607	5.949	5.250	7.934	0.268
19/1.75	45.70	8.75	18300	0.413	4.047	4.375	5.960	0.395
19/2.00	59.69	10.00	23900	0.538	5.272	5.000	7.266	0.302
19/2.75	112.90	13.80	44500	1.020	9.996	6.900	12.146	0.160
19/3.00	134.30	15.00	52800	1.210	11.858	7.500	14.031	0.134

TABLE 1

TEMPERATURE COEFFICIENT OF RESISTANCE = 0.00381 PER °C AT 20°C

Working:

Answer for Question 21 to 23


21. *Sight boards*
They are fixed to two poles of the span at the appropriate height for the desired sag. The conductor is then pulley up to line with a sight taken between the two boards.

Wave timing

With this method the conductor is struck at one end of the span and the time taken for the wave to travel the span six times is measured. The sag can then be calculated from the formula

$$t = \frac{\sqrt{\text{Sag in metres}}}{0.03408}$$


t = time in seconds for 3 return waves



23. Sag = 1.678 metres


2.4 Overhead line Mechanical Design

Step (1) Calculate bending moment on pole




Step (2) Calculate of maximum fibre stress on wood pole caused by wind force on conductor

$f = \frac{M \times C}{I}$ where f = maximum fibre stress N/m^2 , M = Total bending moment, c = Distance from extreme fibre of cross section to neutral axis.



I = Moment of inertia for circular shape = $\frac{\pi d^4}{64} = 0.049 d^4$



Step (3) Using the properties of wood for pole technical chart and select the appropriate type of wood by taking account on stress caused by the load

The original pole with trapezoidal (side view) shape is to be replaced by the pole with uniform diameter.

$$\text{The circumference of the pole} = \frac{3 \times \left(730 \times \text{Safety Factor} \times \text{Total Bending moment (N-m)} \right)}{\text{Ultimate stress of wood selected for making pole (N/ m}^2\text{)}}$$

Problem (1)

12 m pole is set 1.83 m in ground with three no 4/0 stranded conductors on a cross arm with the conductors level at top of pole and 45.7 m balance of span in a heavy loading area. The pole got 20.32 cm at top and 30.48 cm at bottom. NO 4/0 conductor has diameter of 1.34 cm and total ice thickness is 2.54 cm. Wind pressure is 196.2 Pa. Safety factor is taken 2.

(1) Select the appropriate type of wood

Type of wood	Ultimate stress	Safety factor	Cost
Northern white cedar	24.9 x 10 ⁶ N/ m ²	5	Cheap
Western red cedar	38.84 x 10 ⁶ N/ m ²	8	Cheap
Long leaf yellow pine	51.3 x 10 ⁶ N/ m ²	10	Moderate
Wallaha	77.79 x 10 ⁶ N/ m ²	15	Expensive

(2) If the original pole is to be replaced with the pole with uniform diameter, calculate the diameter of the new pole.

Step (1)

Fig 2.1
 $h = 12 - 1.83 = 10.17 \text{ m}$

$$\begin{aligned} \text{Bending moment caused by} &= \text{Wind pressure (Pa)} \times h^2 \left(\frac{d_1}{6} + \frac{d_2}{3} \right) \\ \text{wind force on pole} & \\ \text{(N-m)} & \\ &= 196.2 \times (10.17)^2 \times \left(\frac{30.48}{6 \times 100} + \frac{20.32}{3 \times 100} \right) \\ &= 2404 \text{ N-m} \text{-----(a)} \end{aligned}$$

Fig 2.2

$$\begin{aligned} \text{Total diameter of conductor} &= \text{Conductor diameter} + \text{Thickness of ice} \\ &= 1.34 + 2.54 = 3.88 \text{ cm} \end{aligned}$$

$$\begin{aligned} \text{Bending moment caused by} &= \text{Wind pressure} \times \text{The area of} \times \text{No of} \times h \\ \text{wind force on conductors} & \quad \text{conductor} \quad \text{conductor} \\ & \quad \text{subjected to} \\ & \quad \text{wind for the} \\ & \quad \text{whole span} \\ &= 196.2 \times 45.7 \times \frac{3.88}{100} \times 3 \times 10.17 \\ &= 10614 \text{ N-m} \text{-----(b)} \end{aligned}$$

$$\text{Total bending moment} = (a) + (b) = 2404 + 10614 = 13018 \text{ N-m}$$

Step (2)

$$\begin{aligned} \text{Maximum fibre stress} = f &= \frac{M \times C}{I} \\ &= \frac{13018 \times d / 2}{0.049 d^4} \\ &= \frac{13018}{.098 \times d^3} \\ &= \frac{13018}{.098 \times (25.4 \times 10^{-2})^3} \\ &= 8.095 \times 10^6 \text{ N/m}^2 \end{aligned}$$

By taking safety factor 2 (Given)= Working stress = 4.047 N/ m²

Type of wood	Ultimate stress	Safety factor	Working stress	Cost
Northern white cedar	20 x 10 ⁶ N/ m ²	5	4 x10 ⁶ N/ m ²	Cheap
Western red cedar	32.8 x 10 ⁶ N/ m ²	8	4.1 x10 ⁶ N/ m ²	Cheap
Long leaf yellow pine	51.3 x 10 ⁶ N/ m ²	10	5.13 x10 ⁶ N/ m ²	Moderate
Wallaha	77.79 x 10 ⁶ N/ m ²	15	5.18 x10 ⁶ N/ m ²	Expensive

Selection

Northern white cedar can not be selected because it got less stress


Wallaha got highest stress but in term of cost factor, it is expensive and will not be selected

Western red cedar or Long leaf yellow pine can be selected. But Western white cedar stress is 4.1 which is very close to the calculated stress 4.047 thus long leaf yellow pine is to be selected because
 (1) Appropriate stress (2) Moderate cost

To calculate the diameter of the new pole. if the original pole is to be replaced with the pole with uniform diameter

$$\begin{aligned} \text{The circumference of the pole} &= \sqrt[3]{\frac{730 \times \text{Safety Factor} \times \text{Total Bending moment (N-m)}}{\text{Ultimate stress of wood selected for making pole (N/ m}^2)}} \\ &= \sqrt[3]{\frac{730 \times 2 \times 13018}{51.3 \times 10^6 \text{ N/ m}^2}} \\ &= \sqrt[3]{0.37} \\ &= 0.718 \text{ m} \quad \text{Diameter} = \frac{0.718}{\pi} = 0.228\text{m} = 22.8 \text{ cm} \end{aligned}$$

Design of guy wire



Take moment centre at ground (G)

Guy Wire

$$\text{Total moment} = T \cos \alpha + h = \text{Wire 1 Force} \times h_1 + \text{Wire 2 Force} \times h_2 + \text{Wind force} \times h_w$$

$$\text{Stress in guy wire} = \frac{\text{Total moment}}{0.0982 \times d^3}$$

$$d = \sqrt[3]{\frac{\text{Total moment}}{\text{Stress in guy wire} \times 0.0982}} \quad (\text{m})$$

where d= diameter of guy wire


Problem (2)

3 No 4 medium hard-drawn copper primary conductor is attached at 10m above the ground on pole. 4 No 2 soft-drawn copper cable is attached at 2m below on the pole. A pole face area to wind is 2.5m² and wind pressure is 192.6 Pascal at 7m. The guy wire is attached at 9m above the ground at 45°.

Calculate horizontal and vertical loading on guy wire if No 4 wire has 433 Kg weight for the whole span and No 2 wire has 451 Kg weight for the whole span .

If allowable stress in guy wire is 3317 x 10⁶N/m², calculate the diameter of guy wire.

Fig 3.1



$$T \cos 45 \times 9 = 433 \times 9.81 \times 10 + 451 \times 9.81 \times 8 + 196.2 \times 2.5 \times 7$$

$$T = \frac{433 \times 9.81 \times 10 + 451 \times 9.81 \times 8 + 196.2 \times 2.5 \times 7}{9 \cos 45}$$

$$= \frac{433 \times 9.81 \times 10 + 451 \times 9.81 \times 8 + 196.2 \times 2.5 \times 7}{9 \times 0.707}$$

$$= 12776 \text{ N}$$





Fig 3.2





Total moment = Clock wise +, Anti Clockwise -

$$\begin{aligned}
 &= + 433 \times 9.81 \times 1 - 451 \times 9.81 \times 1 - 196.2 \times 2.5 \times 2 \\
 &= 4247.73 - 4424.3 - 981 \\
 &= -1131 \\
 &= 1131 \text{ N-m Anti Clockwise}
 \end{aligned}$$

$$\begin{aligned} \text{Diameter of guy wire} &= \sqrt[3]{\frac{\text{Total moment}}{\text{Stress in guy wire} \times 0.0982}} \\ &= \sqrt[3]{\frac{1131}{3317 \times 10^6 \times 0.982}} \\ &= 0.015 \text{ m OR } 1.5 \text{ cm} \end{aligned}$$

Cross Arm Design


Fig 3.3, 3.4, 3.5



$$I = \frac{b d^3}{12}$$

$c = d/2$


$$I/c = \frac{b d^2}{6}$$



$$\frac{I}{c} = \frac{d^2(b-a)}{6}$$

Problem

Fig 3.6




In given figure, if total moment on cross arm due to conductor / pin load is 493 N-m, calculate stress.

$$\begin{aligned}
 f &= \frac{M}{I/C} = \frac{493}{\frac{1}{6} (11.4/100)^2 \{9/100 - 2.54/100\}} \\
 &= \frac{493}{\frac{1 \times 11.4 \times 11.4 \times 6.46}{6 \times 100 \times 100 \times 100}} \\
 &= \frac{493}{0.0007929} = 390 \times 10^4 \text{ N/m}^2
 \end{aligned}$$

Bolt Design

Fig 3.7




W

Unit pressure on bolt in cross arm = $\frac{W}{b_1 \times d}$

Pin Design


Fig 3.8



Stress = $\frac{P \times h}{0.0982 \times d^3}$

Problem (3)

12 m pole is installed with 3 No4/0 bare copper conductors in one direction and 3 No 2/0 bare stranded copper conductors in opposite direction. 3 No 4/0 conductors cause 1355016 N-m bending moment and 3 No 2/0 conductors cause 1072721 N-m bending moment. Wind load on pole is 12648 N-m. Calculate tower circumference to withstand the load if long leaf yellow pine has ultimate stress $51.3 \times 10^6 \text{N/m}^2$. Take safety factor 2.



Resultant bending moment caused by conductor = $1355016 - 1072721 = 28228 \text{ N-m}$

Bending moment caused by wind = 12648 N-m

Total bending moment = $\sqrt{28228^2 + 12648^2}$
 $= 282578 \text{ N-m}$

Safety factor = 2

Circumference = $\sqrt[3]{\frac{730 \times \text{Safety factor} \times \text{Total bending moment}}{\text{Ultimate stress of wood selected}}}$

$$= \sqrt[3]{\frac{730 \times 2 \times 282578}{51.3 \times 10^6}}$$


$$= 2 \text{ m}$$

$$\text{Diameter} = \frac{\text{Circumference}}{\pi} = \frac{2}{3.1416} = 0.637 \text{ m} = 63.7 \text{ cm}$$

Problem

Assume a standard 2.43 m six pin arm mounted at its centre on a pole supporting six conductors each of which has 1.27 m ice coating has a maximum weight of 45.6 Kg. The length of moment arm from the centre of the arm to each pin are respectively 38.1, 74.93 and 111.76 cm. Total moment of pin hole is 493 N-m. Calculate stress if the cross section of the arm 9 x 11.4 cm is reduced by 2.54 cm hole.

Fig 3.9, 3.10



$$I/c = \frac{d^2 (b-a)}{6}$$

$$= \frac{(11.4 / 100)^2 \times (9/100 - 2.54 / 100)}{6}$$

$$= 0.00007929$$

$$f = \frac{M}{I / C} = \frac{493}{0.00007929} = 390 \times 10^4 \text{ N/m}^2$$

Double arm

Fig 3.10

Bearing strength on inclined surface at the angle to direction of grain.

$$f_a = f \sin^2 \alpha + n \cos^2 \alpha$$

Where α = Angle of inclination of load to direction of grain

Cross arm brace

Galvanized steel bolt to cross arm and fastened to pole by lag screw.

2.5 State pole and line installation technique

- All poles framing materials must be delivered in the worksite to exact designated positions.
- All structures must be assembled or framed and placed so as to be set without moving equipments
- All holes are dug.
- The setting rig must come by , set the pole and hold it until tamping or backfill crew can screw it.

Construction foundation

- Prepare foundation (Types of foundation and methods will follow)
- Deliver materials to site
- Assemble
- Erect

Maximum conductor tensions are specified.

Tension (N/m)	Heavy	Medium	Light
	4.4	2.9	0.73

Line planning

Line profile drawing

Plan profile drawings are the drawings that show a topographical contour map of the terrain along and near the worksite and a side view profile of the line showing elevation and towers.

The transmission line plan profile drawings serve as a worksheet and eventually shows what is to be done and the problems involved. Initially the drawings are prepared based on a route survey showing land ownership. The locations and elevations of all natural and man made features are to be crossed if they are adjacent to the proposed line. The drawings are then utilized to complete the line design work such as structure spotting. During material procurement and construction, the drawings are used to control the purchase of materials and to prepare the construction specific drawings.

After the construction, the final plan profile drawings become the permanent records of property and data which is useful in line operation, maintenance and in planning future modifications.

Line Drawing Sheet

Important aspect of line drawing.

- Accuracy
- Clarity
- Completeness
- To ensure economical design and construction

Provisions are to be noted with brief description of the revision. Errors in plan profile drawing can cause the construction error. Final field check of the structure site should reveal any error.

Scale

2.5 m to 1 mm for horizontal scale
25 cm to 1 mm for vertical scale

The plan profile should accommodate 1 Km of line.

The scope format for a plan profile drawing is shown in Fig 4.1. Increase in stations and structure numbering usually proceeds from left to right with the profile and corresponding plan view on the same sheet.

Existing features are to be crossed by transmission line including the height and positions of power and communication lines should be shown and noted by station and description in both the plan and profile views. The magnitude and directions of all direction angles in the line should be given and referred in plan and elevation.

Fig 4.1




Fig 4.1

Final drawing

The conductor and ground wire sizes, design tensions, ruling span and the design loading conditions should be shown on the first sheet of the plan-profile drawings. A copy of the sag template should be shown. The actual ruling span between dead-ends should be calculated and noted on the sheets.


As conductor sags and structures are spotted on each profile sheet, the structure locations are marked on the plan view and examined. Beginning with initial preparation, accuracy, clarity and completeness of the drawings should be maintained to ensure economical designed and construction. All revisions made subsequent to initial preparation and transmittal of the drawings should be noted in the revision blocked by date and with brief description of the revision.

Drawing preparation begins with an aerial survey followed by a ground check. The proper translation of these data to the plan-profile drawings is critical. Errors that occur during this initial stage affect line design because graphical method is used to locate the structure and conductor. The final field check


of the structure site should reveal any error. Normally plan-profile ensure that the locations are satisfactory and do not conflict with existing features or obstructions. To facilitate preparation of a structure list and the tabulation of the number of construction units, the following items , where required should be indicated at each structure station in the profile view.

1. Structure type designation
2. Pole height and cross height of tower
3. Pole top, cross arm or brace assemblies.

Fig 4.2, 4.3, 4.4, 4.5



2.6 Recall regulations pertaining to overhead lines






Fig 4.4




Fig 4.5




Fig 4.6

Regulation 12- Protection against corrosion

All iron and steel fittings must be protected by galvanizing or other suitable means. It is necessary to have a minimum deposit of 160 grams of zinc / square meter and hot dip galvanizing should be called for any specification for line fittings.

Regulation 13- Insulation

There must be of adequate strength pin insulators must not be used for strain or termination construction .Where the direction of an over head conductor is changed , there is a resultant load acting on the insulator in addition to the possible wind loading

Permissible line deviation

$$\text{Resultant force on pin} = 2 T \sin \alpha / 2 + W_1 l \cos \alpha / 2$$

For small angle, $\cos \alpha / 2 = 1$

$$\text{Thus Resultant force on pin} = 2 T \sin \alpha / 2 + W_1 l$$

Where

$$W_1 = \text{Wind load on conductor N/m} = \text{Wind pressure} \times \text{Diameter of conductor} \times 1 \text{ m length}$$

l = Span length in metre

T = Maximum tension in conductor (N)

α = Angle of line deviation

Problem

Determine the maximum deviation allowed on 11 KN pin insulator for a 7/ 3.50 hard drawn copper conductor with a span of 150 m. The ultimate strength of the conductor is 26600N. The wind load is to be taken as 500 Pa and the diameter of the conductor is 10.5 mm. Tension in conductor must not be more than 50% of ultimate strength. Transverse loading on pin insulator is not to exceed 40% of ultimate strength.

$$W_1 = \text{Wind load on conductor} = 500 \times 10.5 \times 10^{-3} = 5.25 \text{ N/m} \quad l = 150\text{m}$$

$$\text{Pin load} = 2 T \sin \alpha / 2 + W_1 l$$

$$\frac{40 \times 11000}{100} = \frac{2 \times 26600 \sin \alpha / 2 + 5.25 \times 150}{2}$$

$$\sin \alpha / 2 = \frac{3612.5}{26600}$$

$$\alpha / 2 = 7.8^\circ$$

$$\alpha = 15.6^\circ \text{ Angle of deviation}$$

Regulation 14 Loading condition

Wind load = 500 Pascal

Regulation 15 Aerial conductor

All conductors must be stranded and all normally available materials are allowed.

Regulation 16 Conductor sag and tension

The condition specified in this regulation must be known

Regulation 17 Foundation for support

The foundation for support for aerial conductors must be capable of bearing any load to which they are likely to be subjected.

Staying of pole

Staying of pole is usually necessary on high voltage lines and terminations and all intermediate poles where there is a large deviation in the line. Similar staying may also be needed for poles with lines up to 650V if the soil is of poor bearing quality.

Regulation 18 Support

The percentage of ultimate strength of various parts of overhead line

Steel 50% Wood 25 % Stay wire/ Insulator 40%

For insulator, maximum tension which can be applied without causing the insulator to puncture and fracture when a voltage of 75% of the dry flash over voltage is simultaneously applied to the insulator.

Regulation 19 Earthing and insulating metal work

Earthing prevents the potential of exposed metal work within 2.4 m of the ground from exceeding a sustained voltage of 32 V ac.

Essential components of staying pole

1. Galvanized stay wire of suitable strength
2. Strain insulator to insulate the strain wire within 2.5m of ground
3. Wire rope grips from strain wire preset fitting
4. Stay anchorage
5. Batten

Fig 4.6

Regulation 20 Prevention of unauthorised climbing

Install anti climbing guard and attach danger sign

Regulation 21 to 26 cover over head service lines specification to service line.

Regulation 28 Size of conductor

For 650 V 7/ 1.25 copper conductor is used

7/ 1.75 all aluminium and aluminium alloy conductor are used

Regulation 29 & 30 Clearances of conductors from ground and structure

The clearance stated must be known

Regulation 33- Separation of conductors

Same circuit or different circuit , the equivalent horizontal separation “ S “ to fixed support.

$$S = 0.0076 + 0.3 \times \sqrt{D - 2.13} + 0.083 \sqrt{D} \frac{x d^2}{w_r}$$

Where

S = Equivalent horizontal spacing in metres

D = Sag (m) at 50° C and no wind

d = Overall diameter of conductor in mm

w_r = Resultant load (N/m) due to gravitational force on conductors and 500 Pa horizontal wind load on the conductor

Minimum separation

- Minimum separation between conductors of the same circuit should be 0.38 m up to and including 11 KV + 10 mm / KV in excess of 11 KV.
- The minimum separation between conductors of different circuits should not be less than 0.6 m up to and including 650 V and 1.2 m up to and including 33 KV.
- Where suspension insulators are used and are not restrained from movement, the separation required by above should be maintained with insulator swing of 45 ° from vertical position of one string only.

Distance between insulator and cross arm

450 mm -- Clearance between the insulator on cross arm for medium voltage

600 mm -- Clearance at the insulators on the cross arm for 11 KV

Span	Spacing
• Not exceeding 9 m	0.2 m
• Exceeding 45 m and not exceeding 60 m	0.45 m


When line deviation exceeds 30 degrees, use twin cross arm construction with shackle insulators so that each cross arm is at right angle to direction of line.

Regulation 35

- Automatic interruption to supply in the event of fault condition
- This regulation applies specially to overhead lines of voltages in excess of 650 Volts
- The automatic device should operate within 2 seconds for fault current equivalent to the maximum progressive values.

3.1 Determine the construction features and insulation abbreviations of underground power cables

Fig 5.1



Cable

The majority of cables used for distribution works are impregnated paper insulated cables with a lead or lead alloy sheath.

AS 1026 standard is applied.

Properties	Unit	Annealed copper	99.5 % Purity Aluminium ¾ H	99.5 % Purity Aluminium as extruded
Density	g/ cm ³	8.89	2.703	2.700
Resistivity	Ohm at 20 ° C	1.7241 x 10 ⁻⁸	2.8264 x 10 ⁻⁸	2.803 x 10 ⁻⁸
Temperature coefficient of resistance	Per ° C	0.00393	0.00403	0.00403
Melting point	° C	1083	658	658
Coefficient of elongation	Per ° C x 10 ⁻⁶	17	23.8	23.8
Ultimate tensile strength	K Pa	241	124	83

¾ H -- ¾ Hard

Types of cables

- Single core cable
- Belted cable
- Screened cables
- Multicore SL Cables
- Multicore HBL Cables
- Oil filled cables
- Gas filled cables
- Plastic insulated cables

Rating factor

Tables of current ratings for cables always specify some ambient temperature and the number of cables which are in close proximity.

In practice , the ambient temperature may be higher than that used for design conditions and so reduced current rating must be used.

Maximum conductor temperature ° C	Rating factor									
	Ground temperature for cables laid direct or in ducts					Air temperature for cables laid in air				
	15° C	20° C	25° C	30° C	25° C	30° C	35° C	40° C	45° C	
60	1.14	1.07	1.0	0.92	-	-	-	-	-	-
65	1.12	1.06	1.0	0.96	1.26	1.18	1.10	1.0	0.89	
70	1.11	1.05	1.0	0.94	1.22	1.15	1.08	1.0	0.91	
80	1.09	1.04	1.0	0.95	1.16	1.12	1.06	1.0	0.93	

Current rating of cables

The current rating of cables is determined by

- The thermal capacity of the cable
- The voltage drop
- Short circuit capacity

Sheath current

Sheath currents may be divided into two kinds, namely

- Currents whose outward and return paths lie entirely in the sheath of one cable - sheath eddies
- Currents whose outward and return paths are formed by the sheath of separate cables- sheath circuit eddies

Conditions

1. Where cables are fixed to a vertical surface or wall the distance between the wall and the surface of the cable should not be less than 20 mm
2. Cables of which the cross sectional area does not exceed 185 sq mm should be installed at a distance between centres of not less than twice the overall diameter of cable
3. Cables of which the cross sectional area does not exceed 185 sq mm should be installed at a distance between centres.

4. Cables should be removed from iron and steel other than cable supports

Conductor temperatures

Maximum permissible continuous conductor temperature for paper insulated cable.

Voltage rating of cable (KV)	Type of cable	Maximum permissible temperature °C
0.6 / 1 1.9 / 3.3 3.8 / 6.6 6.35 / 11	All types Single core 3 cores-Belted 3 cores-screened	80 °C 70 °C 65 °C 70 °C
12.7 / 22 19 / 33	All types	65 °C 65 °C

3.2 Calculate cable voltage drop in relation to length of cable run

The actual voltage drop (Vd) for a particular cable in given circuit is calculated using the equation.

$$Vd = \frac{Vc \times L \times I}{1000}$$

Where

Vd = Actual voltage drop in volts

Vc = Unit voltage drop in millivolts per ampere metre (mv / A-m)

L = Route length of circuit

I = Current to be carried by the circuit (Usually maximum demand)

$$Vc = \frac{1000 \times Vd}{L \times I}$$

Single and three phase voltage drop

Conversion of the unit voltage drop Vc (mv / A-m)

3 Phase Vc = Single Vc x 0.866


Single phase Vc= 3 Phase Vc / 0.866

Conversion of the actual voltage drop Vd (Volts)

$$3 \text{ Phase } Vd = \text{Single phase } Vd \times \sqrt{3}$$

$$\text{Single Phase } Vd = \frac{3 \text{ Phase } Vd}{\sqrt{3}}$$

Cable selection based on voltage drop



Problem (1)

Calculate the voltage drop in each segment of a 3 phase 400 volt non-domestic installation consisting of the followings.

Consumer main

Phase = 3 Maximum demand 45 Amp Route length = 25 m

Cable size 16 mm²

Cable configuration V90 Single core thermo plastic and sheathed copper conductor

Cable installation

The circuit is enclosed in heavy duty rigid thermoplastic conduit with no other circuits. Conduit is buried in the ground having an ambient soil temperature of 25 °C and has a top cover of 0.65 m.

Sub main

Phase = 3 Maximum demand = 35 A, Route length = 35 m

Cable size = 10 mm²

Cable configuration

V90 Single core thermoplastic and sheathed copper conductors structure in trefoil formation and installed in single circuit configuration unenclosed in air

Final sub circuit

Phase = 1 Maximum demand = 20 Amp Route length = 35 m

Cable size = 4 mm²

Cable configuration - V90 two cores and earthed thermoplastic and sheathed copper conductors

Cable installation - The cables are clipped to the building structure and installed in single circuit configuration , unenclosed in air.

Does this portion of the installation comply with the voltage drop requirement of AS/NZS 3000 ?

Consumer main

V90 single core / enclosed in conduit-- Select Table 41 (Page 81 of AS/NZS 3008 1.1 1998)

$$L = \frac{1000 \times Vd}{I \times Vc}$$

$$25 = \frac{1000 \times Vd}{45 \times 2.55} \quad \text{Thus } Vd = \frac{25 \times 45 \times 2.55}{1000} = 2.868 \text{ (3 phase voltage drop)}$$

$$\text{For single phase voltage drop} = \frac{2.868}{\sqrt{3}} = 1.655\text{V}$$

Sub main

V90 cables are clipped to building structure in trefoil formation.

Select Table 40 (Page 80 of AS/NZS 3008 1.1 1998)

$$L = \frac{1000 \times V_d}{I \times V_c}$$

$$V_d = \frac{L \times I \times V_c}{1000} = \frac{35 \times 35 \times 4.05}{1000} = 4.96\text{V (3 phase voltage drop)}$$

$$\text{For single phase voltage drop} = \frac{4.96}{\sqrt{3}} = 2.86\text{ V}$$

Final sub circuit

V90 two cores

The cables are clipped to the building structure and installed in single circuit configuration unenclosed in air.

Table 42 Page 82

$$\text{Single phase } V_c = \frac{3 \text{ phase } V_c}{0.866} = \frac{10.2}{0.866} = 11.77$$

$$L = \frac{1000 \times V_d}{I \times V_c}$$

$$V_d = \frac{L \times I \times V_c}{1000} = \frac{35 \times 20 \times 11.77}{1000} = 8.23\text{ V}$$

Total single phase voltage drop = 1.655 + 2.86 + 8.23 = 12.7 V

$$5\% \text{ of } 240\text{ V} = \frac{5 \times 240}{100} = 12\text{ V}$$

The actual voltage drop 12.7 V is higher than limitation 12 V .

It does not comply with AS/ NZS 3000:2000.

3.3 Recall techniques to reduce electrical stresses on cables

To reduce the stress

1. Stand properly
2. Careful in bending / cutting/ removing insulation
3. Follow the proper procedure in connection

4. Take account on external conditions
5. Take account on temperature
6. Take account on installation conditions
7. Set appropriate tension of conductors
8. Select appropriate materials to enclose cable. Select appropriate cable materials for relevant condition.

Implication and type of duty

Current condition, voltage drop consideration, operating voltage

Bending of cable

Excessive bending of cables during their installation will reduce their working life.

Temperature rating

V75 -- Working temperature 75 °C

V105 -- Working temperature 105 °C

Polytetrafluorethylene (PTFE) -- Working temperature 200 °C

Enclosure of cables

- Determine overall cross sectional area of each cable to be installed in conduit/ trench / cable way
- Calculate total overall cross sectional area of all cables to be installed in conduit / trench / cable way trunk.
- Determine required conduit / trench / trunk size
- Check the proposed conduit enclosure will conform to the requirement of regulations.

Type of conductors

Copper

- High conductivity per unit area
- Easily mechanically joined (or) soldered \
- Expensive
- Resistant to corrosion
- Stronger than aluminium

Aluminium

- High conductivity per weight
- Must be joined with a joining paste since aluminium oxide , an insulator forms almost immediately after cleaning.
- Cheaper than copper but it's coefficient of expansion must be taken in to account when joining.
- It is not as resistant to corrosion
- Weaker than copper
- When used in installation such as aerials, aluminium cable is usually steel cored to add strength

Performance of cable insulation material will be drastically affected if the cable is exposed to weather, oil, abrasion and chemicals

3.4 Recall cable rating factors, method of cable joining

Stripping cable

Use knife / plier / stripper

Termination- Solder / crimp ----Adjustable crimper 10 to 120 mm² cable
 For large cables-- hydraulic crimpers are used.


3.7 Recall cable testing techniques and methods to locate the fault

Stress in 3 cores cable

Even when the dielectric is homogeneous , the problem can not be solved with accuracy, and as the dielectric is never homogeneous because of the fillers, there is no point in quoting or working from formulae. There is a rotating electric field in the 3 core cable and the maximum stress occurs at the point nearest to the centre on the conductor at maximum voltage.

It is however almost certain that this stress is not the determining factor in the life of the cable. It is normal for the paper and is more easily borne than the lower stresses which occur in and near the fillers and are tangential to the papers. It was found in the 3 core 33KV cables that deterioration began in the fillers and warming and not at the point of maximum stress on the conductor

Fig 5.2



$$\text{Stress without sheath} = S_{\text{max without sheath}} = \frac{E}{\frac{1}{2} d \ln D/d} \text{ Volt / mm}$$

$$E = \text{Peak voltage per phase} = \frac{\sqrt{2} E_{\text{rms}}}{\sqrt{3}}$$

$$\text{Stress maximum with sheath} = \frac{S_{\text{max without sheath}}}{\sqrt{3(1 + \alpha + \alpha^2)}}$$

For double sheath

$$E_2 = \frac{E}{1 + \frac{1}{\alpha} + \frac{1}{\alpha^2}}$$

$$E_1 = E_2 \left(1 + \frac{1}{\alpha} \right)$$

Problem

A single core 66KV cable has a conductor diameter of 2 cm and a sheath of inside diameter 5.3 cm . Find the maximum stress. If two inter-sheaths are used, find the best positions, the maximum stresses and the voltage on inter-sheaths.

$$D = 5.3 \text{ cm} \quad d = 2 \text{ cm} \quad \text{Thus } D/d = 5.3/2 = 2.65$$

$$D/d = \alpha^3 \quad \text{Thus } \alpha = \sqrt[3]{2.65} = 1.384$$

$$\text{Peak voltage on conductor} = \frac{66 \times \sqrt{2}}{\sqrt{3}} = 53.8 \text{ KV}$$

$$E_2 = \frac{E}{1 + \frac{1}{\alpha} + \frac{1}{\alpha^2}}$$

$$= \frac{53.8}{1 + \frac{1}{1.384} + \frac{1}{1.384^2}}$$

$$= \frac{53.8}{1 + \frac{1}{1.384} + \frac{1}{1.91}}$$

$$= 23.9 \text{ KV}$$

$$E_1 = E_2 \left(1 + \frac{1}{\alpha} \right)$$

$$= 23.9 \left(1 + \frac{1}{1.384} \right) = 41.1 \text{ KV}$$

Maximum stress without inter-sheaths = $\frac{\text{Peak voltage}}{\dots}$

$$\frac{1}{2} d \ln D/d$$

$$= \frac{53.8}{\frac{1}{2} \times 2 \times \ln 5.3/2}$$

$$= \frac{53.8}{\ln 2.65}$$

$$= 55.3 \text{ KV/cm}$$

Stress maximum with sheath = $\frac{S \text{ max without sheath}}{\sqrt[3]{(1 + \alpha + \alpha^2)}}$

$$= \frac{55.3}{\sqrt[3]{(1 + 1.384 + 1.384^2)}}$$

$$= \frac{55.3}{\sqrt[3]{(1 + 1.384 + 1.91)}}$$

$$= 38.7 \text{ KV/cm}$$

Sheath effect


The currents induced in the sheaths are of two kinds.


Sheath eddies - Whose paths lie in the sheath of a single cable and which flow even when the sheaths are isolated from each other.

Sheath current eddies – Whose paths lie in the sheaths of separate cables and flow only when the sheaths are bonded.

Sheath eddy paths

Fig 5.3





$$L = 2 \ln d / r$$


$$M = 2 \ln \frac{d}{D/2}$$

$$\text{Flux} = 0.4 \ln \frac{d}{D/2}$$

$$\text{Induced voltage} = 4 \omega I \ln \frac{d}{D/2} \times 10^{-9} \text{ Volt / cm length}$$

Capacitance in 3 core belt type cable

Fig 5.4




Conductor 2 and 3 are connected to sheath and measure the capacitance between conductor 1 and the rest.

$$X_c = \frac{V}{I}$$

$$\frac{1}{2 \parallel f c} = \frac{V}{I}$$

$$C = \frac{I}{V \times 2 \times \parallel \times f}$$

Fig 5.5




Total capacitance = $C_s + 2 C_c$

Thus $C_a = C_s + 2 C_c$ ----- Eq 1

All conductors are connected and the capacitance be measured between conductor 1 and the rest.

Fig 5.6



$C_b = 3 C_s$ ----- Eq 2

Thus $C_s = \frac{1}{3} C_b$

By this way the capacitance to sheath is measured.

Then the capacitance between conductor is calculated

$C_a = C_s + 2 C_c$

$C_a = \frac{1}{3} C_b + 2 C_c$

$C_c = \frac{1}{2} (C_a - \frac{1}{3} C_b)$

$C_c = \frac{C_a}{2} - \frac{C_b}{6}$

By this way the capacitance between conductor is measured.

Problem

Conductor 2 and 3 are connected , measured capacitance between conductor 1 and the skin in 6 micro farad.

All conductors are connected, measure the conductor and the skin is 4 micro farad.

Calculate Cs and Cc.

When all conductors are connected

$$C_s = \frac{1}{3} C_b$$

$$C_s = \frac{1}{3} \times 4 = 1.333 \text{ micro farad}$$

When conductor 2 and 3 are connected.

$$C_a = C_s + 2 C_c$$

$$6 = C_s + 2 C_c$$

$$C_s + 2 C_c = 6$$


$$1.33 + 2 C_c = 6$$

$$\text{Thus } C_c = \frac{6 - 1.33}{2} = 2.335 \text{ micro farad}$$

Capacitance to neutral Co

$$C_o = \frac{0.048 \epsilon}{\text{Log} \left[1 + \frac{T+t}{d} \left\{ 3.84 - 1.7 \frac{t}{T} + 0.53 \frac{t^2}{T^2} \right\} \right]} \times \frac{1}{1.609} \text{ micro farad / Km}$$

Fig 5.7



- d = Conductor diameter
- T = Thickness of conductor insulation
- t = Thickness of belt insulation
- ε = Dielectric constant

Problem

Diameter of conductor = 1.65 cm Dielectric constant = 3.6
 Conductor insulation = 0.508 cm Thickness of belt = 0.43 cm
 Calculate Co .

$$C_o = \frac{0.048 \times 3.6}{\text{Log} \left[1 + \frac{0.508 + 0.43}{1.65} \left\{ 3.84 - 1.7 \frac{0.43}{0.508} + 0.53 \frac{0.43^2}{0.508^2} \right\} \right]} \times \frac{1}{1.609}$$

$$= \frac{0.48 \times 3.6}{\text{Log} 2.57} \times \frac{1}{1.609} = 0.26 \text{ micro farad / Km}$$

Cable testing technique and methods to find the location of cable fault

Fault finding methods

- (1) Sectionalizing --- Divide the line route in to smaller sections. Test each section
- (2) Thumping—Supply high voltage in to faulted cable resulting high current arc makes a noise loud enough to hear it by tester above the ground. Applied voltage is 25 KV.

Disadvantage --- It can degrade the insulation

(3) Time Domain Reflectory (TDR)

Send a low energy through the cable causing no insulation degradation . Perfect cable returns the signal in a known time and known profile.

Impedance variation in cable alter both time and profile which TDR screen or print

Weak point - It does not pin point the fault.

(4) High voltage radar method

- Arc reflection
- Surge pulse reflection
- Voltage pulse reflection

Arc reflection -----Use TDR and Thumper ----- It provides appropriate distance to fault

Surge reflection ----Use current coupler and storage oscilloscope - It can find the difficult faults

Disadvantage -- High out put surge can damage the cable and it needs skill to interpret.

(5) Voltage pulse reflection

Voltage pulse reflection uses a voltage coupler and analyzer with a dielectric test set of proof tester.

This method provides a way to find faults that occur at voltage above the maximum thumper voltage of 25 KV.

Open neutral

Open neutral and bare neutral can be corroded quickly in contaminated soil that holds corrosive chemicals or excessive moisture

Open neutral often thwart the effectiveness of high voltage radar.

Test to detect open neutral

Shorting a known good conductor to suspect neutral.

Measure the resistance with ohm meter

Reading 10 ohm or higher, it can be suspected that there is an open neutral.

Use of TDR method

When the neutral is open, there will be no reflected pulse. If TDR displays the open neutral, AC voltage gradient test set can locate the break in a direct buried unjacketed cable.

Test set transmitter forces AC current to flow through neutral. , then detect the resulting voltage gradient in soil.

Equipments applied for cable fault location

TX 2001 TDR cable fault locator

Megger cable fault locator

Computerware TX 2002 / 2003


3.5 Apply cable schedules for underground reticulation scheme

Cable laying

(1) Direct laying (2) Draw in system (3) Solid system

Direct laying

A trench is dug in which the cable is laid, covered with soil. The cable may be protected by planks, bricks, tiles or concrete slabs. Cable should be armour cable. If the ground contains harmful chemicals, the serving must be adequate to protect the cable from corrosion and electrolysis.






Draw in system

A line of conduits, ducts or tubes is laid in trench. The tubes are of glazed stoneware, cement or concrete. The cables are pulled into the position from manholes or brick pits. It is unnecessary to armour the cable but a serving of heasian type of jute protects the cable when drawing in.

Solid system

The cable is laid in throughing in open trench. The throughing is of stoneware, cast iron, asphalt or treated wood. After the cable is placed in position, the throughing is filled with a bituminous or asphaltic compound and covered over. Cable can be laid with a bare sheath and is immune from electrolysis as the sheath is electrically insulated from earth.






3.5 Apply cable schedules for underground cable installation

Joining

The most common way of joining the conductors is to insert the ends into a ferrule which is a slotted metal tube, and solder the whole solid.

With oval cables, the ferrule is made in two halves which can be turned with respect to one another in order that the cables need not be twisted to make their axes parallel. Packing adaptors are being used.



Method

1. Lead sheath is cut back 60 cm, the paper in 7 cm.
2. Lead sleeve, lead flame, paper tube are passed back along the conductor.
3. The ferrule is put on and the parts are soldered together.
4. The paper is pencilled back 3.2 cm and metallised paper is cut back to within 3.8 cm of lead.
5. The paper tube is slipped into position and fixed by 4 narrow wedges
6. Which are jammed by layers of oiled silk tape
7. Joint is filled with compound. No air will be on trapped
8. Oil proof tape is wrapped over the end of lead sheath to prevent oil from flowing from the joint into cable
9. Lead flame is placed in position and lead wire is wrapped on

10. Lead sleeve is put in position and plunked at the ends and middle
11. Bending strands are fixed
12. Joints is filled with oil

$$\text{Insulation resistance of cable} = \frac{\rho}{2 \ln \frac{D}{2r}} \text{ L}$$

Conductor radius = r Internal sheath radius = 1/2 D

Problem

Find the insulation resistance per Km of cable of conductor diameter. 1.6 cm and internal sheath diameter is 5.08 cm. $\rho = 6 \times 10^{14} \Omega\text{-cm}$

$$\begin{aligned} \text{Insulation resistance of cable} &= \frac{\rho}{2 \ln \frac{D}{2r}} \text{ L} \\ &= \frac{6 \times 10^{14}}{2 \times 3.14 \times 10^3 \times 10^2} \text{ L} \ln \frac{5.08}{1.6} \\ &= 0.955 \times 10^9 \times \ln 3.175 \\ &= 0.955 \times 10^9 \times 1.155 \\ &= 1.103 \times 10^9 \text{ M}\Omega \\ &= 1103 \text{ M}\Omega \end{aligned}$$

Problem

In above problem, if the cable is subject to 66KV 3 phase line, find dielectric loss.

E line = 66 KV

$$E_{ph} = \frac{66 \times 10^3}{\sqrt{3}} = 38104 \text{ V}$$

$$\begin{aligned} \text{Therefore dielectric loss} &= \frac{E_{ph}^2}{R_{\text{insulation}}} \\ &= \frac{38104^2}{1103 \times 10^6} \\ &= 1.316 \text{ watts} \end{aligned}$$

Underground cables

Low tension cable -- Below 1000V

Insulation material may be impregnated paper, varnished cambric, vulcanised rubber or vulcanised bitumen

Insulation

Thickness of dielectric at 660 V between 0.2 cm and 0.28 cm

Varnished cambric is coated with petroleum jelly to provide lubrication between layers so that bending of cable is possible without damage

Vulcanised bitumen - Refined bitumen is melted and sulphur and vegetable oil are added.

Sheath

Lead sheath - Vat field of use





3.6 Describe techniques used to install cable and associate equipments

Ducts

To expand future installation

Iron / reinforced concrete/ steel pipe/ wood / fibre/ plastic

Fig 6.4

Duct type	Cost of construction	Ability to radiate heat	Cost of support
	Expensive	Best	Best
	Moderate	Very good	Very good
	Moderate	Very good	Good
	Cheapest	Very poor	Very poor

Service boxes

Secondary mains are installed in ducts buried at shallower depths than those carrying primary conductor. Precast reinforce concrete is used.

Cable manhole


- Rectangular for straight line conduit construction.
- Square for accommodating from 4 directions.

Fig 6.5

Transformer Manholes

Transformer manholes are designed to contain transformers and other equipments for radial or network system.

Fig 6.6



Design loading on manhole

$$\text{Concentrated load} = \frac{\text{Wheel load (1 + \% Impact / 100)}}{\text{Wheel Area}}$$

Problem

Wheel load 9576 Kg , imposed 50% for heavily travelled street under which truck traffic may be concrete. Wheel area is 15.5 cm x 30.5 cm

Calculate concentrate load on manhole cover.

$$\begin{aligned} \text{Concentrated load} &= \frac{\text{Wheel load (1 + \% Impact / 100)}}{\text{Wheel Area}} \\ &= \frac{9576 (1 + 50 / 100)}{15.5 \times 30.5 \times 10^{-4}} \end{aligned}$$

$$\begin{aligned}
 & \frac{14364 \times 10^4}{472.75} \\
 & = 303839 \text{ Kg / m}^2
 \end{aligned}$$

Roofs

Manhole roofs are designed as a series of structural steel beams or rail or reinforced concrete with extra reinforcement or structural steel to support manhole frames

Wall

Manhole wall designs are based on the horizontal component of the effect of both line and dead loads acting on the walls.

Floors

In the design of manhole, floors, the load bearing power of the soil and the height of the water tube play an important part. The soil must support the weight of the manhole structure its contents and any imposed surface level loads.

Frame / covers

- Made of cast iron/ malleable iron/ steel
- Are designed to withstand the loadings of traffic
- May be made of reinforced concrete

Ventilation

- Principal heat source is power loss in windings
- Tube ventilation is natural ventilation
- Large conductors are put in separate ducts
- XLPLE/ Lead/ Plastic insulation are used.

Fig 6.7 Cross section of joint

Underground Equipments

transformers, oil filled cutouts and oil switches for use underground are hermetically sealed so as to be water proofed

Such submersible equipment is usually of welded construction. Wiping sleeves are welded or brazed directly to the tank or terminal chamber to which cable sheaths are attached.

Barriers in the conductors prevent the equipment oil from being siphoned into the cables.

4.1 Recall the terminology used in relation to voltage profile

Voltage regulation


The voltage regulation is defined as the percentage rise in voltage at receiving end when full load is thrown off, the sending end voltage is unaltered.

$$\text{Regulation} = \frac{E_s - E_r}{E_r} \times 100 \%$$

$$= \frac{I R \cos \phi_r + I X \sin \phi_r}{E_r}$$

Off load tap changer


Fig 7.1



+/- 2 ½ % to +/- 5% of nominal voltage

On load tap changer

Fig 7.2



Many transformers are provided with equipments for changing their voltage ratio under load.

Booster transformer



A separate transformer may be used to inject a variable voltage into a circuit for regulating purpose.

Quadrature booster

Injects a voltage with a major component at 90 degree to the existing voltage.

Induction and moving coil regulator

Φ output = $\Phi 1 + \Phi 2$ depending on the position of moving coil.



4.2 Describe the reasons effects and limitation of voltage variation

Voltage control

All modern transmission systems with the exception of the constant current system, operate at a constant voltage . It is essential for the satisfactory operation of the consumer's apparatus that the vltage be kept within narrow limit.

Voltage drop

The conductor must operate so that when the maximum current is being conveyed. The fall in voltage along the line is within certain limit.

SAA Rule

Fall in the potential in the consumer's mains to any point on the installation does not exceed 5 % of the voltage at the commencement when full current is flowing.

Medium voltage – variation within 6% (Not exceed)


Higher voltage—Variation within 10% (Not exceed)

Power loss

The power loss in the distribution feeders depends on the square of the current and the resistance of the feeder. His loss must be considered in relation to the capital cost involved in the erection of distribution line.

4.3 Recall methods used in controlling voltage level

Fig 7.5



Er= Receiving end voltage

$$E_s = [(E_r \cos \phi_r + I R)^2 + (E_r \sin \phi_r + I X)^2]^{1/2}$$

$$\text{Regulation} = \frac{E_s - E_r}{E_r} \times 100$$

$$= \frac{IR \cos \phi_r + IX \sin \phi_r}{E_r} \times 100$$

Methods of voltage control

Three general methods are available for controlling the voltage at the end of a distribution feeder. They are


1. By controlling the sending end voltage
2. By controlling the receiving end voltage
3. By controlling the current in the line that is varying the power factor

Voltage control equipments

1. Off load tap changing transformer
2. On load tap changing transformer
3. Booster transformer
4. Moving coil regulator
5. Induction regulator

Induction voltage regulator

Fig 7.6



$$V_2 = V \pm V_1$$

$$V \pm V_1 = V_2$$


$V = \text{Input voltage}$

$V_1 = \text{Injected series voltage}$

Constant ratio distribution transformer

Light load, zone transformer tap changer is set at 100%.

Fig 7.8




Voltage profile example

The simplified single line diagram of a distribution system is shown in the figure. It is desired to keep the voltage within + 6 % and -4% of the nominal voltage.

Consumers

- A, B --- Distribution transformer T1
- C, D---- Distribution transformer T2

Fig 7.9



Problem

An industrial consumer takes a load of 100KVA at 0.8 Power factor lagging . Calculate the voltage at the consumer terminal . Given that supply transformer is a half kilometre away and has a sending end voltage of 433 Volts and the conductor has resistance 0.238 Ω/ km and reactance of 0.296 Ω/ km.

$$\text{Line current} = \frac{100 \times 10^3}{3 \sqrt{x} \times 433} = 133 \text{ Amp}$$

$$\begin{aligned} V \text{ drop} &= I (R \text{ Cos}\Phi + X \text{ Sin } \Phi) \\ &= 133 (0.119 \times 0.8 + 0.148 \times 0.6) \\ &= 133 (0.0952 + 0.0888) \\ &= 133 \times 0.184 = 24.5\text{V} \end{aligned}$$


$$\text{Receiving end voltage} = \frac{433}{\sqrt{3}} - 24.5 = 225.5 \text{ V / Ph or } 390.5 \text{ V /line}$$

Problem

From the given graph, determine the minimum voltage rating required for the direct laid single core cable so that a voltage rating of 0.6/ 1 KV can be achieved when

- (a) 2 circuits are in each group with spacing of 0.6 m
- (b) 3 circuits exist in two touching groups.

Fig 7.9



(a)

$$\text{Phase to earth voltage} = \frac{0.6}{0.92} = 0.652 \text{ KV}$$

$$\text{Phase to phase voltage} = \frac{1}{0.92} = 1.087 \text{ KV}$$

(b)

$$\text{Phase to earth voltage} = \frac{0.6}{0.66} = 0.91 \text{ KV}$$

$$\text{Phase to phase voltage} = \frac{1}{0.66} = 1.52 \text{ KV}$$


Problem

For the simplified single line diagram shown, draw the voltage profile for the following full load conditions

- Full load system voltage at point A is 12.19 KV
- Voltage drop in 11 KV supply is 212V
- Voltage drop in 11 KV transformer is 318 V
- Voltage drop in main is 2 V.
- Voltage drop in sub-main is 10 V
- Voltage drop in final sub circuit is 6 V.

Use 415 V as nominal load voltage.

Fig 7.10




Formula

$$V1 = \text{Voltage drop (1)}$$

$$V2 = \text{Voltage drop (2)}$$

Side	Voltage drop	Side	Voltage drop
11 KV line	12.19 KV	415 V	$\frac{11000}{415} = \frac{12.19 \times 10^3}{V2}$ $V2 = 459 \text{ V}$
11 KV line drop	212 V	415 V	$\frac{11000}{415} = \frac{212}{V2}$ $V2 = 8 \text{ V}$
11 KV Transformer drop	318 V	415	$\frac{11000}{415} = \frac{212}{V2}$

			V2 = 12 V
		415 V main	2 V
		415 V Sub main	10 V
		415 V Final Sub circuit	6 V



Problem

A phase load of 200 KVA 50 Hz is to have it's power factor improved from 0.75 to 0.9. Calculate the size of capacitor bank required if the supply voltage is 415V. Sketch the connection.

Use delta capacitor bank

$\Phi 1 = \cos^{-1} 0.75 = 41$

$$\Phi 2 = \text{Cos}^{-1}0.9 = 26$$

$$Kw = 200 \times 0.71 = 151 \text{ Kvar}$$

$$\text{Kvar correction} = 151 (\tan 41 - \tan 26) = 65.2 \text{ Kvar}$$


$$Xc = \frac{V^2}{Kvar} = \frac{415^2}{65.2 / 3 \times 1000}$$

$$C = \frac{1}{2 \pi f Xc} = 100 \text{ micro farad}$$

2.7 Measure ground level, deviation angles and compass bearing



Linear measurement

Measurement having only one dimension



Angular measurement

The measurement of the angles formed when two straight lines meet.



Site surveying and levelling

Scale of map

1:25000---- Small scale map.

- Planning large scale engineering works involving gradient of roads, sewers , pipes
- Involve with the flow of rivers, street
- When contour lines provide a means of solving problems intervisibility and clearance between points
- To illustrate aspects of regional planning

1:10000---Almost accurate drawn to scale. To accommodate road names.

- Estate management, design of schemes for water supply
- Geological surveying
- Town planning

1:2500-----Highly detailed map providing accurate information to fairly large scale

1:1250----- Double management of 1:2500

- All streets are named
- Block plan , location plan when marking application for planning and building regulation approval
- By designers for initial layout.
- By statutory undertakings to record the positions of power lines.

Survey stations

A survey station is a point of importance at the beginning (or) end of a chart (or) at the junction of one line with another.

It is usually marked by an insertion into the ground of a vertical ranging pole. On the surface , this point may be marked by a stud. Stations should be placed as may be found convenient at the corner of area (or) at prominent points so that the lines joining them are as close as possible.

The base line

This is normally the longest of the chain line forming the pattern of triangle. It should , if possible be laid off on level ground through the center of the site and encompass the whole length of the area. A compass bearing should be taken to fix its direction which in turn will fix the direction of all other lines and allow the position of north to be determined. All survey drawings require a drawn north point.

Survey equipments

Chain


Typical chain pattern The tags shown are for 20 m chain and may be of brass or plastics. Plastics tag may be attached at each whole metre positions with a different colour used at each 5 m position. This is usual for chains longer than 20 m.

Tapes

A tape is used for taking subsidiary measurements in the field. It is suitable for taking off sets which are measurements taken from and at right angles to the chain line or to fix adjacent points as on a boundary.

Laying down the chain

The leader equipped with his ten arrow drags the chain until he is brought up by a gradual pull and directed into line by the followers. Once alignment effected , an arrow is inserted which marks the measurement of one length , care must be taken to ensure that arrows are inserted vertically and the side of vertical handle so that no error equally to the thickness of arrow or the thickness of the handle is in trouble.



On hilly ground

Very often , due to undulations of some size, the last station point can not be seen, the first , yet intermediate poles must be positioned for lining in the chain man.

The difficulty may be resolved by tying two poles together although this is not very accurate or satisfactory, two other methods may be adopted as follows.

Prism in Theodolite

To see pole

Clinometer

To measure height

Required drawing equipments


Long steel straight edge parallel ruler, protractor 360 degree. French curve, Offset scale

2.8 Perform basic survey of short distribution line , extension to produce field notes

Surveying software

Read the article

“ Re- engineering the Transmission Line Design Design Process in 2.8 Perform basic survey of short distribution line extension to produce field notes handout.



2.8 Site Surveying

Surveying Meanings

Level Datum—It is the level line or surface that has been given to a value to which the heights of points above or below can be referred.

Reduced Level (RL)—It is a value given to a point or surface that represents its height above or below , an assumed level datum.

Bench Mark- Bench Marks are the points that have a reduced level value.

Back Sight--- Back sight is the first reading taken from any instrument set up. It is always taken to a point which has a known RL


Fore Sight – It is the last reading taken from an instrument set up . It is taken to a point where RL is known or where RL is required for further levelling.


Intermediate Sight—It is any other reading taken from an instrument set up.

Change Point—It is a point where RL may not be required but is used in series levelling so that the levelling process can be proceeded.

Inverted Level-- It refers to the bottom inside RL of a pipe

Temporary Bench Mark (TBM)—It is a location normally transferred from a bench mark as a convenient location for other heights to be noted or positioned. For example, they may be positioned close to a building being erected.





Determination of height difference between two points

Reading		Difference Height
Station 1	Station 2	
0.812	1.013	0.201
0.566	0.764	0.198
	ADD The Difference	0.399
	Average--- / 2	0.195

Rise and fall calculation

FALL

- Second point value is bigger than first point----- FALL

RISE


- Second point value is smaller than first point-----RISE

Rules


1. Data Entry Table

Back sight	Intermediate	Fore Sight	Rise	Fall	RL	Prism
(1) 1.325					100	A

2. Flow Direction of Data Entry



6. If Second point > First Point----- FALL
 If Second point < First Point-----RISE




8. Calculation of reduced level

First RL – Fall = Second RL

First RL + Rise = Second Level

9. To Adjust



What is a power grid? ^{P1}

Imagine filling a small salt shaker from a large bag of salt. It would be an extremely difficult job and much of the salt would be spilled in the process. However, if a funnel is used, the large amount of salt being poured into the top of the funnel is reduced to a small manageable stream at the narrow end, making the task of filling the salt shaker much easier.

The power grid works in much the same way. Extra high voltage electricity generated at power stations is delivered through the power grid and along the way is reduced to much lower voltage levels which the customer is able to manage.

Perhaps the most recognisable part of the power grid is the network of high voltage transmission lines, supported by large metal pylons, which thread their way through the countryside. Other components of the grid include switching stations which connect the transmission lines together and substations within which the electricity is changed to lower voltages.

The two most common forms of energy used in the production of electricity in New South Wales are coal, which is burned in large boilers to produce steam and thence electricity, and water, which is stored in dams until it is needed. Power stations where the electricity is generated are almost always sited close to their source of energy.

Once the power is generated it is delivered to customers, who may live in the city or the country, by using the power grid.

Extra high voltage transmission lines are needed to carry large amounts of electricity over long distances. In New South Wales most of the transmission lines operate at voltages of 330 kilovolts (one kilovolt equals one thousand volts) or 132 kilovolts, with other lines operating at 500 and 220 kilovolts. These extra high voltage lines have a higher energy efficiency than a large number of lower voltage lines. They are more economic to construct, operate and maintain.

Most transmission lines are overhead lines with aluminium conductors supported by steel lattice towers. The conductors are insulated from the towers by porcelain, glass or synthetic insulators.

Transmission lines can also be laid underground but these are many times more expensive than overhead lines of equal capacity.

The power carried over the high voltage lines must be changed to a lower voltage before it can be used in the home or industry. This occurs in several stages.



500kV double circuit steel tower



330kV single circuit steel tower



330kV double circuit steel tower



132kV double circuit steel tower



PACIFIC POWER

Firstly, the electricity is delivered to substations or switching stations, to either change the voltage level of the power or to provide a switching point for a number of transmission lines.

ENERGY AUSTRALIA

Your local county council (e.g. ...) then uses sub-transmission lines to transfer the purchased electricity at 132 and 66 kilovolts from Pacific Power substations to zone substations. The sub-transmission lines generally have the conductors supported on wood or concrete poles. (Sometimes these poles also carry distribution lines of a lower voltage.) Some sub-transmission lines are also placed underground. Once the power arrives at a zone substation it is converted to 22 or 11 kilovolts (22kV or 11 kV).

From this point high voltage distribution lines transfer the electricity from zone substations to distribution substations sited close to homes and factories, where it is transformed to 240 volts for supply to customers.

The flow of high voltage electricity through the power grid is controlled from a single control centre in Sydney. This control centre uses computers and communications systems to enable the operators to monitor both the flow of electricity and the condition of the power grid. The power carried over the extra

high voltage lines must be changed to a lower voltage before it can be used in the home or industry.


Electricity does not recognise state boundaries. The NSW power grid is joined to similar power grids in Victoria and South Australia. This enables the buying and selling of electricity between states.

The connection with the Victorian grid uses the 330 kilovolt transmission lines from the Snowy Mountains Hydro Scheme. In March 1990, the Victorian power grid was connected to the grid in South Australia by a 275 kilovolt line from a terminal station at Heywood in western Victoria to a substation near Mt Gambier in South Australia.

The South-Eastern Australian power grid extends from northern New South Wales to about 300 kilometres north of Adelaide, a distance of 2200 kilometres, making it one of the longest power grids in the world.

The giant three-state grid enables the more efficient use of resources and a reduced need for generating plant because generating capacity can be shared between the three states. Studies are presently being undertaken to see if it is possible to connect Queensland and Tasmania to the south-east Australian power grid.

New South Wales main power system



- 500 kV double circuit line
 - 330 kV double circuit line
 - 330 kV single circuit line
 - Substation
 - Power station
 - 330 kV cable
- Note: Some lines will initially operate at a lower voltage

ELECTRICITY SUPPLY SYSTEM

Electrical energy is generated and supplied to consumers (domestic, commercial and industrial), by way of an "Electricity Supply System".

The major divisions of the supply system are:

- a) Generation,
- b) Transmission,
- c) Distribution,
- d) Utilisation.

FIG 1 shows the relationship between these divisions in a simple block diagram.



FIG 1

Generation

Conversion of a fuel or other source of energy to electrical energy.

Transmission

Moving large quantities of electrical energy over long distances between generating stations and load centres.

Distribution

Supplying electrical energy to individual consumers (domestic, commercial, industrial, transport).

Utilization

Use of electrical energy by consumer and conversion back to another energy form (heat, light, mechanical etc)

THE N.S.W. POWER SUPPLY SYSTEM

Refer to handout "What is a Power Grid?"

Generation of electrical energy

Carried out by "The Electricity Commission of N.S.W." (trading as Pacific Power)

Methods used in N.S.W. to generate electricity in commercial quantities:

a) Steam Thermal Cycle:

Refer to handout "How Electricity is Made":

- Coal fired boilers convert water to steam,
- steam drives steam turbine,
- steam turbine drives alternator to produce electricity.
- accounts for >90% of total state demand.

b) Hydro-Electric Cycle:

Refer to handout "Hydro Electric Generation":

- Flowing water drives water turbine,
- water turbine drives alternator to produce electricity.
- can supply up to 25% of maximum demand.

c) Gas Turbine:

- natural gas powered turbine driving alternator.
- small output for emergency supplies, hospitals, large buildings,
- usually for emergency start-up of system or peak loading.

d) Internal Combustion Engine:

- diesel engine drives alternator.
- small output for emergency supplies, hospitals, large buildings, industrial complexes.

Note: More detail about other sources and generation in "Generation of Electrical Energy" topic.

Location of Power Stations in N.S.W.

Major Thermal Stations:

Located on or near coalfields, to provide cheap supply of fuel. (Hunter Valley, Central Coast, Lithgow).

Unfortunately, they are far from the major load centres (Sydney, Newcastle, Wollongong)

Major Hydro Stations:

Located in the Snowy Mountains and Kangaroo Valley.
The output of Snowy Mountains is shared between N.S.W. and Victoria.

Gas Turbines:

Located strategically throughout the state to provide emergency supply to re-start the system in the event of a major system fault or shutdown (known as a "Black Start").

Diesel Internal Combustion

Located in industrial sites, large buildings, hospitals etc for providing Un-interrupted Power Supplies (UPS) for computers and emergency equipment when the normal supply fails.

Alternator (Generator) Size and Ratings

The size (rating) of Turbo-Alternators in power stations is specified for:

- a) frequency (50Hz),
- b) generated voltage (typical three phase 16.5kV or 23kV),
- c) power output (typical 500 or 660 megawatts),

Electrical Power Transmission System in N.S.W.

The electrical power transmission system in N.S.W. consists of an interconnected grid of Extra High Voltage (EHV) and High Voltage (HV) overhead transmission lines, linking the major power stations with load centres.

Question??:

Why are EHV and HV lines used for power transmission?

Answer:

To reduce power losses in transmission.

Power loss in a transmission line $P = I^2R$ (power proportional to current squared), so that if the value of current flowing in the line is reduced, then power loss will also be reduced ($\frac{1}{2}$ current reduces power loss to $\frac{1}{4}$)

If the level of transmission voltage is increased, and the current level is decreased by the same proportion, then the same power will be transmitted since power $P = EI$.

Transformers are used to step-up and step-down voltage levels in the transmission system.

EHV (500kV and 330kV) is used in the transmission system.

The output voltage of the alternators (23kV) is stepped-up to 330kV or 500kV for transmission on the EHV overhead transmission lines.

The overhead (O/H) transmission lines carry the energy to large substations, located on the outer perimeter of major load centres.

In these large substations, transformers step-down the voltage level so that a Sub-Transmission system may supply smaller substations in each district. Voltages on the Sub-Transmission system are 132kV and 66kV.

Sub-Transmission substations also have transformers which step down the voltage further, for supply to the Distribution System through HV overhead lines and underground (UG) cables.

Note: Some large industrial consumers are supplied at Sub-Transmission voltages, through "Bulk Supply Points".

Electrical Power Distribution System in N.S.W.

The Distribution System is a series of smaller substations and HV O/H lines and UG cables to supply power to all consumers premises.

Distribution voltages range from 33kV - 22kV - 11kV - 415V - 240V.

Transformers are used to step-down to these different voltage levels in small substations in streets (on pole tops, or in green footpath cabinets), or in customer premises (factories and buildings).

Utilization of Electrical Energy

Customers receive supplies at various voltages, depending on their load requirements.

Domestic:

415 volts	3 phase
415 volts	2 phase
240 volts	1 phase

Commercial:

415 volts	3 phase
11kV	to own transformer on site (office block)

Industrial:

415 volts	3 phase (small factories)
11kV	to own transformer (larger factories)
33kV & 66kV	large industrial complex (oil refineries etc)
132kV	large power requirements to own substation on site (BHP steel works, ALCAN aluminium smelter)

Major Items of Plant in each Division of Supply SystemGeneration:

Boilers, Turbines, Alternators, Step-up transformers.

Transmission & Sub-Transmission:

Transmission lines (OH & UG), substations, bulk supply points, step-down transformers, circuit breakers.

Distribution:

Transmission lines (OH & UG), step-down transformers, metering equipment

Utilization:

Consumer items of machinery, lighting, transformers, motors, furnaces, boilers, heaters, appliances.

Block Diagram of Supply System

Refer to FIG 2 which shows a block diagram of the Electricity Supply System.





FIG 2

POWER GENERATION

Definitions used in Generation

Refer to the total system demand curves shown in FIG 1.



Base Load: Minimum total system demand that is required 24 hours a day.

Thermal stations are operated to supply this demand. The most efficient generators operated at maximum output continuously and are called base load generators.

Peak (Max) Load: Maximum loading (demand) for power on the system in a 24 hour period.

The peak loading is usually a short duration (2 hours) in morning and/or evening.

Hydro-electric and gas turbines have quick response times, and are used in addition to base load generators to supply the extra power at peak loading times.

Spinning Reserve: The extra output that can be supplied from an in service (spinning) generator that is not supplying its maximum output.

The most efficient generating plant is adjusted to give maximum output continuously.

Less efficient thermal plant is operated at less than its maximum output and is adjusted to meet the varying system load.

The reserve output available from these machines, can be obtained immediately it is required, in the event of a sudden increase in system load, or a breakdown of base load generators.

Steam Thermal Power Station

- Can be:
- coal fired boilers
 - nuclear reactor
 - geothermal (heat from within the earth)
 - steam direct to turbine (2000MW in USA)
 - hot water/warm water

a) Coal Fired Power Station

Refer to handout "How Electricity is Made" and FIG 2 below.




FIG 2

Main parts of plant:

Boiler(1): Converts water to steam in boiler tubes (S1) held in drum (2). Steam must be dry (no water) otherwise damage will be caused to the blades of the steam turbine, so steam is passed through superheater (S2) to remove water. Steam is also passed back through boiler reheater (S3) to obtain extra heat, after passing through first stage of turbine. Pulverised coal is blown into boiler (9) and burnt, the air supply being provided by forced draught (FD) fan (10). Gases are removed from boiler to chimney by induced draught (ID) fan (11).

Turbine:

There are three stages of turbine, High Pressure (HP), Medium Pressure (MP), and Low Pressure (LP). Steam impinges on blades of turbine, to cause rotation. The turbine takes many hours to heat up before it can be operated, as there is only small clearance between fixed and moving blades and they must expand at the same rate otherwise damage will occur.

Electrical Alternator:

Rotating electrical machine driven by the steam turbine. Produces a three phase set of AC voltages. Voltages are induced into three sets of windings on the stator (stationary part of machine) by a magnetic field system on the rotor (rotating part of machine). More details of alternators in AC Machines topic.

Condenser:

After steam has passed through the turbine, it is condensed back to water in condenser (6) reheated in reheater (7) so that it can be recycled and pumped back into the boiler with feedpump (8). The condenser requires quantities of cooling water, and the availability of plentiful water will determine the method of cooling used.

Methods of Cooling Spent Steam

Fig 3 shows four different methods used to condense used steam before returning it to the boiler. If there are large quantities of cooling water available from lake, river or ocean, then wet cooling methods can be used, otherwise a dry cooling method must be used.







FIG 3

P11

Environmental Effects of Coal Fired Power Stations

Environmental effects can include air pollution, disposal of coal ash and heating of waterways by the cooling water.

Coal Fired Station Efficiency

The overall efficiency of a modern coal fired steam thermal generating station is approximately 35%. Most heat is lost in the smoke stack and in condensing steam back to water.

FIG 4 shows the approximate proportions of power between each part of a coal fired thermal station.




FIG 4

b) Nuclear Power Station

Similar to coal fired power station, except that heat is produced by a nuclear reactor. A coolant (heavy water, water or gas) circulates through the reactor and carries the heat away to a heat exchanger, where water is heated to produce steam to drive a steam turbine.

Refer to FIG 5 showing a schematic diagram of a nuclear power station.




FIG 5

Types of Nuclear Reactions

Nuclear Fusion:

Combining the nuclei of two light elements releases energy. This is done by making the two nuclei hit each other at high speed, and the fusing of the nuclei together will generate heat. (Hydrogen Bomb is an example)

At present the reaction cannot be controlled, so that it is unsuitable for use in nuclear reactors. Research continues.

Nuclear Fission:

Splitting the nucleus of an atom in two releases considerable amounts of energy.

Uranium 235 is suitable for fission because it contains many neutrons. The nucleus of U_{235} is split by bombarding it with neutrons. The splitting of the nucleus releases other neutrons which will cause a chain reaction by hitting other U_{235} nuclei and releasing much heat energy.

The reaction, (unlike an atomic bomb) is controlled within the reactor and heat is taken away by a circulating liquid to the heat exchanger.

Types of Nuclear Reactors

- | | |
|---------------------------------|---|
| 1. Pressure Water Reactor | heat exchanger |
| 2. Boiling Water Reactor | turbine |
| 3. High Temperature Gas Reactor | heat exchanger |
| 4. Fast Breeder Reactor | also creates nuclear fuel while operating |

c) Geothermal Power Station

Steam or hot water produced by underground volcanic action is used to drive thermal generating plant.

Refer to FIG 6 which shows the principle of Geothermal energy.




FIG 6

Hydro-Electric Power Station

Refer to handout "Hydro Electric Generation" and FIG 7 below




FIG 7

Hydro-electric power is produced by water stored in a dam being allowed to run through a pipe, turning a water turbine which drives an alternator

In NSW, the limited supply of water means that hydro power is not used continuously, but is used to assist thermal power stations during peak demand times or at times of emergency or breakdown.

Pumped Storage Hydro Generation

It is possible to recycle the water which passes through a hydro power station and use it again.

The water after passing through the water turbine is stored in another dam and then pumped back to the top water dam using the water turbine in reverse as a pump.

The pump uses electricity generated by thermal stations during off-peak times.

The water is then available to use again during the peak demand times the next day.

This conserves water.

FIG 8 shows how pumped storage hydro can be used to reduce the consumption of water and decrease the rating of the hydro generator. In FIG a, a 100MW thermal base load station is supplemented by a 60MW rated hydro unit to meet the demand.

In FIG b, a 130MW thermal base load station is supplemented by a 30MW hydro station, and during low load times the thermal station excess power generation is used to pump water to the top reservoir at the pumped storage hydro station.

This results in less water being used and a lower rated hydro station b.




FIG 8

Gas Turbine Power Station

In NSW mainly small units used for emergency supplies in power stations in event of major equipment failure.

Internal Combustion Power Station

Small units, mainly used for and emergency.

Alternative Methods of Generating Power

There are other alternative methods of generating electricity used throughout the world, some of which are used in Australia, but not producing electricity in commercial quantities.

Magnetohydrodynamics (MHD)

Refer to FIG 9 which shows a MHD plant.




FIG 9

An DC emf is induced between the walls of a cylinder, if a hot conducting gas (plasma) expands at high velocity through the tube in the presence of a very strong magnetic field. The hot gas can be produced from burning coal, and if the gas is "seeded" with potassium or caesium it will become conducting. After passing through the MHD unit, the gas could be used to turn water to steam and increase efficiency. Some MHD units are in service overseas (25 - 1000MW), but not yet in Australia.

Solar Electrical Generation (Solar Photo-voltaic)

Refer to FIG 10 below.




FIG 10

A P-N junction, if exposed to light, generates an emf.

Efficiency of units manufactured at present is about 14-18%.

Maximum theoretical efficiency is 30%.

Disadvantage is high cost of installation.

At present \$6000/kW (large scale) compared to \$1200/kW for coal fired thermal.

Requires backup at night (batteries etc).

Good for small supplies in remote areas or unmanned sites (navigation beacons, telephones).

Largest installation overseas is 1MW in the California desert (USA).

Wind Electrical Generation

Wind turbines rotate at low speed and there are various designs.

The output depends on wind speed, with a wind of 8 metres/sec providing twice the power of a wind of 6 metres/sec with the most economical generator size of 300-600 kW rating.

At present, the cost is twice that of coal fired thermal power.

Worldwide, there is about 2000MW of wind generation installed, with Denmark having 250MW out of 2600 turbines.

FIG 11 shows the various designs of wind turbines.




FIG 11

Wave Electrical Generation

Wave energy depends on wave height and wave period.

In NSW, there is wave energy of about 12kW/metre of coastline.

The cost of \$3000/kW of installation is high.

Types of Wave Generators

There are two types of wave generators.

Tapchan

Waves spill over into a reservoir and then water is allowed to run out through a water turbine.

Oscillating Wave Chamber (Wave Resonance Generation)

Refer to FIG 12.

Wave action causes air to be blown and sucked through an air turbine connected to a generator. Blade profile ensures that turbine continues to rotate in the same direction.





FIG 12

Tidal Electrical Generation

A reservoir is built on the shoreline, and as the tide comes in the reservoir is filled.

Gates are closed when the reservoir is filled.

When the tide goes out, water is released through a water turbine.



A 10500.0
 B 10500.0
 C 10500.0
 D 10500.0

9000.0
 9000.0
 9000.0
 9000.0

7500.0
 7500.0
 7500.0
 7500.0

6000.0
 6000.0
 6000.0
 6000.0

995
 4500.0
 4500.0
 4500.0

Invalid
 No data

	ETA	TransGrid	Total	System	Load
A	SYS:LOAD	ETA	TransGrid	Total	System Load
B	SYS:LOAD	ETA	TransGrid	Total	System Load
C	SYS:LOAD	ETA	TransGrid	Total	System Load
D	SYS:LOAD	ETA	TransGrid	Total	System Load

Date	MAX	Max
1-DEC-1995	7789.900	MW
30-NOV-1995	8141.500	MW
29-NOV-1995	8295.000	MW
6-JUL-1995	10342.00	MW

Voltage Stability

Voltage Security

- ◆ Voltage Security is the ability of a system, not only to operate stably, but also to remain stable (as far as the maintenance of system voltage is concerned) following any reasonably credible contingency or adverse system change.

(i)

Voltage Stability

- ◆ Voltage Stability is the ability of a system to maintain voltage so that when load admittance is increased, load power will increase, and so that both power and voltage are controllable.

Known factors contributing to Voltage Collapse

- ◆ Increase in loading
- ◆ Generators of SVC reaching reactive power limits
- ◆ Action of tap changing transformers
- ◆ Load recovery dynamics
- ◆ Line tripping or generator outages

Voltage Collapse

- ◆ Voltage Collapse is the process by which voltage instability leads to very low voltage profiles in a significant part of the system (voltage may collapse due to "angle instability" as well, and sometimes only a careful post-incident analysis can discover the primary cause).


Example of a system voltage collapse

Introduction


The following slides simulate a voltage collapse in a simple power system. The West generator has unlimited VAR (or reactive power) supply capability so it is able to keep the voltage at its bus constant at 1.0 per unit (or at the rated voltage). The East generator can only supply up to 1,200 MVARs (or 1,200 million VARs). There are 6,000 MWs of real power load and 1,000 MVARs of reactive power load at each bus. The West generator is transferring 3,000 MW to the East to help serve the 6,000 MW load in the East. Therefore, the outputs of the West and East generators are 9,000 MW and 3,000 MW respectively.

Six identical lines are initially in service and the 3,000 MWs of real power transfer are divided equally across the lines. The generators in the West and East are supplying reactive power (or VARs) to their local loads plus VARs to the transmission lines to support the transfer. The lines are assumed to be lossless (that is, they do not absorb real power). We have assumed that the individual line capacities (or thermal ratings) exceed 3,000 MW so the real power transfer could occur on one line if maintaining voltage (through sufficient VAR supply) is not a problem. Circuit breakers can open (or trip) the lines.


Case 1: All Lines In-Service 3,000 MW transfer – 500 MW per line




Case 2: One Line Out 3,000 MW transfer – 600 MW per line




Case 1: All Lines In-Service 3,000 MW transfer – 500 MW per line




Case 2: One Line Out 3,000 MW transfer – 600 MW per line




Case 3: Two Lines Out 3,000 MW transfer – 750 MW per line




Case 4: Three Lines Out 3,000 MW transfer – 1,000 MW per line



Case 5: Four Lines Out 3,000 MW transfer – 1,500 MW per line



Case 6: Five Lines Out Voltage Collapse



SYNCHRONOUS ALTERNATORS

All three phase AC machines consists of two parts:

- a) The Stator - stationary or outer part of the machine
- b) The Rotor - rotating or inner part of the machine.

Three Phase Alternators

The rotor and the stator are magnetic circuits, and must be made from stacked laminated magnetic steel, with slots provided to place in the electrical windings.

The laminations are required to reduce eddy current losses due the alternating flux.

Refer to FIG 1 which shows how laminations for stators and rotors are stamped.




FIG 1

WI133b

The stator consists of three sets of windings distributed around the circumference and displaced from each other by 120° .

The windings are placed in the slots provided in the stator laminations.

Refer to FIG 2 which shows the position of the three sets of windings and how they fit into the stator slots.




FIG 2

HU154/155

The rotor consists of DC windings which provide a set of magnetic poles.

When the rotor is driven mechanically by a motor, steam turbine or water turbine, as the magnetic poles rotate, they cut the stator windings and induce into them alternating voltages.

Separate voltages are induced into each winding and because of their 120° displacement from each other, the three voltages are 120° out of phase with each other (three separate phase voltages).

A pair of poles passing a winding will induce one cycle of emf.

The four pole rotor shown on the machine in FIG 2, will induce two cycles of emf into each set of coils for each revolution of the rotor.

For this reason, the large DC Main Exciter requires a DC supply for its own field coils and the DC supply for the Main Exciter, is supplied by a smaller DC generator called a "Pilot Exciter".

The output voltage of the alternator is varied by changing the DC field strength of the alternator rotor poles usually by changing the output of the Pilot Exciter.

The DC supply to rotor windings of smaller alternators can be applied from an external source through sliprings and brushes.

Refer to FIG 4 which shows the connections of the large Alternator, Main Exciter and Pilot Exciter.




FIG 4

WI161

Alternator Stator Windings

The stator windings of a Synchronous Alternator have resistance and inductive reactance.

Usually the winding inductive reactance (called Synchronous Reactance) is very much (10-100 times) greater than the resistance, and a single phase equivalent circuit of the alternator stator windings is as shown in FIG 5.




FIG 5

WI1619

The excitation current I_x produces the flux in the rotor which induces the emf E_0 in the stator windings.

The stator winding resistance is neglected and only the synchronous reactance X_s is shown.

The alternator terminal voltage E_T will be determined by the generated emf E_0 and the voltage drop across the reactance X_s caused by the load current I supplied by the alternator.

Phasor Diagram of an Alternator supplying Lagging Power Factor Load

Refer to FIG 6 which shows the phasor diagram of an alternator supplying a lagging power factor load.




FIG 6

WI1620

The internal generated voltage E_0 is greater than the terminal voltage E_T , and requires the field windings on the rotor to be excited at a high level (over excited).

There is an angular difference between E_0 and E_T measured as angle δ which is called the "Torque or Load Angle".

Phasor Diagram of an Alternator supplying Leading Power Factor Load

Refer to FIG 7 which shows the phasor diagram of an alternator supplying a leading power factor load.




FIG 7

WI1621

The internal generated voltage E_0 is less than the terminal voltage E_T , and requires the field windings on the rotor to be excited at a low level (under excitation) to generate a lower voltage.

There is partial resonance between the alternator synchronous reactance and the capacitance of the load.

$$\begin{aligned} E_{\text{TERMINAL}} &= E_0 - E_T \text{ volts} \\ &= E_0 - I X_s \end{aligned}$$

Regulation % of an Alternator

$$\text{Regulation \%} = \frac{(E_0 - E_T) \times 100}{E_T}$$

Example: Calculate the % regulation of an alternator which has terminal voltage of 12kV at full load and a no load voltage of 15kV.

Solution:

$$\begin{aligned} \text{Regulation \%} &= \frac{(E_0 - E_T) \times 100}{E_T} \\ &= \frac{(15 - 12) \times 100}{12} \\ &= 25\% \end{aligned}$$

Note: This value is quite high, due to the high value of X_s .

Synchronising Alternators

Before any two AC voltage sources (alternators) can be connected in parallel, the voltages must:

- a) be the same magnitude,
- b) be in phase with each other,
- c) have the same frequency,
- d) have the same phase rotation.

In other words, the two voltages must be identical in every way.

The action of making the outputs of two alternators identical before connecting them in parallel is called "Synchronising" the machines.

Connecting an Alternator to an Infinite Busbar

An "Infinite Busbar" is a power system so powerful, that it imposes its own voltage and frequency upon any alternator connected to its terminals.

Once a power system has a number of large alternators connected to it, the voltage and frequency cannot be altered by any additional machine connected to it.

An interconnected power system has a large number of alternators connected in parallel, synchronised with each other, and sharing the total load.

Additional alternators are connected to and disconnected from the power system as the total load varies.

When an alternator is connected to an infinite busbar, there are only two machine parameters that be altered:

- the rotor exciting current I_x
- the mechanical torque of the turbine.

Effect of Varying Excitation of an Alternator on an Infinite Busbar

Refer to FIG 8 which shows the connections of, and phasor diagram for an alternator connected to an infinite busbar, with machine excitation adjusted so that there is no current flow from the terminals.




FIG 8

WI1626a

The alternator is "floating" on the infinite busbar and E_o and E_T are equal and in phase.

No real power in WATTS and no reactive power in VARS flows into or out of the alternator.

Refer to FIG 9 which shows the connections of, and phasor diagram for an alternator connected to an infinite busbar, with machine excitation adjusted so that generated voltage E_o is greater than terminal voltage E_T ("over excited").

P31




FIG 9

WI1626b

Reactive power (VARs) are supplied to the system which appears to be inductive.

E_o and E_T are in phase.

No real power in watts is supplied.

Refer to FIG 10 which shows the connections of, and phasor diagram for an alternator connected to an infinite busbar, with machine excitation adjusted so that generated voltage E_o is less than terminal voltage E_T ("under excited").




FIG 10

WI1626c

Reactive power (VARs) will flow from the system which appears to be capacitive.

E_o and E_T are in phase.

No real power in watts is supplied.

Note: Variation in excitation will only change the VAR flow from the machine, and will not change the real power in watts supplied by the machine.

Real Power Flow from an Alternator on an Infinite Busbar

Assume that the excitation of an alternator is adjusted so that the machine is "floating" on the system, and then mechanical torque of the turbine is increased by opening the steam valve on turbine.

The increased mechanical torque will accelerate the rotor so that the flux lines between the rotor and stator will be stretched from their normal "floating" position as shown in FIG 11.




FIG 11

WI1628

The axis of the rotor poles is advanced by mechanical angle α , and also the generated voltage E_o will become leading the terminal voltage E_r by the load or torque angle δ .

The relationship between α and δ is given by

$$\delta = \alpha \times p/2$$

where p = number of magnetic poles on the machine.

Note: On a two pole machine, $\delta = \alpha$.

Refer to FIG 12 which shows the connection diagram and phasor diagram for a machine connected to an infinite busbar and increased mechanical power input.




FIG 12

WI1627

Notes: The leading angle δ of E_0 with reference to E_r will cause real power in watts to be delivered from the machine to the system.
 If this machine had not been connected to an infinite busbar, then the machine speed would increase, thus increasing the supply frequency.

Calculation of Real Power Flow between Sources

Assume that an alternator is connected to a system as shown in FIG 13. (Single phase equivalent circuit)




FIG 13

WI1633

Assuming that system E_r is consuming real power in watts, and the load has a lagging power factor angle θ .

The resulting single phase phasor diagram is as shown in FIG 14.




FIG 14

WI1633

From the phasor diagram:

$$E_0 = E_r + jIX_s \text{ volts} \quad \sqrt{V + jIX_s}$$

Real Power consumed by the system is:

$$P = E_r \times I \times \cos\theta \text{ watts} \quad \sqrt{VI \cos\theta}$$

Applying the sine rule to the triangle ABC:

$$\frac{IX_s}{\sin\delta} = \frac{E_o}{\sin\phi}$$

$$\text{where } \phi = (90 - \theta)$$

$$\frac{IX_s}{\sin\delta} = \frac{E_o}{\sin(90 - \theta)}$$

$$\frac{IX_s}{\sin\delta} = \frac{E_o}{\cos\theta}$$

Rearranging

$$I \cos\theta = \frac{E_o X_s \sin\delta}{X_s}$$

$$\text{Power out} = E_r I \cos\theta \quad \text{watts per phase}$$

$$\text{Power} = \frac{E_o E_r \sin\delta}{X_s} \quad \text{watts per phase}$$

where:

- E_o = generated voltage
- E_r = terminal voltage
- X_s = alternator synchronous reactance in ohms
- δ = phase angle between E_o and E_r in degrees.

Example: An alternator has the following single phase equivalent values.

$$E_o = 12 \text{ kV}$$

$$E_r = 14 \text{ kV}$$


$$X_s = 2 \Omega$$

E_o leads E_r by 30° .


- a) Calculate the total real power output of the alternator,
- b) Draw a single phase phasor diagram.

Solution:


$$\begin{aligned} \text{Power} &= \frac{E_o E_r \sin\delta}{X_s} \\ &= \frac{12 \times 10^3 \times 14 \times 10^3 \times \sin 30^\circ}{2} \\ &= 42 \text{ MW per phase} \end{aligned}$$




Block diagram of complete turboalternator control systems.




GENERATOR OUTPUT AT VARIOUS GOVERNOR SETTINGS






GENERATOR LOAD SUDDENLY REDUCED

2 GENERATING STATIONS LINKED BY INTERCONNECTOR




How is the 200mw load shared by the 2 machines?



Speed-load diagram for Example

100mw AC machine supplies = 66.66mw
 200mw AC machine supplies = 200 - 66.6
 = 133.3mw

POWER SYSTEM VAR DEMAND



Q. What total MW and MVAR must the generator supply and at what power factor.

① At busbar A

$$P = 50\text{MW} = 0.5\text{PU}$$

$$\text{Vars } Q = 0$$


$$\begin{aligned} \text{Vars lost in } 132\text{kV} &= I^2 X_T \\ &= \frac{(VA)^2}{V^2} \times X_T \\ &= \frac{Q^2 + P^2}{V^2} \times X_T \\ &= \frac{0^2 + 0.5^2}{1^2} \times 0.2/0.2 \end{aligned}$$

$$= 0.025 \text{ PU VARS}$$

$$= 2.5 \text{ MVAR's inductive}$$

② At busbar C

200MW @ 0.8 pf lag



$$\begin{aligned} \tan \phi &= \frac{\text{VARS}}{\text{Watts}} \\ \text{Vars} &= \text{Watts} \times \tan \phi \\ &= 200 \times \tan 36.6^\circ \\ &= 150 \text{ mvars} \end{aligned}$$

③ $P_{\text{TOTAL}} = 2 + 0.5$

$$= 2.5 \text{ PU} = 250 \text{ MW}$$

$Q_{\text{TOTAL}} = 1.5 + 0.025$

$$= 1.525 \text{ PU} = 152.5 \text{ MVAR's}$$

∴ VARS required for 330kV lines + Tx's

$$\begin{aligned} &\frac{P^2 + Q^2}{V^2} \times X_{\text{Total}} \\ &= \frac{2.5^2 + 1.525^2}{1^2} \times 0.14/0.14 \end{aligned}$$

$$= 0.6 \text{ PU (60MVars) P.T.O}$$

GENERATOR LOAD =

$$P = 2.5 \text{ pu} \quad (250 \text{ MW})$$

$$Q = 2.125 \text{ pu} \quad (212.5 \text{ Mvars})$$

$\uparrow =$

$$1.525$$

$$+ 0.6$$

$$- 2.125$$

$$\text{P.f.} = 0.76 \text{ lagging}$$

$$\text{Vars} = \frac{0^2 + 0.5^2}{3} \times 0.2 \quad \text{Bas A}$$

$$= 0.05 \text{ PU Vars}$$

$$P_{\text{TOTAL}} = 0.5 + 2.0 = 2.5 \text{ pu} \quad \text{Bas C}$$

$$Q_{\text{TOTAL}} = 0.05 + 1.5 = 1.55 \text{ PU}$$


VARS in 330kV system

$$\frac{P^2 + Q^2}{V^2} \times X_{\text{TOTAL}}$$



$$= \frac{2.5^2 + 1.55^2}{3^2} \times 0.14$$

$$= 1.21 \text{ mVars}$$

$$\begin{aligned} \text{Total Vars} &= 5 + 121.2 + 150 \\ &= 276.2 \text{ mVars} \end{aligned}$$



$$\begin{aligned} \text{p.f.} = Q &= \frac{276.2}{200} \\ &= \tan^{-1} 1.381 \\ &= 54.1^\circ \end{aligned}$$



Performance chart of a synchronous generator

MACHINE DATA:

60 MW 0.8 pf 75 MVA

MAIN EXCITER CURRENT 500A




Figure : 1 Power-angle curve of a synchronous machine. Resistance and saliency are neglected




Figure : 2 Small disturbance—initial operation on power-angle curve at P_0, δ_0 . Linear movement assumed about P_0, δ_0

$$\frac{\Delta P}{\Delta \delta}$$




Figure 3. Power-angle curves for one line and two lines in parallel. Equal-area criterion. Resistance neglected




Figure 4 (a) Equivalent circuit of a line supplying a load $P + jQ$. (b) Relation between load voltages and received power at constant power factor for a 400 kV, $2 \times 260 \text{ mm}^2$ conductor line, 160 km in length. Thermal ratings of the line are indicated

Voltage Control Methods

① Alternator excitation, Generator excitation

② VAR Balance

VAR injection - static cap, cap banks	}	course control
- inductors		
- static VAR compensation		
- synchronous condensers		control

③ Power transformer tap changers

Generator excitation

Transformer Tap changers	}	steps up + down output voltage
Capacitor Banks		

Shunt reactor, for too much capacitance. fine control

Static var compensation.

TRANSMISSION LINE CONSTRUCTION

Transmission involves moving large quantities of electrical energy over long distances between generating stations and load centres. The transmission system consists of 500kV and 330kV overhead transmission lines of steel tower construction. The sub-transmission system consists of 132kV and 66kV overhead lines on steel towers and wood poles and also underground cables.

Route Selection for Transmission Lines

The easement space required for overhead transmission lines means that the route taken by a line is an environmentally sensitive issue.

Ideally, the transmission line should take the shortest route to reduce its capital and installation cost.

However, the selection of the route of a transmission line, will depend on a number of important considerations:

- a) shape of the terrain, affecting cost of construction,
- b) acquisition of easement land,
- c) proximity to housing,
- d) ease of maintenance and access to easement.

Components of Transmission Lines

Conductor Support Structures

Support structures are required to keep the conductors at a safe height above the ground and also to keep them apart.

Refer to FIG 1 which shows various arrangements of support structures.




FIG 1

EASE

COMMUNICATION METHODS

- ① Telecommunication lines e.g. Telstra
- ② Solid conductors - pilot cables
 - control cables
 - buried adjacent to H.V. power cables
- ③ Fibre optics - underground
 - overhead
- ④ Power line carrier - using H.V. conductors to transmit comms info at higher frequencies.
 - wave traps allow H.F. signals to be injected + filtered at remote end of line.
- ⑤ Microwave system

HIGH VOLTAGE CABLES

Factors influencing Installation of Cables

- a) Environmental - appearance of overhead lines
- b) Space - no casement available for overhead lines in built up areas.

Cost Relative to Overhead Lines

Higher capital cost (10-20 times that of an overhead line)

Advantages:

- a) protected from lightning strikes
- b) reduced maintenance of cable since it is protected from environment.

Disadvantages:

- a) higher repair cost after failure
- b) maintenance of auxiliary equipment (oil/gas supplies etc)

Types of Cable Construction

Paper Insulated - Metal Sheathed

- a) **Solid type** (up to 66kV)

Oil impregnated paper is wrapped around the conductor in concentric layers.

A lead or aluminium sheath is extruded over the paper to prevent ingress of moisture and mechanical damage to the cable.

Oil impregnated paper has a high dielectric strength than plain paper.

Typical dielectric strength of plain paper is 70kV peak/cm while oil impregnated paper has a typical strength of 600kV peak/cm.

Disadvantage: Voids (spaces) may occur in the paper insulation over a period of time, and this will lead to local electrical stress, ionisation of the air in the void and eventual failure of the insulation.

Refer to FIG 1 which shows solid insulated cables




FIG 1

b) **Pressurised type**

The paper insulated cable is sealed so that a pressure above atmospheric pressure is maintained by gas or insulating oil.

- Advantages:**
- i) Any voids in the paper insulation are filled with gas or oil, and so ionisation is prevented.
 - ii) Moisture is prevented from entering the cable,
 - iii) Loss of oil pressure is an early indication of cable damage.

Oil Filled Cables (up to 500kV)

The thin high quality insulating oil used in cables is not intended for cooling, but is used to increase the dielectric strength of the cable insulation.

Reservoirs of oil are installed along the route to maintain supply of oil pressure and to allow for the expansion and contraction of the oil during heating and cooling cycle of the cable.

The oil system is sealed, and pressure is applied to the oil by gas (nitrogen) filled bellows in the oil pressure tanks.

Pressure switches are installed to detect loss of oil pressure and are used to initiate alarms at the remote ends of the cable when oil pressure is lost.

The cable is divided into hydraulic sections depending on the cable route profile, to ensure that excessive pressure is not developed at the lowest section of the cable.

If the cable is damaged with subsequent loss of oil pressure, the cable must be de-energised because if air is drawn into the cable, electrical failure will result due to ionisation of the air.

If air has entered the cable, either due to damage or after jointing, all air must be removed from the cable by applying a vacuum pump before the cable is energised.

Disadvantage: Higher initial cost of installation and more complicated jointing procedure than with solid cables.

Refer to FIG 2 which shows single and three core oil filled cables




FIG 2

Gas filled Cables (up to 132kV)

Similar to oil filled cables except that the cable is pressurised with nitrogen.

Requires gas pressure tanks, pressure switches and alarm systems to monitor the cable condition.

Sheath and Armouring Materials

Metal armouring is applied over the sheath of some cables to provide additional mechanical strength.

Stranded steel wire is used to allow more flexibility of the cable.

PVC serving over the outside of the cable provides protection against corrosion.

Electrical Stress in Dielectric Materials

Refer to FIG 3 which shows the electrical stress diagrams for single and three core cables.




FIG 3

Cable Inductance

The overhead line inductance equation shown below can be applied to a cable:

$$L = \frac{\mu_r \log_e(d/r_m)}{2\pi} \quad \text{henry/metre}$$

where r_m = geometric mean radius = $re^{-0.25}$

However, this calculation does not take into account mutual coupling with the sheath and mutual coupling with the armour wires which will add 10-20% to the inductance value.

Conductor Resistance

Affected by temperature, skin effect and proximity effect.

Induced Voltage in Cable Sheaths

Emfs will be induced into the metallic sheath of HV power cables when current flows in the HV conductor.

Three phase HV cable installations will have induced voltages in the sheaths of the cables and these voltages cause circulating currents in the sheaths which will heat the cable.

The sheaths must be earthed so that the circulating currents will flow.

The effect of circulating currents in sheaths is reduced by electrically insulating sections of the cable sheath from each other and by transposing the 3 phase sheaths to help balance out the induced emfs and circulating currents.

This transposing of cable sheaths is called "**Cross Bonding**".

Cable sheaths also protect the cable against over voltage spikes caused by lightning and switching transients.

Breakdown of Insulation

Breakdown of cable insulation can occur due to:

- a) puncture - mainly during testing in the laboratory,
- b) thermal instability,
- c) tracking - across insulation following void ionisation causing burning of insulation in "treering" patterns,
- d) loss of oil in oil filled cables.

Cable Rating

The thermal conductivity of soil in which the cable is buried, is important to ensure that the heat generated by the cable in service is conducted away from the cable.

Three phase cables in particular have high electrical stress points in the dielectric material due to varying field strengths.

Stress can be reduced by screening each phase conductor separately by metallised paper sheaths connected together and to the overall aluminium sheath.

This connection equalises the potential gradient and produces a radial stress in each cable similar to a single core cable.

The dielectric strength of paper insulation is greater across the layer than along the layer and so tangential stress fields should be avoided.

Capacitance of single Core cable

The capacitance of a single core cable can be determined using the following equation:

$$C = \frac{2\pi r \epsilon_0 \epsilon_r}{\log_e(R/r)} \text{ farad/metre length}$$

where ϵ_0 = permittivity of air = 8.85×10^{-12}

ϵ_r = relative permittivity of dielectric material

R = radius of cable outer sheath in metres

r = radius of conductor in metres

Electrical Stress in Single core Cables

Potential Gradient at radius x is:

$$E_x = \frac{V}{x \log_e(R/r)} \text{ volts/metre (1 phase equivalent)}$$

where

V = potential difference between sheath and conductor in volts

R = radius of cable outer sheath in metres

r = radius of conductor in metres

Maximum stress occurs at the surface of the conductor ($x = r$) and can be calculated from:

$$E_r = \frac{V}{r \log_e(R/r)} \text{ volts/metre (1 phase equivalent)}$$

from this equation it can be seen that the smaller the conductor size, the higher is the electrical stress.

HV cables are buried in "stabilised backfill" which is a mixture of sand and cement which helps to protect the cable, prevent movement and has a high thermal conductivity.

Cable Current Rating depends on:


- a) thickness of dielectric,
- b) ambient temperature,
- c) proximity of other cables,
- d) load cycle,
- e) depth of burial,
- f) soil conductivity.

Cable Termination

Cables terminated in switchgear or connecting to an overhead line must have the insulation removed and replaced by a graded insulation to allow the HV conductor to be brought out to the air.

This is done in a cable "sealing end" where the oil, gas or solid insulated cable end is sealed and the conductor is available to connect.

P67



ALUMINIUM SHEATHED

13 1/2" / 1x0.665 SO"
SHEATHED EXTRUDED PVC SERVED OIL FILLED CABLE

INSULATION COORDINATION

Insulation coordination is the correlation of the insulation strengths of components of the high voltage power system, to minimise damage and loss of supply caused by over voltages.

Steps taken to minimise supply interruptions due to overvoltage are:

- a) to ensure that system insulation will withstand all normal stresses and most abnormal stresses,
- b) to discharge or divert overvoltages which exceed the withstand strength of apparatus,
- c) to ensure that breakdowns occur by external flashover, rather than internal failure of equipment such as puncture or breakdown of solid or liquid dielectrics,
- d) and to control points at which breakdowns occur, thus avoiding important items of equipment.

Sources of Overvoltage

Overvoltages can be either at system frequency or due to transient surges with higher frequency components.

System Frequency Overvoltages

Overvoltages at the power frequency can be caused by:

- a) sudden loss of load on a generator (20%-30% overvoltage),
- b) energising an unloaded transmission line (up to 90% overvoltage),
- c) unbalanced system faults which may cause unfaulted phase voltages to rise above normal.

Transient Overvoltages

Power system transient overvoltages may be generated either internally or externally.

Internal generation is from switching surges.

External generation is from lightning strikes.

On equipment rated at between 200-300kV, switching surges are about the same intensity as lightning strikes.

On equipment rated over 300kV, switching surges produce larger transients than lightning strikes.

Lightning Strikes

Lightning strikes on HV equipment may be either direct or indirect.

Lightning strikes can range in size from a few kA to 100kA.

The current waveform is a unidirectional pulse rising to a peak value in $\approx 3\mu\text{sec}$ and falling away in 30-40 μsec .

Direct Lightning Strike

A direct strike occurs when lightning strikes the line conductor and causes a flashover of the line insulators or is rapidly attenuated by corona along the line.

Any discharge current flowing through the towers to earth may set up a large voltage drop due to tower footing resistance and tower inductance.

There may result a back flashover from the tower to the line.

Indirect Lightning Strike

An indirect strike occurs where a voltage is induced into the line by a nearby object being struck by lightning.

This is usually only a problem on lower voltage lines rated at less than 33kV.

Effect of Lightning Strikes on Overhead Lines

If lightning strikes an overhead line, the excessive voltage can cause damage to line insulators and the wave can travel along the line to cause damage to terminal equipment in substations.

FIG 1 shows how charge moves along the line in a wave after a lightning strike.




FIG 1

Electrical Testing of HV Equipment

Electrical testing of HV equipment is carried out to ensure that insulation can withstand normal and surge voltages.

The two main tests carried out are:

- a) HV impulse test,
- b) HV power frequency test.

HV Impulse Test

The standard impulse test is intended to reproduce the effects of switching transients and lightning strikes.

Refer to FIG 2 which shows the standard 1/50 impulse test waveform.




FIG 2

The wave specification of 1/50 indicates that the test voltage rises to the peak value in 1µsec and then drops to 50% of the peak value by 50µsec.

Typical value of test voltage for 330kV equipment is 1050kV (peak).

HV Power Frequency Test

A voltage of $\approx 150\%$ of the rated voltage at power frequency is applied to the apparatus under test for 1 minute, and leakage current measured.

Typical value of test voltage for 330kV equipment is 460kV rms.

Protection of Overhead Lines and Substation Equipment from Surges

Surge Protection Devices

HV equipment is protected against surges by Surge Arrestors (also called Surge Diverters) and Rod or Arc Gaps.

These devices limit the surge voltage and conduct the surge energy away from the protected equipment.

In particular, they are installed and located for protecting transformers and cables that are expensive the repair, if their paper insulation is damaged by impulse voltages.

Overhead Earthwire (Shield Conductor)

At the very top of each tower on each side, are installed earthing conductors, which run the whole length of the line, and are earthed at each tower.

They provide an earthed shield above the live conductors and attract lightning away from the line.

Tower Earthing

Each tower must be solidly connected to earth and earthing rods and an earth grid are installed at the base of each tower.

Earthing is important so that any shorting of insulators does not cause the tower to become dangerously alive.

Refer to FIG 3. which shows how a lightning strike can cause flashover of insulators, resulting in high current flow to earth. The potential of the tower will rise because the tower earth resistance is high.




FIG 3

Lightning/Surge Arrestors and Diverters

Surge arrestors and diverters are protective devices which are connected between HV conductors and earth, to divert any surge to earth.

They protect valuable equipment such as transformers or cables from being damaged or destroyed by excessive high voltage surges travelling along a line after a lightning strike.

They are connected as close as possible to the terminals of the transformer or equipment to be protected.

Pr

The surge diverter does not conduct at normal system voltage level, but is designed to conduct at a pre-determined level of voltage above normal voltage.

Refer to FIG 4 which shows the construction of a typical non-linear resistor type surge diverter.




FIG 4

The non-linear resistor, usually made of silicon carbide, acts as a low resistance to the flow of high discharge voltages and a high resistance at normal power frequency voltage.

The series spark gaps keep the circuit open under normal conditions.

Sometimes grading resistors are connected in parallel with multiple gaps to assist in voltage distribution.

The assembly is usually evacuated and filled with dry nitrogen at atmospheric pressure to ensure that the operation is not affected by surrounding atmospheric conditions.

Refer to FIG 5 which shows the operating sequence of a surge diverter.




FIG 5

When a surge reaches the surge diverter, the excessive voltage causes the diverter to conduct, diverting the energy to earth and when the voltage drops back to normal, the diverter ceases conducting.